Canon

PUB. DIE-0391-000A

HD Camcorder

Instruction Manual

LEGRIA
HF M46

LEGRIA
HF M406

PAL

Downloaded From VideoCamera-Manual.com Manuals

HDMI AVCHD

Important Usage Instructions

WARNING!

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING!

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

COPYRIGHT WARNING:
Unauthorized recording of copyrighted materials may infringe on the rights of copyright owners and be contrary to copyright laws.

CAUTION:
TO REDUCE THE RISK OF ELECTRIC SHOCK AND TO REDUCE ANNOYING INTERFERENCE, USE THE RECOMMENDED ACCESSORIES ONLY.

CAUTION:
DISCONNECT THE MAINS PLUG FROM THE SUPPLY SOCKET WHEN NOT IN USE.

To reduce the risk of electric shock, do not expose this product to dripping or splashing.

The Mains plug is used as the disconnect device. The Mains plug shall remain readily operable to disconnect the plug in case of an accident.

CA-570 identification plate is located on the bottom.

Using any device other than the Compact Power Adapter CA-570 may damage the camcorder.

Downloaded From VideoCamera-Manual.com Manuals

European Union (and EEA) only.



These symbols indicate that this product is not to be disposed of with your household waste, according to the WEEE Directive (2002/96/EC), the Battery Directive (2006/66/EC) and/or your national laws implementing those Directives.

This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (EEE) and batteries and accumulators. Improper handling of this type of waste could have a possible impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. Your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources.

For more information about the recycling of this product, please contact your local city office, waste authority, approved scheme or your household waste disposal service or visit www.canon-europe.com/environment.

(EEA: Norway, Iceland and Liechtenstein)

Trademark Acknowledgements

- SD, SDHC and SDXC Logos are trademarks of SD-3C, LLC.
- Microsoft and Windows are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.
- Macintosh and Mac OS are trademarks of Apple Inc., registered in the U.S. and other countries.
- “x.v.Color” and the “x.v.Color” logo are trademarks.
- HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.
- “AVCHD” and the “AVCHD” logo are trademarks of Panasonic Corporation and Sony Corporation.
- Manufactured under license from Dolby Laboratories. “Dolby” and the double-D symbol are trademarks of Dolby Laboratories.

DOLBY DIGITAL STEREO CREATOR

- YouTube is a trademark of Google Inc.
- Other names and products not mentioned above may be trademarks or registered trademarks of their respective companies.
- This device incorporates exFAT technology licensed from Microsoft.
- ANY USE OF THIS PRODUCT OTHER THAN CONSUMER PERSONAL USE IN ANY MANNER THAT COMPLIES WITH THE MPEG-2 STANDARD FOR ENCODING VIDEO INFORMATION FOR PACKAGED MEDIA IS EXPRESSLY PROHIBITED WITHOUT A LICENSE UNDER APPLICABLE PATENTS IN THE MPEG-2 PATENT PORTFOLIO, WHICH LICENSE IS AVAILABLE FROM MPEG LA, L.L.C., 250 STEELE STREET, SUITE 300, DENVER, COLORADO 80206.
- This product is licensed under AT&T patents for the MPEG-4 standard and may be used for encoding MPEG-4 compliant video and/or decoding MPEG-4 compliant video that was encoded only (1) for a personal and non-commercial purpose or (2) by a video provider licensed under the AT&T patents to provide MPEG-4 compliant video. No license is granted or implied for any other use for MPEG-4 standard.

Downloaded From VideoCamera-Manual.com Manuals

Exciting Features and New Functions

FULL HD 1080 [1] HD CMOS FULL HD SENSOR

Your camcorder's Full HD CMOS sensor captures video at a resolution of 1,920 x 1,080 pixels[2]. Videos are then recorded in the memory, using AVCHD specifications[3].
With your new HD camcorder, capturing the special moments in your life with amazing image quality and in lifelike vibrant colors is easy and fun!

Story Creator (📖 58)

Transform your movies into compelling video stories just by recording video following simple pre-scripted suggestions, optimized for various scenarios.

Decoration (📖 62)

Add flare to your movies by adding text, stamps or freehand drawings directly in the camcorder.

Cinema-Look Filters (📖 60)

Use professional cinema-look filters to create unique movies with distinctive looks.

[1] "Full HD 1080" refers to Canon camcorders compliant with high-definition video composed of 1,080 vertical pixels (scanning lines).
[2] Video is recorded at this resolution only when the recording mode is set to MXP or FXP mode. In other recording modes, the picture is recorded at 1,440 x 1,080 pixels.
[3] AVCHD is a standard for recording high-definition video. With AVCHD specifications, the video signal is recorded using MPEG-4 AVC/H.264 compression and the audio signal is recorded in Dolby Digital.

Downloaded From VideoCamera-Manual.com Manuals

Smart AUTO (📖 42)



Smart AUTO automatically selects the best scene mode for the scene you want to shoot. You get spectacular recordings every time without worrying about settings.

Video Snapshot (📖 61)

Shoot or capture short scenes and arrange them into a video clip set to your favorite background music.

Relay Recording (📖 37)

The memory almost full? Use the double memory card slot to keep on recording video without interruption.

Face Detection (📖 83)

The camcorder automatically detects people's faces and adjusts the focus and other settings accordingly for beautiful results.

Image Stabilization

Dynamic IS (📖 81) compensates for camcorder shake when you shoot video while walking. Powered IS (📖 82) will produce stable shots when you zoom in on distant subjects (full telephoto).

Downloaded From VideoCamera-Manual.com Manuals

Enjoying your Recordings on Other Devices


AVCHD
Connect the camcorder to an HDTV (📖 119)
Play video directly from your recorded memory card
AVCHD-compatible HDTVs and digital recorders with a card slot **compatible with the type of memory card used***.
POWERED IS/ WEB
Eye-Fi
Use an Eye-Fi card (📖 133) to wirelessly upload recordings to your computer or a video sharing Web site.
Save or upload to the Web.
Create discs
Use the supplied PIXELA's software (📖 123, 128).
AVCHD
MPEG-2
High Definition
Standard Definition
HF M46 Convert your HD movies, in the camcorder itself, to standard definition files (📖 128).

* Refer to the instruction manual of the device. Depending on the device used, correct playback may not be possible even if the device is AVCHD-compatible. In such case, play back the recordings on the memory card using the camcorder.

Downloaded From VideoCamera-Manual.com Manuals

Downloaded From VideoCamera-Manual.com Manuals

Table of contents

■ Introduction

4 Exciting Features and New Functions
12 About this Manual

14 Getting to Know the Camcorder
14 Supplied Accessories and CD-ROMs
16 Names of Parts

■ Preparations

19 Getting Started
19 Charging the Battery Pack
21 Preparing the Accessories
24 Adjusting the Position and Brightness of the LCD Screen

26 Basic Operation of the Camcorder
26 Using the Touch Screen
27 Operating Modes
28 Using the Menus

30 First Time Settings
30 Setting the Date and Time
31 Changing the Language
31 Changing the Time Zone

33 Using a Memory Card
33 Memory Cards Compatible for Use with the Camcorder
35 Inserting and Removing a Memory Card
36 Selecting the Memory for the Recordings
37 Relay Recording
38 Initializing the Memory

Downloaded From VideoCamera-Manual.com Manuals

■ AUTO Mode

40 Basic Recording

40 Shooting Video and Taking Photos in AUTO Mode

42 About the Smart AUTO function

45 Zooming

46 Quick Start Function

■ Video

48 Basic Playback

48 Playing Back Video

52 3D Flip View

52 The Index Selection Screen: Selecting the Content to Play Back

54 Deleting Scenes and Stories

58 Video Stories and Cinema Style

58 Using Story Creator to Create Compelling Stories

60 CINEMA Mode and Cinema-Look Filters

61 Video Snapshot

62 Decoration: Adding a Personal Touch

66 Playing Back Stories from the Gallery

68 Rating Scenes

69 Playback with Background Music

71 Copying and Moving Scenes Within/Between Stories

72 Selecting a Story's Thumbnail Image

73 Changing a Story's Title

75 Advanced Functions

75 Recording in **M** (Manual) Mode

76 Selecting the Video Quality (Recording Mode)

78 Selecting the Frame Rate

78 Special Scene Recording Programs

81 Advanced Image Stabilization

82 Pre-Recording

83 Face Detection

85 Touch & Track

86 Faders

87 Manually Setting the Shutter Speed or Aperture

89 Manual Exposure Adjustment

Downloaded From VideoCamera-Manual.com Manuals

90 Automatic Gain Control (AGC) Limit
90 Manual Focus Adjustment
92 Tele Macro
93 White Balance
94 Image Effects
95 Self Timer
96 Audio Recording Level
97 Built-In Microphone Directionality
98 Audio Equalizer
99 Using Headphones
100 Using the Mini Advanced Shoe
101 Using an External Microphone
102 Using an External Video Light
102 Using a Zoom Remote Controller
104 Selecting the Playback Starting Point
105 Onscreen Displays and Data Code
106 Capturing Photos and Video Snapshot Scenes from a Movie
108 Dividing Scenes

■ Photos

110 Viewing Photos
112 Deleting Photos
113 Slideshow

■ External Connections

115 Terminals on the Camcorder
116 Connection Diagrams

119 Playback on a TV Screen

120 Saving and Sharing Your Recordings
120 Copying Recordings to a Memory Card
123 Saving Recordings on a Computer
127 Copying Recordings to an External Video Recorder
128 HF M46 Uploading Movies to Video Sharing Web Sites

Downloaded From VideoCamera-Manual.com Manuals

■ Additional Information

135 Appendix: Menu Options Lists
135 FUNC. Panel
138 Setup Menus

150 Appendix: Onscreen Icons and Displays

154 Trouble?
154 Troubleshooting
160 List of Messages

167 Do's and Don'ts
167 Handling Precautions
172 Maintenance/Others
173 Using the Camcorder Abroad

174 General Information
174 Accessories
175 Optional Accessories
180 Specifications
184 Index

Downloaded From VideoCamera-Manual.com Manuals

About this Manual

Thank you for purchasing the Canon LEGRIA HF M46 / LEGRIA HF M406. Please read this manual carefully before you use the camcorder and retain it for future reference. Should your camcorder fail to operate correctly, refer to *Troubleshooting* (📖 154).

Conventions Used in this Manual

- IMPORTANT: Precautions related to the camcorder's operation.
- NOTES: Additional topics that complement the basic operating procedures.
- POINTS TO CHECK: Restrictions or requirements regarding the function described.
- 📖: Reference page number within this manual.
- PHOTO > References to sections of the 'Photo Application' Instruction Manual, included as a PDF file in the supplied Camcorder Supplemental Disc.
- HFM46 : Text that applies only to the models shown in the icon.
- The following terms are used in this manual:
  When not specified as "memory card" or "built-in memory", the term "memory" by itself refers to both.
  "Scene" refers to one movie unit from the point you press the START/STOP button to start recording until you press again to pause the recording.
- The photos included in this manual are simulated pictures taken with a still camera. Unless indicated otherwise, illustrations and menu icons refer to the HFM46.

Downloaded From VideoCamera-Manual.com Manuals

AUTO indicates that a function is available in the operating mode indicated and AUTO indicates that the function is not available. For a detailed explanation refer to *Operating Modes* (📖 27).

Brackets [ ] are used to refer to control buttons and menu options you will touch on the screen and to other onscreen messages and displays.


Self Timer
Operating modes: AUTO M CINEMA
[FUNC.] [MENU] [Self Timer]
ON On] [✕]
• will appear on the screen.
• Repeat, selecting [OFF Off], to turn off the self timer.
Movies: In record pause mode, press START/STOP.
The camcorder starts recording after a 10-second countdown*. The countdown appears on the screen.
touch [PHOTO].
to after a 10-second countdown*. The

The names of physical buttons and switches on the camcorder are indicated within a "button" frame.
For example DISP.

The ❯ arrow is used to abbreviate menu selections. For a detailed explanation on how to use the menus, refer to *Using the Menus* (📖 28). For a concise summary of all available menu options and settings, refer to the appendix *Menu Options Lists* (📖 135).

Downloaded From VideoCamera-Manual.com Manuals

Supplied Accessories and CD-ROMs

The following accessories are supplied with the camcorder:



▶CA-570 Compact Power Adapter (incl. power cord)

BP-808 Battery Pack◀

▶WL-D89 Wireless Controller (incl. CR2025 lithium button battery)

Stylus Pen◀



▶HTC-100/S HDMI Cable



STV-250N Stereo Video Cable◀

▶Quick Guide



IFC-300PCU/S USB Cable◀

▶Installation Guide for PIXELA's Software

Downloaded From VideoCamera-Manual.com Manuals

The following CD-ROMs and software are supplied with the camcorder:

- **PIXELA's Transfer Utility** CD-ROM*
  - Use **Transfer Utility** for saving and transferring movies and music files you can use as background music.
- **PIXELA's VideoBrowser** CD-ROM*
  - In addition to all the functionality of **Transfer Utility**, you can use **VideoBrowser** for managing, editing, and playing back movies.
- **Instruction Manual/Photo Applications Ver.35*/Music Data/ Image Mix Data** CD-ROM (referred in the manual as "Camcorder Supplemental Disc"). Contains the following components.
  - Instruction Manual - The full-version instruction manual of the camcorder (this PDF file).
  - Photo Application - Software for saving, managing, and printing photos.
  - Music data - Music files that can be used as background music during playback. These music files are for exclusive use with the supplied PIXELA's software. The disc cannot be played back on CD players.
  - Image mix data - Image files that can be used with the image mix function (image mix frames).

* The CD-ROM includes the instruction manual of the software (on PDF file).

Downloaded From VideoCamera-Manual.com Manuals

Names of Parts

Left side view



Right side view



Front view



① (camera/play) button (📖 27)
② VIDEO SNAP (video snapshot) button (📖 61)
③ (Story Creator button) (📖 58)
④ DISP. (onscreen display) button (📖 24, 105)/
BATT. INFO button (📖 153)
⑤ USB terminal (📖 115, 118, 127)
⑥ AV OUT terminal (📖 115, 117)/
(headphones) terminal (📖 99)
⑦ COMPONENT OUT terminal (📖 115, 117)
⑧ HDMI OUT terminal (📖 115, 116)
⑨ ACCESS indicator (📖 40)
⑩ Mode switch (📖 27)
⑪ Grip belt (📖 22)
⑫ Speaker (📖 50)
⑬ Strap mount (📖 22)
⑭ Double memory card slot cover
⑮ Memory card slot A (📖 35)
⑯ Memory card slot B (📖 35)
⑰ Stereo microphone (📖 96, 97)
⑱ Instant AF sensor (📖 140)

Downloaded From VideoCamera-Manual.com Manuals

Top view



⑲ Mini advanced shoe (📖 100)
⑳ Zoom lever (📖 45)
㉑ POWER button
㉒ ON/OFF (CHG) (charge) indicator:
Green – ON
Orange – Standby (📖 46)
Red – Charging (📖 19)
㉓ Remote sensor (📖 21)
㉔ LCD touch screen (📖 24, 26)
㉕ POWERED IS button (📖 82)/
HF M46 WEB button (📖 128)
㉖ Battery attachment unit (📖 19)
㉗ START/STOP button (📖 40)
㉘ DC IN terminal (📖 19)
㉙ RESET button (📖 158)

LCD panel



Back view



Downloaded From VideoCamera-Manual.com Manuals

Bottom view



㉚ BATTERY RELEASE switch (📖 20)
㉛ Tripod socket (📖 168)
㉜ **Serial number**



Wireless Controller WL-D89



① START/STOP button (📖 40)
② ↺▶ (index selection) button (📖 52)
Press and hold for more than 2 seconds to switch between shooting and playback mode.
③ MENU button (📖 29, 138)
④ DISP. (onscreen display) button (📖 105)
⑤ SET button
⑥ ■ (stop) button (📖 48)
⑦ PHOTO button (📖 40)
⑧ Zoom buttons (📖 45)
⑨ Navigation buttons (▲/▼/◀/▶)
⑩ ▶/❚❚ (play/pause) button (📖 48)

Downloaded From VideoCamera-Manual.com Manuals

Preparations

This chapter describes basic operations, such as using the touch panel, navigating the menus, and first time settings to help you learn more about your camcorder.

Getting Started

Charging the Battery Pack

The camcorder can be powered with a battery pack or directly using the compact power adapter. The first time you use a battery pack, fully charge it and then use the camcorder until the battery pack is completely exhausted. Doing so will ensure that the remaining recording time will be displayed accurately.
For approximate charging times and recording/playback times with a fully charged battery pack, refer to *Charging, Recording and Playback Times* (📖 176).

1. **Connect the power cord to the compact power adapter.**
2. **Plug the power cord into a power outlet.**
3. **Connect the compact power adapter to the camcorder's DC IN terminal.**
4. **Attach the battery pack to the camcorder.**
   Press the battery pack softly into the battery attachment unit and slide it up until it clicks in place.



Downloaded From VideoCamera-Manual.com Manuals

5 **Charging will start when the camcorder is turned off.**

- If the camcorder was on, the green ON/OFF (CHG) indicator will go out when you turn off the camcorder. After a moment, the ON/OFF (CHG) indicator will start flashing in red (battery pack charging). The red ON/OFF (CHG) indicator will go out when the battery pack is fully charged.
- If the indicator flashes quickly, refer to *Troubleshooting* (📖 157).



To remove the battery pack

1 Slide BATTERY RELEASE in the direction of the arrow and hold it pressed down.

2 Slide the battery pack and then pull it out.



IMPORTANT

- Turn off the camcorder before connecting or disconnecting the compact power adapter. After pressing POWER to turn off the camcorder, important data is updated in the memory. Be sure to wait until the green ON/OFF (CHG) indicator goes out.
- Do not connect to the camcorder's DC IN terminal or to the compact power adapter any electrical equipment that is not expressly recommended for use with this camcorder.
- To prevent equipment breakdowns and excessive heating, do not connect the supplied compact power adapter to voltage converters for overseas travels or special power sources such as those on aircraft and ships, DC-AC inverters, etc.

Downloaded From VideoCamera-Manual.com Manuals

NOTES

- We recommend charging the battery pack in temperatures between 10 °C and 30 °C. If either the ambient temperature or the battery pack's temperature is outside the range of approx. 0 °C to 40 °C, charging will not start.
- The battery pack will be charged only when the camcorder is off.
- If the power supply was disconnected while charging a battery pack, make sure the ON/OFF (CHG) indicator has gone out before restoring the power supply.
- If remaining battery time is an issue, you can power the camcorder using the compact power adapter so the battery pack will not be consumed.
- Charged battery packs continue to discharge naturally. Therefore, charge them on the day of use, or the day before, to ensure a full charge.
- We recommend that you prepare battery packs to last 2 to 3 times longer than you think you might need.

Preparing the Accessories

Wireless Controller

First, insert the supplied CR2025 lithium button battery into the wireless controller.

1 **Press the tab in the direction of the arrow and pull out the battery holder.**

2 **Place the lithium button battery with the + side facing up.**

3 **Insert the battery holder.**



To use the wireless controller

Point the wireless controller at the camcorder's remote sensor when you press the buttons.
You can rotate the LCD panel 180 degrees to use the wireless controller from the front of the camcorder.

Downloaded From VideoCamera-Manual.com Manuals



NOTES

- The wireless controller may not work properly when the remote sensor is situated under strong light sources or direct sunlight.

Grip Belt and Straps



Fasten the grip belt.

Adjust the grip belt so that you can reach the zoom lever with your index finger, and the START/STOP button with your thumb.

You can attach the supplied stylus pen to the grip belt.

To remove the grip belt

1 Lift the padded handgrip's flap and detach the strap from the Velcro pad.

2 Pull the strap to remove it first from the front bracket on the camcorder, then to unthread it from the handgrip and finally to remove it from the rear bracket on the camcorder.

Downloaded From VideoCamera-Manual.com Manuals



To attach an optional wrist strap

Attach the wrist strap to the rear bracket on the camcorder, adjust the length and fasten.
You can also attach the wrist strap to the strap mount on the grip belt to use both for extra convenience and protection.



To attach an optional shoulder strap

Pass the ends of the shoulder strap through the strap mount on the grip belt and adjust the length of the strap.



Downloaded From VideoCamera-Manual.com Manuals

Adjusting the Position and Brightness of the LCD Screen

Rotating the LCD Panel

Open the LCD panel 90 degrees.

- You can rotate the panel 90 degrees downward.
- You can rotate the panel 180 degrees toward the lens. Rotating the LCD panel 180 degrees can be useful in the following cases:
  - To include yourself in the picture when recording with the self timer.
  - To allow the camcorder to be operated with the wireless controller from the front.





Subject can monitor the LCD screen

NOTES

- **About the LCD screen:** The screen is produced using extremely high-precision manufacturing techniques, with more than 99.99% of the pixels operating to specification. Less than 0.01% of the pixels may occasionally misfire or appear as black, red, blue or green dots. This has no effect on the recorded image and does not constitute a malfunction.

LCD Backlight

When recording in bright places it may be difficult to use the LCD screen. Turn on the LCD backlight to make it brighter.

With the camcorder on, hold DISP. pressed down for more than 2 seconds.

Repeat this action to switch the LCD backlight between off (normal) and on (bright).



Downloaded From VideoCamera-Manual.com Manuals

NOTES

- The LCD backlight does not affect the brightness of the recordings.
- Using the bright setting will shorten the effective usage time of the battery pack.
- You can further adjust the brightness of the LCD screen with the [ ] ▸ [LCD Brightness] setting, or dim it with the [ ] ▸ [LCD Screen Dimmer] setting to use in places where the light from the LCD screen can be a nuisance.
- For details about how to take care of the touch screen, refer to *Handling Precautions* (📖 167), *Cleaning* (📖 172).

Downloaded From VideoCamera-Manual.com Manuals

Using the Touch Screen

The control buttons and menu items that appear on the touch screen change dynamically depending on the operating mode and the task you are performing. With the intuitive touch screen interface you have all the controls at your fingertips. You can also use the supplied stylus pen for a more precise operation.

Touch
Press firmly on an element displayed on the touch screen.
Used to start playing back a scene in an index screen, to select a setting from the menus, to select the subject whom the camcorder will recognize as the main subject of the scene, etc.



Drag
While applying pressure, swipe your finger up and down or left and right across the screen.
Used to scroll menus, to browse through index screen pages or to adjust slider controls like the volume.



IMPORTANT

- **The camcorder uses a pressure-sensitive touch screen. Press firmly when using touch operations.**
- In the following cases, you may not be able to perform touch operations correctly.
  - Using your fingernails or hard-tipped objects other than the supplied stylus pen, such as ballpoint pens.
  - Operating the touch screen with wet or gloved hands.
  - Applying excessive force or forcefully scratching the touch screen.
  - Attaching commercially available screen protectors or adhesive film onto the touch screen's surface.

Downloaded From VideoCamera-Manual.com Manuals

Operating Modes

Recording

In recording mode, the camcorder's operating mode is determined by the position of the mode switch.

Operating mode	Mode switch	Operation
AUTO		Let the camcorder take care of all the settings while you concentrate on recording (📖 40). Great for beginners or if you just prefer not to bother with detailed camcorder settings.
M		Enjoy full access to menus, settings and advanced functions (📖 75).
CINEMA		Give your recordings a cinematic look and use cinema-look filters to create unique movies (📖 60).

Playback

Press the camera/play button to switch the camcorder between camera (recording) mode and playback mode. You can press it when the camcorder is off to turn it on directly in playback mode.

Operating mode	Operation
	Playing back movies (📖 48).
	Viewing photos (📖 110).

NOTES

- When switching to a playback mode, the memory selected for playback will be the same currently used for recording.
- You can also press and hold on the wireless controller for more than 2 seconds to switch between recording and playback mode.

Downloaded From VideoCamera-Manual.com Manuals

Using the Menus

Many of the camcorder's functions can be adjusted from the FUNC. panel and the setup menus. For details about the available menu options and settings, refer to the appendix *Menu Options Lists* (📖 135).

FUNC. Panel

Operating modes: AUTO M CINEMA

The FUNC. panel shows a convenient overview of frequently used shooting functions. Touch [FUNC.] to access the FUNC. panel and then touch the function you want to set or adjust.
You may need to drag your finger up and down along the scroll bar to find the control button of the desired function. In AUTO mode, access to functions is limited.

FUNC. panel in M mode



Touch the control button of the desired function

Drag your finger up and down along the scroll bar to display the rest of the panel

Edit Panel

Operating modes: AUTO M CINEMA

Touch [Edit] to display a panel showing available operations (copying, deleting, etc.), and then touch the operation you want to perform.

Edit panel in mode



Touch the control button of the desired operation

Downloaded From VideoCamera-Manual.com Manuals

Operating modes: AUTO* M CINEMA

* In AUTO mode setup menus cannot be accessed and most menu settings will be reset to default values.

1 **M or CINEMA mode only: Touch [FUNC.]**

2 **Touch [MENU] to open the setup menus.**
You can also press MENU on the wireless controller.

3 **Touch the tab of the desired menu.**



4 **Drag your finger up and down to bring the setting you want to change into the orange selection bar.**
- Menu items not available appear grayed out.
- You can touch any menu item on the screen to bring it directly into the selection bar.

5 **When the desired menu item is inside the selection bar, touch the orange frame on the right.**

6 **Touch the desired option and touch [✕].**
You can touch [✕] to close the menu at any time.

Downloaded From VideoCamera-Manual.com Manuals

Setting the Date and Time



You will need to set the date and time of the camcorder before you can start using it. The [Date/Time] screen will appear automatically when the camcorder's clock is not set.
When the [Date/Time] screen appears, the year will be selected.

1. **Touch a field you want to change (year, month, day, hours or minutes).**
2. **Touch [▲] or [▼] to change the field as necessary.**
3. **Set the correct date and time by changing all the fields in the same way.**
4. **Touch [Y.M.D], [M.D,Y] or [D.M.Y] to select the date format you prefer.**
   In some screens, the date will be displayed in short form (numbers instead of month names), but it will still follow the order you selected.
5. **Touch [24H] to use 24-hour clock or leave it unselected to use 12-hour clock (AM/PM).**
6. **Touch [OK] to start the clock and close the setup screen.**

NOTES

- You can adjust the date and time later on with the [Date/Time] setting.
- When you do not use the camcorder for about 3 months, the built-in rechargeable lithium battery may discharge completely and the date and time setting may be lost. In such case, recharge the built-in lithium battery (📖 170) and set the time zone, date and time again.

Downloaded From VideoCamera-Manual.com Manuals

Changing the Language

The default language of the camcorder is English. You can set it to one of 26 other languages.

Operating modes: AUTO M CINEMA

[FUNC.]* ▸ [MENU] ▸ ☛ ▸ [Language] ▸ Desired language ▸ [✕]

* Only when performing the procedure in a recording mode.

NOTES

- Some control buttons, such as [ZOOM], [FUNC.] or [MENU], will appear in English regardless of the language selected.

Changing the Time Zone

Change the time zone to match your location. The default setting is Paris.

Operating modes: AUTO M CINEMA

1 Open the [Time Zone/DST] screen.

[FUNC.]* ▸ [MENU] ▸ ☛ ▸ [Time Zone/DST]

* Only when performing the procedure in a recording mode.

2 Touch [🏠] to set the home time zone, or [✈] to set the time zone of your destination when you are traveling.

3 Touch [▲] or [▼] to set the desired time zone. If necessary, touch [☀] to adjust for daylight saving time.

Downloaded From VideoCamera-Manual.com Manuals

4 Touch [✕] to close the menu.

Downloaded From VideoCamera-Manual.com Manuals

Memory Cards Compatible for Use with the Camcorder

You can use the following types of commercially available Secure Digital (SD) cards with this camcorder.
As of October 2010, the movie recording function has been tested using SD/SDHC/SDXC memory cards made by Panasonic, Toshiba and SanDisk.

Memory card type:	SD memory card, SDHC memory card, SDXC memory card
SD Speed Class*:	CLASS 2, CLASS 4, CLASS 6, CLASS 10
Capacity:	128 MB or larger**.

* When using an SD memory card without a speed class rating, you may not be able to record movies, depending on the memory card used.
** SD memory cards with a capacity of 64 MB or smaller cannot be used to record movies.

NOTES

- **About the Speed Class:** Speed Class is a standard that indicates the minimum guaranteed data transfer speed of memory cards. When you buy a new memory card, look for the Speed Class logo on the package. We recommend using memory cards rated SD Speed Class 4, 6 or 10.

SDXC Memory Cards

You can use SDXC memory cards with this camcorder. When using memory cards with other devices, such as digital recorders, computers and card readers, **make sure that the external device is compatible with SDXC cards**. The table below summarizes compatibility by computer operating system, as of October 2010. For the latest information, however, contact the computer, operating system or memory card manufacturer.

Downloaded From VideoCamera-Manual.com Manuals

Compatible operating systems for SDXC memory cards

Operating system	Compatibility
Windows 7	Compatible
Windows Vista	Compatible (requires Service Pack 1 or later)
Windows XP	Compatible (requires Service Pack 3 and KB955704 update)
Mac OS X	Not compatible

IMPORTANT

- If you use an SDXC memory card with a computer OS that is not SDXC-compatible, you may be prompted to format the memory card. In such case, **cancel the operation to prevent data loss**.
- After repeatedly recording, deleting and editing scenes (fragmented memory), it will take longer to write data on the memory and recording may stop. Save your recordings and initialize the memory.

Eye-Fi Cards

This product is not guaranteed to support Eye-Fi card functions (including wireless transfer). In case of an issue with an Eye-Fi card, please check with the card manufacturer.
Also note that an approval is required to use Eye-Fi cards in many countries or regions. Without approval, use of the card is not permitted. If it is unclear whether the card has been approved for use in the area, please check with the card manufacturer.

Downloaded From VideoCamera-Manual.com Manuals

Inserting and Removing a Memory Card

Make sure to initialize (📖 38) all memory cards before using them with this camcorder.

1 **Turn off the camcorder.**
Make sure the ON/OFF (CHG) indicator is off.

2 **Open the double memory card slot cover.**

3 **Insert the memory card straight, with the label facing up, all the way into one of the memory card slots until it clicks.**



- You can also use two memory cards, one in each memory card slot.
- To use the wireless communication features of an Eye-Fi card, insert it into memory card slot **B**. Be sure you understand the information provided in *Eye-Fi Cards* (📖 34) before using an Eye-Fi card.

4 **Close the double memory card slot cover.**
Do not force the cover closed if the memory card is not correctly inserted.

To remove the memory card

Push the memory card once to release it. When the memory card springs out, pull it all the way out.

IMPORTANT

- Memory cards have front and back sides that are not interchangeable. Inserting a memory card facing the wrong direction can cause a malfunction of the camcorder. Be sure to insert the memory card as described in step 3.

Downloaded From VideoCamera-Manual.com Manuals

Selecting the Memory for the Recordings

You can select to record your movies and photos in the built-in memory (HF M46 only) or on a memory card. The default memory for recording both is the built-in memory (HF M46) or memory card A (HF M406).

Operating modes: AUTO M CINEMA

POINTS TO CHECK

- Be sure you understand the information provided in *Eye-Fi Cards* (📖 34) before using an Eye-Fi card.

HF M46

[FUNC.] ▸ [MENU] ▸ [ ] ▸ [Rec Media for Movies] or [Rec Media for Photos] ▸ [ ] (built-in memory), [A] (memory card A) or [B] (memory card B)* ▸ [✕]

HF M406

[FUNC.] ▸ [MENU] ▸ [ ] ▸ [Rec Media for Movies] or [Rec Media for Photos] ▸ [A] (memory card A) or [B] (memory card B)* ▸ [✕]

* When selecting the memory, you can check the approximate available recording time/number of photos, based on currently used settings.

NOTES

- HF M46 Select to record movies in the built-in memory or memory card A if you later want to convert the movies to standard definition in order to upload them to the Web.

Downloaded From VideoCamera-Manual.com Manuals

Relay Recording

You can activate the relay recording so if the memory you are using becomes full while recording movies, the recording will continue uninterrupted on a memory card.
When recording on memory card **A**, you can use memory card **B** for relay recording (A ➔ B). HFM46 only: When recording in the built-in memory, you can choose to use only memory card **A** for relay recording (▣ ➔ A), or use both memory cards (▣ ➔ A ➔ B).

Operating modes: AUTO | M | CINEMA | | |

1 **Insert a memory card that contains no video recordings into the card slot of the memory card you want to use for relay recording.**
- When relay recording from the built-in memory (HFM46 only): memory card slot **A** or both memory card slots.
- When relay recording from memory card **A**: memory card slot **B** only.

2 **Activate the relay recording.**

[FUNC.] ➔ [MENU] ➔ ⚙ ➔ [Rec Media for Movies] ➔ [▣] (HFM46 only) or [A] ➔ [Relay Recording] ➔ Desired option* ➔ [✕]

* The approximate available recording time will now reflect the combined space in the memories used for relay recording.

NOTES

- HFM46 You cannot use relay recording from the built-in memory to memory card **B**. When using a single memory card, be sure to insert it into memory card slot **A**.
- There will be a momentary stop in the scene at the point where the camcorder switches from one memory to another.
- Any of the following actions will deactivate the relay recording function:
  - Turning off the camcorder.
  - Opening the double memory card slot cover.
  - Changing the position of the mode switch.
  - Changing the camcorder's operating mode.
  - Changing the memory used for recording movies.

Downloaded From VideoCamera-Manual.com Manuals

Initializing the Memory

Initialize memory cards when you use them with this camcorder for the first time. You can also initialize a memory card or the built-in memory (HFM46 only) to permanently delete all the recordings it contains.
HFM46 At the time of purchase, the built-in memory comes pre-initialized and contains music files for use as background music and images for use with the image mix function (image mix frames).

Operating modes: AUTO M CINEMA

1 Power the camcorder using the compact power adapter.

Do not disconnect the power source or turn off the camcorder until the initialization is completed.

2 Initialize the memory.

HFM46

[FUNC.][1] ➤ [MENU] ➤ [⚙] ➤ [Initialize 🖴/SD] ➤ [🖴 Built-in Mem.], [A Mem. Card A] or [B Mem. Card B] ➤ [Initialize] ➤ [Complete Initialization][2] ➤ [Yes][3] ➤ [OK] ➤ [✕]

HFM406

[FUNC.][1] ➤ [MENU] ➤ [⚙] ➤ [Initialize SD] ➤ [A Mem. Card A] or [B Mem. Card B] ➤ [Initialize] ➤ [Complete Initialization][2] ➤ [Yes][3] ➤ [OK] ➤ [✕]

[1] Only when performing the procedure in a recording mode.
[2] Touch this option if you want to physically erase all the data rather than just clear the file allocation table of the memory.
[3] If you selected the [Complete Initialization] option, you can touch [Cancel] to cancel the initialization while it is in progress. All recordings will be erased and the memory can be used without any problem.

Downloaded From VideoCamera-Manual.com Manuals

IMPORTANT

- Initializing the memory will permanently erase all recordings. Lost original recordings cannot be recovered. Make sure you save important recordings in advance using an external device (📖 120).
- Initializing a memory card will permanently erase any music files and images you may have transferred to the card. (HF M46 The music files and image mix frames that come pre-installed in the built-in memory will be restored after it is initialized.) To transfer music files from the supplied Camcorder Supplemental Disc to the memory card:
  - Windows users: Remove the memory card from the camcorder, connect it to a computer and use the supplied PIXELA's software. For details, refer to the Software Guide (PDF file) of the supplied PIXELA's software.
  - Mac OS users: Remove the memory card from the camcorder and connect it to a computer. Use Finder to transfer music files from the [MUSIC] folder on the supplied Camcorder Supplemental Disc to the memory card. Refer to *About the music files* (📖 183) for the folder structure of the memory card.
- At the time of purchase, Eye-Fi cards contain the necessary network configuration software. Be sure to install the software and complete the required configuration setup before you initialize the Eye-Fi card prior to using it with this camcorder.

Downloaded From VideoCamera-Manual.com Manuals

AUTO Mode

This chapter covers how to easily record video and photos in AUTO mode, and how to use basic shooting functions like zoom and Quick Start. To enjoy full access to menus and more advanced functions, refer to *Recording in* ***M*** *(Manual) Mode* (📖 75).

Basic Recording

Shooting Video and Taking Photos in AUTO Mode

By default, movies and photos are recorded in the built-in memory (HF M46 only) or on memory card A (HF M406). You can select the memory that will be used to record movies and photos (📖 36).
Please read the IMPORTANT section (📖 43) before using an Eye-Fi card.

Operating modes: AUTO | M | CINEMA | | |

POINTS TO CHECK

- **Before you begin recording,** make a test recording first to check that the camcorder is operating correctly.

Downloaded From VideoCamera-Manual.com Manuals

1 **Set the mode switch to AUTO.**

2 **Turn on the camcorder.**



To record video

Press START/STOP to begin recording.

- Press START/STOP again to pause the recording.
- The ACCESS indicator will flash from time to time while the scene is being recorded.

To take photos

Touch [PHOTO].

- A green icon (⊙) will appear momentarily on the screen and the ACCESS indicator will flash as the photo is recorded.
- You can record photos simultaneously while recording a movie.
- You can also press PHOTO on the wireless controller.

When you have finished recording

1 Make sure that the ACCESS indicator is off.

2 Turn off the camcorder.

3 Close the LCD panel.

Downloaded From VideoCamera-Manual.com Manuals

Rating Scenes

You can turn on the scene rating option in recording mode with the [ ] [Rate Scenes (Recording)] setting. Immediately after recording a scene, you will have the option to rate it by touching one of the rating buttons; you can also touch [• • •] or [✕] to leave the scene unrated. Later you can play back scenes and perform other scene operations by rating.

About AUTO mode

- Only the following functions are available in AUTO mode.
  - Zoom (📖 45).
  - Quick Start (📖 46).
  - Video snapshot (📖 61).
  - Advanced image stabilization modes (📖 81) to shoot video while walking or to stabilize the shot while zooming in on faraway subjects (telephoto).
  - Face detection (📖 83) to get beautiful shots of people every time, tracking the subject even if the person moves.
  - Touch & Track (📖 85) to track other moving subjects, keeping them in focus and using the best settings to record them.
  - Story Creator (📖 58) to transform your movies into compelling video stories by following simple scripts for various scenarios.
  - Decoration (📖 62) to add a fun personal touch using stamps, drawings, image mix and more.

About the Smart AUTO function

In AUTO mode, the camcorder will automatically detect certain characteristics of the subject, background, lighting conditions, etc. It will then adjust various settings (focus, exposure, color, image stabilization, image quality, among others), selecting the best settings for the scene you want to shoot. The Smart AUTO icon will change to one of the following icons.

Downloaded From VideoCamera-Manual.com Manuals

Smart AUTO icons

Background → (color of the icon) / Subject ↓	Bright[2] (grey)	Blue skies[2] (light blue)	Vivid colors[2] (green/red)	Sunsets (orange)
People (stationary)	( )	( )	( )	—
People (moving)	( )	( )	( )	—
Subjects other than people, such as landscapes	AUTO ( )	AUTO ( )	AUTO ( )	
Close objects	/ [1] (/ [1])	/ [1] (/ [1])	/ [1] (/ [1])	—

Background → (color of the icon) / Subject ↓	Dark (dark blue)		
		Spotlight	Night scene
People (stationary)		—	—
People (moving)		—	—
Subjects other than people, such as landscapes	AUTO		
Close objects	/ [1]	—	—

[1] This icon will appear under tele macro conditions.
[2] The icon in parentheses appears under backlight conditions.

IMPORTANT

- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss or damage to the memory.
  - Do not open the double memory card slot cover.
  - Do not disconnect the power source or turn off the camcorder.
  - Do not change the camcorder's operating mode.

Downloaded From VideoCamera-Manual.com Manuals

- Be sure to save your recordings regularly (📖 120), especially after making important recordings. Canon shall not be liable for any loss or corruption of data.
- Photos recorded on an Eye-Fi card in memory card slot B will be uploaded automatically after setting the camcorder to playback mode, if you are within the range of a configured network. Always verify that Eye-Fi cards have been approved in the country/region of use. See also *Using an Eye-Fi card* (📖 133).

NOTES

- **About the power saving mode:** If [wrench] ▸ [Power Saving Mode] ▸ [Auto Power Off] is set to [ON On], the camcorder will shut off automatically to save power when it is powered by a battery pack and is left without any operation for 5 minutes. Press [POWER] to turn on the camcorder.
- When recording in bright places, it may be difficult to use the LCD screen. In such cases, you can turn on the LCD backlight (📖 24) or adjust the brightness of the LCD screen with the [wrench] ▸ [LCD Brightness] setting.
- Under certain conditions, the Smart AUTO icon that appears on the screen may not match the actual scene. Especially when shooting against orange or blue backgrounds, the Sunset or one of the Blue Skies icons may appear and the colors may not look natural. In such case, we recommend recording in [M] mode (📖 75).
- In [AUTO] mode, most camcorder settings will return to default values, but the following settings will be maintained even after setting the mode switch to AUTO.
  - FUNC. panel: [Decoration], [Zoom].
  - [camera] menu: [AF mode], [Auto Slow Shutter].
  - [film] menu: [Video Snapshot Length], [Rate Scenes (Recording)], [Rec Media for Movies], [Recording Mode], [Rec Media for Photos].
  - [wrench] menu: All settings.
- Photos are recorded as JPG files. The photo size (1920x1080) and quality cannot be changed. At this size, a 1 GB memory card can hold approximately 670 photos. However, the actual number of photos that can be recorded will vary depending on the subject and shooting conditions.

Downloaded From VideoCamera-Manual.com Manuals

Zooming

Operating modes: AUTO M CINEMA

There are three ways you can zoom in and out: using the zoom lever on the camcorder, using the zoom buttons on the wireless controller or using the zoom controls on the touch screen.
In addition to the 10x optical zoom, in M mode, you can turn on the digital zoom (40x or 200x) with the [Digital Zoom] setting.

Using the Zoom Lever or Wireless Controller

Move the zoom lever toward W (wide angle) to zoom out. Move it toward T (telephoto) to zoom in.

- By default, the zoom lever operates at a variable speed – press gently for a slow zoom; press harder for faster zooms.
- You can also use the zoom buttons on the wireless controller.



Downloaded From VideoCamera-Manual.com Manuals

Using the Touch Screen's Zoom Controls

1 Display the zoom controls on the touch screen.

[FUNC.] ▸ [ZOOM]

- The zoom controls appear on the left side of the screen.

2 Touch the zoom controls to operate the zoom.

Touch anywhere within the **W** area to zoom out or anywhere within the **T** area to zoom in. Touch closer to the center for a slow zoom; touch closer to the **W**/**T** icons for faster zooms.

3 Touch [✕] to hide the zoom controls.

NOTES

- Keep at least 1 m away from the subject. At full wide angle, you can focus on a subject as close as 1 cm. Using tele macro (📖 92), you can focus on a subject as close as 40 cm at full telephoto.
- In [M] or [CINEMA] mode, you can also set [📹] ▸ [Zoom Speed] to one of three constant speeds (3 is the fastest, 1 the slowest).
- When [Zoom Speed] is set to [VAR Variable]:
  - When you use the **T** and **W** buttons on the wireless controller, the zoom speed will be constant at [▸▸▸ Speed 3].
  - The zoom speed will be faster in record pause mode than when actually recording, except when pre-recording (📖 82) is activated.
- See *Specifications* (📖 181) for notes about this function when the recording program is set to [Underwater] or [Surface].

Quick Start Function

When you close the LCD panel with the camcorder on, the camcorder enters the standby mode. In standby mode the camcorder consumes only about 1/3 the power used when recording, saving energy when you are using a battery pack. Additionally, when you open the LCD

Downloaded From VideoCamera-Manual.com Manuals

panel, the camcorder is ready to start recording in approximately 1 second*, allowing you to record the subject right away.

* The actual time required varies depending on the shooting conditions.

Operating modes: AUTO M CINEMA

1 **With the camcorder on and in a recording mode, close the LCD panel.**

A beep will sound and the green ON/OFF (CHG) indicator will change to orange to indicate the camcorder entered standby mode.

2 **When you wish to resume recording, open the LCD panel.**

The ON/OFF (CHG) indicator turns back green and the camcorder is ready to record.

IMPORTANT

- Do not disconnect the power source during standby mode (while the ON/OFF (CHG) indicator is lit in orange).

NOTES

- The camcorder will not enter standby mode if the LCD panel is closed while the ACCESS indicator is on or flashing or while a menu is being displayed. The camcorder may also not enter standby mode when the battery charge is too low. Check that the ON/OFF (CHG) indicator changes to orange.
- **About standby mode and auto power off:**
  - The camcorder will power off automatically if left in standby mode for 10 minutes. Press POWER to turn on the camcorder.
  - You can select the length of time until shut-off or turn off the Quick Start function altogether with the [Power Saving Mode] [Quick Start (Standby)] setting.
  - The usual 5-minute auto power off setting of [Power Saving Mode] is not applicable while the camcorder is in standby mode.
- Changing the position of the mode switch while the camcorder is in standby mode will reactivate the camcorder in the operating mode selected.

Downloaded From VideoCamera-Manual.com Manuals

3 Video

This chapter covers functions related to movies, including playback, advanced shooting, using Story Creator and other advanced functions. For details about basic video shooting, refer to *AUTO Mode* (📖 40).

Basic Playback

Playing Back Video

Operating modes: AUTO M CINEMA

1 **Press** .
You can also press and hold on the wireless controller for more than 2 seconds to switch between shooting and playback mode.



2 **Open the date index screen, if it is not displayed.**

[] [Date]

3 **Look for the scene you want to play back.**
Move the zoom lever toward **W** to show 15 scenes per page; move it toward **T** to show 6 scenes per page.

Downloaded From VideoCamera-Manual.com Manuals



1 Memory being read.
2 Recording date.
3 Division line between recording dates.
4 Drag your finger left for the next index page*.
5 Drag your finger right for the previous index page*.
6 Open the index selection screen (52).
7 3D Flip View (52).
8 Scene's timeline (104).

* While browsing through index pages, a scroll bar will appear at the bottom of the screen for a few seconds. When you have a large number of scenes it may be more convenient to drag your finger along the scroll bar.

4 Touch the desired scene to play it back.

- Playback will start from the scene selected and continue until the end of the last scene in the index screen.
- Touch the screen to display the playback controls. During playback, the playback controls will disappear automatically after a few seconds without operation. In playback pause, touch the screen again to hide the playback controls.

Downloaded From VideoCamera-Manual.com Manuals

During playback:



1 Jump to the beginning of the scene. Double-tap to jump to the previous scene.
2 Jump to the beginning of next scene.
3 Pause the playback.
4 Fast playback* backward/forward.
5 Display the volume (📖 50) and background music mix balance (📖 69) controls.
6 Stop the playback.
7 Decoration (📖 62).

* Touch several times to increase the playback speed to approximately 5x → 15x → 60x the normal speed. During fast playback, touch anywhere on the screen to return to normal playback.

Adjusting the volume

1 During playback, touch the screen to display the playback controls.
2 Touch [🎵], drag your finger along the [Speaker Volume]* bar to adjust the volume and touch [↩].

* When [⚙] » [AV/Headphones] is set to [🎧 Headphones], adjust the [Headphone Volume] bar instead.

Downloaded From VideoCamera-Manual.com Manuals

During playback pause:

1 Resume playback.
2 Slow playback* backward/forward.
3 Capture the displayed frame as a photo (📖 107).
4 Decoration (📖 62).

* Touch several times to increase the playback speed 1/8 → 1/4 the normal speed. During slow playback, touch anywhere on the screen to return to playback pause.

IMPORTANT

- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.
  - Do not open the double memory card slot cover.
  - Do not disconnect the power source or turn off the camcorder.
  - Do not change the camcorder's operating mode.
- You may not be able to play back with this camcorder movies recorded on a memory card using another device.

NOTES

- You can turn off the recording date and time display or change the information displayed with the [ ] [Data Code] setting.
- Depending on the recording conditions, you may notice brief stops in video or sound playback between scenes.
- During fast/slow playback, you may notice some anomalies (blocky video artifacts, banding, etc.) in the playback picture.
- The speed indicated on the screen is approximate.
- Slow reverse playback will look the same as continuous frame reverse.

Downloaded From VideoCamera-Manual.com Manuals

Touch [ ] in the date index screen to switch to 3D Flip View. This fun way of displaying scenes grouped by recording date in a 3D layout can be useful to flip through a large number of recordings.



1 Recording date.
2 Drag your finger left to go to the next date with recordings.
3 Drag your finger up and down to browse through the scenes recorded in the displayed date.
4 Drag your finger right to go to the previous date with recordings.
5 Return to the date index screen.
6 Current scene / Total number of scenes recorded on the selected date.
7 Touch the scene in the front to play it back.

The Index Selection Screen: Selecting the Content to Play Back

From the index selection screen you can select the content you want to play back (original scenes by date or by story, or photos, for example). You can also select the memory from which you want to play back your recordings.

Operating modes: AUTO M CINEMA

Downloaded From VideoCamera-Manual.com Manuals

In any index screen, touch [ ].

During single photo view, touch the screen once to display the controls then touch [ ] to open the [Photos] index screen.

1 Touch the tab of the desired memory: built-in memory (HF M46 only), memory card A or memory card B.

2 Touch a control button to select the content you want to play back.

Options

[Date] Scenes organized by recording date.

[Gallery] Scenes organized by story (66).

[Photos] Photos' index screen.

[SD Movies] (HF M46 only when a memory card is selected) Scenes that were converted to standard definition to upload them to the Web (128).

NOTES

- HF M46 Fast/slow playback modes are not available for scenes converted to standard definition. Scenes in the [SD Movies] index screen can only be played back at normal speed.

Downloaded From VideoCamera-Manual.com Manuals

Two playback modes: the date index screen vs. the gallery

In the **date index screen** you can find all the movies you have recorded, conveniently organized by recording date. When you play back scenes from the date index screen they will be played back in chronological order.

In the **gallery**, you can find your scenes grouped as video stories. If you record movies using the Story Creator function (📖 58), your scenes will appear in the story you created; scenes recorded without using this function will appear in the [Unsorted] story (or [Video Snapshot] story, in the case of video snapshot scenes). When you play back a story from the gallery, scenes will be played back in the order of the story's outline, regardless of their recording date.

Deleting Scenes and Stories

You can delete those scenes and stories that you are not interested in keeping. Deleting scenes allows you also to free up space on the memory.

Operating modes: AUTO M CINEMA

Deleting a Single Scene

1 **Play back the scene you wish to delete.**

2 **Touch the screen to display the playback controls.**

3 **Delete the scene.**

[▮▮] ▸ [Edit] ▸ [Delete] ▸ [Yes] ▸ [OK]

Deleting Scenes from the Date Index Screen

1 **Open the date index screen.**

To delete all the scenes recorded on a specific date, drag your finger left/right until the desired date appears in the title bar.

Downloaded From VideoCamera-Manual.com Manuals

2 **Delete the scenes.**

[Edit] ❯ [Delete] ❯ Desired option* ❯ [Yes]** ❯ [OK]

* When you select [Select], perform the following procedure to select the individual scenes you want to delete before touching [Yes].

** Touch [Stop] to interrupt the operation while it is in progress. Some scenes may be deleted nevertheless.

To select individual scenes

1 Touch on the individual scenes you want to delete.

- A checkmark ✓ will appear on the scenes you touch. The total number of selected scenes will appear next to the ☑ icon.
- Touch a selected scene to remove the checkmark. To remove all checkmarks at once, touch [Remove All] ❯ [Yes].

2 After selecting all the desired scenes, touch [OK].

Options

[*date*] Delete all the scenes recorded on the date shown in the control button.

[Select] Select individual scenes to delete.

[All Scenes] Delete all the scenes.

Deleting a Single Scene from a Story

1 Open the list of scenes of the story that contains the scene you want to delete.

[] ❯ [Gallery] ❯ Bring the desired story to the front ❯ [Scene List]

2 In the [Scene List] screen, drag your finger up/down to select the scene you want to delete.

3 Touch the orange box on the right to open the [Edit Scene] screen.

Downloaded From VideoCamera-Manual.com Manuals

4 **Delete the scene.**

[🗑] ➤ [Yes] ➤ [OK] ➤ [⮌]

Deleting Scenes from a Story by Rating

1 **Open the information screen of the story that contains the scenes you want to delete.**

[▶] ➤ [Gallery] ➤ Bring the desired story to the front ➤ [Story Details]

2 **Open the rating selection screen.**

[Edit Story] ➤ [Delete]

3 **Touch one or more of the rating buttons to select all the applicable scenes.**

A grayed out rating button indicates that no scenes in the story have been given that particular rating.

4 **Delete all applicable scenes.**

[Set] ➤ [Yes]* ➤ [OK] ➤ [⮌]

* Touch [Stop] to interrupt the operation while it is in progress. Some scenes may be deleted nevertheless.

Deleting Stories

Deleting a story permanently deletes all the scenes it contains. The two preexisting stories, [Unsorted] and [Video Snapshot], cannot be deleted.

1 **Open the gallery.**

[▶] ➤ [Gallery]

Downloaded From VideoCamera-Manual.com Manuals

2 **Select the story you want to delete.**

Drag your finger right/left to bring the desired story to the front.

3 **Delete the story.**

[Story Details] ❯ [Edit Story] ❯ [Delete Story] ❯ [Yes]* ❯ [OK]

* Touch [Stop] to interrupt the operation while it is in progress. Some scenes may be deleted nevertheless.

IMPORTANT

- Be careful when deleting recordings. Once deleted, scenes cannot be recovered.
- Deleting a story permanently deletes all the scenes it contains.
- When deleting scenes, scenes will be removed from the date index screen and from any stories in the gallery they may have belonged to, regardless of the method used to delete them.
- Save copies of important scenes before deleting them (📖 123).
- Observe the following precautions while the ACCESS indicator is on or flashing (while scenes are being deleted).
  - Do not open the double memory card slot cover.
  - Do not disconnect the power source or turn off the camcorder.
  - Do not change the camcorder's operating mode.

NOTES

- To delete all movies and make all recordable space available again you may prefer to initialize the memory (📖 38).

Downloaded From VideoCamera-Manual.com Manuals

Using Story Creator to Create Compelling Stories

Story Creator is a helpful function that offers suggestions for typical scenes in a number of situations. With Story Creator, creating interesting video stories is as easy as selecting one of the story themes, such as [Travel], [Party] or [Kids & Pets], and following the suggested categories to record video. During playback, select your story from the gallery to play back the scenes you recorded as a single, compelling video story (66).

Operating modes: AUTO M CINEMA

Creating a New Story

1 **Press .**
If the memory already contains other stories, the story selection screen will appear. In that case, touch [New Story].

2 **Select the desired theme.**
- Drag your finger left/right to browse through the themes and touch the thumbnail of the desired theme.
- A list of the suggested categories (story scenes) for the selected theme will appear.

3 **Drag your finger up/down to select a category and touch [OK].**

4 **In the confirmation screen, touch [Yes] to create the story.**
- Initially, the current date will be used as the story's title, but you can change it (73) before pressing [Yes].
- A new story will be created and the camcorder will enter record pause mode. The selected story scene category will appear at the bottom of the screen.

Recording a Scene within a Story

Press START/STOP to record movies within the selected story scene (category).
- Use the displayed recommended length as a reference when recording scenes.

Downloaded From VideoCamera-Manual.com Manuals

- Scenes will be recorded under the story and category currently selected.
- You can also record video snapshot scenes (61).



1 Return to the list of story scenes (categories).
2 Recommended length of scenes in this category.
3 Currently selected story scene (category). You can also touch here to return to the list of story scenes.

To select a different story scene (category)

1 Touch [ ] to return to the list of story scenes.
When it appears on the screen, you can also touch the button of the current story scene.

2 Drag your finger up/down to select another category and touch the orange frame on the right (number of scenes).

To exit Story Creator mode

Press and touch [Yes].

NOTES

- When recording video snapshot scenes, you can have the camcorder automatically link the length of video snapshot scenes to the recommended length of story scenes with the [ ] [Video Snapshot Length] setting.

Recording Additional Scenes within an Existing Story

1 Press .

2 Select the story to which you want to add new scenes.

Downloaded From VideoCamera-Manual.com Manuals

The list of story scenes will appear. The orange frame on the right will show how many scenes you have recorded in each story scene (category).

3 **Drag your finger up/down to select a category and touch the orange frame on the right (number of scenes).**
The camcorder will enter record pause mode and the selected story scene category will appear at the bottom of the screen.

4 **Press START/STOP to record a scene within the selected story scene.**

CINEMA Mode and Cinema-Look Filters

In CINEMA mode, the camcorder will adjust the frame rate and several other picture-related settings to give your recordings a cinematic look. In this mode you can also use a variety of professional cinema-look filters to create unique movies with a distinctive appearance.

Operating modes: AUTO M CINEMA

1 **Set the mode switch to CINEMA.**

2 **Select the desired cinema-look filter.**

[FILTER 1] ▸ Desired cinema-look filter* ▸ [OK]

* When you select a cinema-look filter other than [Cinema Standard], you can change the effect level with the following procedure before touching [OK].

- The selected cinema-look filter will be applied and its number will appear on the control button.

To select the effect level of the cinema-look filter

[▾] ▸ [L] (low), [M] (medium) or [H] (high) ▸ [⮌]

Options (♦ Default value)

The camcorder offers 9 cinema-look filters. Select the desired filter while previewing the effect on the screen.

Downloaded From VideoCamera-Manual.com Manuals

[1: Cinema Standard]♦
[2: Vivid]
[3: Dream]
[4: Cool]
[5: Nostalgic]
[6: Sepia]
[7: Old Movies]
[8: Memory]
[9: Dramatic B&W]



1 Filter number (will appear on the control button)
2 Filter name
3 Preview the effect on the screen
4 Select the effect level
5 Brief description (onscreen guidance)

NOTES

- Photos cannot be recorded while the camcorder is set to CINEMA mode.

Video Snapshot

Record a series of short scenes. Then, play back your video snapshot scenes set to your favorite music (69) to create your own fun music video. You will be surprised how by changing the background music, you can give your scenes an entirely new feel.
The default length of a video snapshot scene is 4 seconds but you can change it to 2 or 8 seconds, or to the length recommended for the selected story scene (category) in Story Creator, with the [Video Snapshot Length] setting.

Operating modes: AUTO M CINEMA

Downloaded From VideoCamera-Manual.com Manuals

1 **Press** VIDEO SNAP.
- A blue border appears on the screen.
- Press VIDEO SNAP again to return to normal video recording mode.



2 **Press** START/STOP.
- The camcorder records for a few seconds (the blue frame serves as a visual progress bar) and then automatically returns to record pause mode.
- When the camcorder stops recording, the screen will momentarily turn black as if a camera shutter had released.

NOTES

- Changing the camcorder's operating mode will deactivate the video snapshot mode.

Decoration: Adding a Personal Touch

Add a new level of enjoyment to your scenes by decorating them. You can add animated graphics, stamps and even your own freehand drawings. The supplied stylus pen will be especially useful for decorating scenes.
You can decorate scenes as they are being recorded, during playback or just before converting them to standard definition (HF M46 only).



Downloaded From VideoCamera-Manual.com Manuals

Operating modes: AUTO M CINEMA

1 Open the decoration screen.

[FUNC.] ▸ [Decoration]

- The decoration screen will open automatically also when you stow the LCD panel with the touch screen facing out.

2 Use a tool from the toolbar as explained in the following procedures.

3 Press START/STOP to record movies with your decorations.
You can add decorations even while recording a scene.

4 Touch [✕] to exit the decoration screen.



1 Canvas - The area where you will draw and see your decorations in action.

2 Toolbar.

3 [Pens and Stamps] Select the type of pen or stamp and its color. You can also save a canvas or load a previously saved canvas.

4 [Animated Stamps] Select animated stamps to add to your decoration.

5 [Captions] Add the date, date and time, story title or story theme as a caption that will be included in the recording.

6 [Image Mix]* (Image Mix) Choose one of 27 different frames to add onto the canvas. Image mix can be used in combination with the pens, stamps and animated stamps.

7 [❚❚]* In recording mode: pause the live video. Touch [❚❚] again to restore the live video. You can add decorations to and record the frozen image.

Downloaded From VideoCamera-Manual.com Manuals

In playback mode: pause the playback. Touch [▶] to resume playing back the scene.

8 [↖] Minimize the toolbar to the top of the screen to view almost all of the canvas. Touch [↘] to restore the toolbar.

* Not available in CINEMA mode.

To use [Pens and Stamps]

1 Touch [🖌].
The [Pens and Stamps] screen will appear.

2 Select the desired pen or stamp from [Tools].

3 Select white or black from [Colors].
Alternatively, you can touch [💉] and select a color from the color palette.

4 Draw freely on the canvas.
Touch [🖌] ❯ [Clear] ❯ [Yes] to clear the canvas and start again.

5 When you finish drawing, save the canvas.

[🖌] ❯ [Save] or [A Save] ❯ [Yes] ❯ [⮌]

- The freehand drawings and stamps will be saved in the built-in memory (HF M46 only) or on memory card A (HF M406 only).

To load a previously saved canvas

In the decoration screen:

[🖌] ❯ [Load] or [A Load] ❯ [Yes] ❯ [⮌]

- The camcorder will apply the last freehand drawings and stamps that were saved in the built-in memory (HF M46 only) or on memory card A (HF M406 only).

To use [Animated Stamps]

1 Touch [✨].
The [Animated Stamps] screen will appear.

2 Touch one of the control buttons.

Downloaded From VideoCamera-Manual.com Manuals

3 Touch anywhere on the canvas to place the selected animated stamp. You can also drag the animated stamp to a different location.

To use [Captions]

1 Touch [ ].
The [Captions] screen will appear.

2 Touch [Date] or [Time].
When recording a scene using Story Creator, you can also select [Title] (the story's title) or [Story Scene] (the story scene category).

3 Select the desired text settings and touch [ ].
- Touch [ ] (white text on dark background), [ ] (white text) or [ ] (black text).
- The selected caption will appear in the center of the screen.

4 Touch the caption and drag it to the desired location.

To use image mix

To use the image mix function when recording on a memory card, you will need to connect the memory card to a computer and transfer the image mix data from the supplied Camcorder Supplemental Disc to the memory card in advance.
See *About the image files for the Image Mix function* (📖 183).

1 Open the [Select Image] screen.



2 Touch [+] or [-] to select a different image mix frame.
You can touch one of the memory icons at the bottom of the screen to read image mix frames saved on a different memory (HF M46: only when recording on or playing back scenes from a memory card).

3 Touch [ ] to mix the selected frame with the live video.

Decorating Scenes during Playback

Operating modes: AUTO M CINEMA

1 Play back the scene you want to decorate.

Downloaded From VideoCamera-Manual.com Manuals

2 **Touch the screen to display the playback controls.**

3 **Touch [ ] to open the decoration screen.**

4 **Decorate the scene using the tools from the toolbar as explained in the previous section.**

In playback mode, the decorations will not be saved with the original recording.

NOTES

- Initializing a memory will erase any [Pens and Stamps] drawing canvas and image files you may have saved. (HF M46 The image mix frames that come pre-installed in the built-in memory will be restored after it is initialized.)
- Animated stamps and captions cannot be used at the same time.
- HF M46 When [ ] [Rec Media for Movies] is set to [ ] (the built-in memory), you will not be able to select image mix fames saved on a memory card.
- Image mix cannot be selected during playback or while converting a scene to standard definition (HF M46 only). Select the image mix during playback pause or before starting the conversion.

Playing Back Stories from the Gallery

You can play back recordings made using Story Creator to play them back as a single compelling video story following the order of the story's script. Regular scenes and video snapshot scenes recorded without using Story Creator, will appear in the gallery under the [Unsorted] or [Video Snapshot] stories. When playing back stories from the gallery, you can choose to play back only scenes with a certain rating.

Operating modes: AUTO M CINEMA

1 **Open the gallery.**

[ ] [Gallery]

- From the date index screen you can also press to open the gallery on the same memory.

Downloaded From VideoCamera-Manual.com Manuals



1 Drag your finger right or left to select a story.
2 Story's theme.
3 Selected story (large thumbnail in the front).
4 Story's title (📖 73).
5 Open the index selection screen (📖 52).
6 Details about the story (number of scenes, total playback time) and editing options.
7 List of scenes recorded in the selected story.

2 Select the story you want to play back.

Drag your finger right/left to bring the desired story to the front.

3 Select the rating of the stories you want to play back.

[Story Details] ⟩ [Play by Rating] ⟩ Desired rating ⟩ [↩] ⟩ [↩]

4 Touch the story's thumbnail to start the playback.

- The complete story will be played back from the first scene to the last. When playback ends, the camcorder will return to the gallery.
- Touch the screen to display the playback controls. Touch [📖] to display the scene's category during playback. Touch [📖] to turn the story scene display off.
- Playback controls are the same as when playing back scenes from the date index screen (📖 50).

IMPORTANT

- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.

Downloaded From VideoCamera-Manual.com Manuals

- Do not open the double memory card slot cover.
- Do not disconnect the power source or turn off the camcorder.
- Do not change the camcorder's operating mode.

Rating Scenes

You can rate story scenes immediately after recording them (📖 42) or during playback. You can then select multiple scenes with the same rating, for example, in order to play back or copy only your favorite scenes.

Operating modes: AUTO M CINEMA

Rating Scenes from the List of Scenes

1 **Open the list of scenes of the story that contains the scenes you want to rate.**

[ ] ➤ [Gallery] ➤ Bring the desired story to the front ➤ [Scene List]

2 **In the [Scene List] screen, drag your finger up/down to select the scene you want to rate.**

3 **Touch the orange box on the right to open the [Edit Scene] screen.**

4 **Touch the control button of the desired rating and touch [ ] twice to return to the gallery.**

Rating Scenes During Playback

1 **Play back from the gallery the story that contains the scenes you want to rate.**

2 **During playback of a scene you want to rate, pause the playback and rate the scene.**

Touch the screen ➤ [ ] ➤ [Edit] ➤ [Rating] ➤ Desired rating ➤ [ ]

Downloaded From VideoCamera-Manual.com Manuals

3 Touch [▶] to resume the playback and rate other scenes in the same way or touch [■] to return to the gallery.

Playback with Background Music

You can play back movies (or a photo slideshow) using one of the supplied music tracks as background music.

Operating modes: AUTO M CINEMA

The supplied Camcorder Supplemental Disc contains 3 music tracks you can use as background music. HFM46: The music files come preinstalled in the built-in memory.
You can mix the original audio and the background music and adjust the background music mix balance to your preference.

POINTS TO CHECK

- To play back scenes or a slideshow of photos recorded on a memory card, you will need to connect the memory card that contains your recordings to a computer and transfer the music tracks in advance. See the NOTES section (📖 71).

1 Open the gallery or date index screen.

[⇄] ➤ [Gallery] or [Date]

2 Select the music track.

[MENU] ➤ [ ] ➤ [Select Music] ➤ [ON On] ➤ [▲] or [▼] to select the desired music track

Downloaded From VideoCamera-Manual.com Manuals



1 Select the desired music track.
2 Adjust the background music balance.
3 Play back the original sound (no background music).
4 Delete the music track selected.
5 Listen to the music track selected. Touch again (■) to stop the playback.

3 Adjust the mix balance between the original sound and the background music.

Touch [🎥] (more of the original sound) or [♫] (more of the background music) or drag your finger along the [Music Balance] bar to adjust the background music balance as desired.

4 Touch [✕] and then touch a story or scene to start the playback with the selected background music.

To adjust the background music balance during playback

1 During playback, touch the screen to display the playback controls.
2 Touch [♫🎥], drag your finger along the [Music Balance] bar to adjust the background music balance as desired and touch [⮌].

To delete a music track

In the [Select Music] screen, touch [▲] or [▼] to select the track you want to delete.

[🗑] ➤ [Yes]

Downloaded From VideoCamera-Manual.com Manuals

IMPORTANT

- If you use copyrighted songs and music tracks in your video creations, remember that music under copyright may not be used without permission from the copyright holder, except for cases permitted under applicable laws, such as for personal use. Make sure to follow applicable laws when using music files.

NOTES

- Initializing a memory card will permanently erase any music files you may have transferred to the card. (HFM46 The music files that come preinstalled in the built-in memory will be restored after it is initialized.) To transfer music files from the supplied Camcorder Supplemental Disc to the memory card:
  - Windows users: Remove the memory card from the camcorder, connect it to a computer and use the supplied PIXELA's software. For details, refer to the Software Guide (PDF file) of the supplied PIXELA's software.
  - Mac OS users: Remove the memory card from the camcorder and connect it to a computer. Use Finder to transfer music files from the [MUSIC] folder on the supplied Camcorder Supplemental Disc to the memory card. Refer to *About the music files* (📖 183) for the folder structure of the memory card.
- Transfer music files to the memory card that contains the recordings you want to play back with background music.

Copying and Moving Scenes Within/Between Stories

You can copy and move scenes in the gallery within the same story scene (category), between story scenes in the same story, and between stories recorded in the same memory.

Operating modes: AUTO M CINEMA

1 Open the list of scenes of the story that contains the scene you want to copy or move.

[] ▸ [Gallery] ▸ Bring the desired story to the front ▸ [Scene List]

Downloaded From VideoCamera-Manual.com Manuals

2 **In the [Scene List] screen, drag your finger up/down to select the scene you want to copy/move.**

3 **Touch the orange box on the right to open the [Edit Scene] screen and touch [Copy] or [Move].**

4 **Select the destination.**

Drag your finger right/left to select the desired story and touch its thumbnail. Then, drag your finger up/down to select the desired category and touch the orange frame on the right (number of scenes). And last, drag your finger up/down to move the orange bar within the category to select the position of the scene.

5 **Copy or move the scene.**

[Set]* ▸ [Yes]** ▸ [OK] ▸ [⮌]

* This step is not necessary when copying/moving a scene into a story scene category that contains no other scenes.

** When copying a scene, you can touch [Stop] to interrupt the operation while it is in progress.

NOTES

- You cannot copy or move scenes to the two preexisting stories, [Unsorted] and [Video Snapshot].

Selecting a Story's Thumbnail Image

Initially, the image used as the story's thumbnail is the first frame of the first scene in the story. You can set your favorite scene as the thumbnail that will represent the story in the gallery.

Operating modes: AUTO M CINEMA

1 **Open the gallery.**

[ ] ▸ [Gallery]

Downloaded From VideoCamera-Manual.com Manuals

2 **Select the story whose thumbnail you want to change.**
Drag your finger right/left to bring the desired story to the front.

3 **Open the [Story Thumbnail] screen.**

[Story Details] ❯ [Edit Story] ❯ [Story Thumbnail]

4 **Locate the frame you want to use as the story's thumbnail.**
Playback controls will appear on the screen (📖 50). Use any special playback modes (fast/slow playback, frame reverse/advance) as necessary to locate the desired image.

5 **Touch [Set] to change the story's thumbnail.**

6 **Touch [↩] to return to the gallery.**

Changing a Story's Title

When you first create a story, the current date will be used as the story's title but you can change the title later on. The title can be up to 14 characters long (available characters are limited). The title of the two preexisting stories, [Unsorted] and [Video Snapshot] cannot be changed.

Operating modes: AUTO M CINEMA

1 **Open the gallery.**

[] ❯ [Gallery]

2 **Select the story whose title you want to change.**
Drag your finger right/left to bring the desired story to the front.

3 **Open the [Edit Title] screen.**

[Story Details] ❯ [Edit Story] ❯ [Edit Title]

4 **Use the virtual keyboard to change the title.**

Downloaded From VideoCamera-Manual.com Manuals

5 Touch [OK] ➤ [⮌] ➤ [⮌] to return to the gallery.



1 Switch between letters and numbers/special characters.
2 Change the position of the cursor.
3 Delete the character to the cursor's left (backspace).
4 Caps Lock. When the numerical keyboard is displayed, [#%?] switches between set 1 and set 2 of special characters.

Downloaded From VideoCamera-Manual.com Manuals

Recording in M (Manual) Mode

When the mode switch is set to **M** (Manual mode), you can enjoy full access to the menus and manually adjust the exposure, focus, white balance and many more of the camcorder's settings to your preference. Even in M mode, though, the camcorder can help you with the settings. For example, by using Special Scene recording programs (📖 78).
By default, movies and photos are recorded in the built-in memory (HF M46 only) or on memory card A (HF M406). You can select the memory that will be used to record movies and photos (📖 36).
Please read the IMPORTANT section before using an Eye-Fi card.

Operating modes: AUTO **M** CINEMA

1 **Set the mode switch to M.**

2 **Turn on the camcorder.**

3 **Record movies and photos.**
The procedure is the same as in AUTO mode (📖 40).



IMPORTANT

- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss or damage to the memory.
  - Do not open the double memory card slot cover.
  - Do not disconnect the power source or turn off the camcorder.
  - Do not change the camcorder's operating mode.

Downloaded From VideoCamera-Manual.com Manuals

- Be sure to save your recordings regularly (📖 120), especially after making important recordings. Canon shall not be liable for any loss or corruption of data.
- Photos recorded on an Eye-Fi card in memory card slot **B** will be uploaded automatically after setting the camcorder to playback mode, if you are within the range of a configured network. Always verify that Eye-Fi cards have been approved in the country/region of use. See also *Using an Eye-Fi card* (📖 133).

NOTES

- The zoom, Quick Start function, power saving modes, etc. operate the same way in **M** mode as in AUTO mode. For details, refer to *AUTO Mode* (📖 40).
- Photos cannot be recorded while the digital zoom is activated or while fading in or fading out a scene.

Reviewing the Latest Scene Recorded

You can review the last 4 seconds of the last scene recorded with the camcorder without switching to playback mode. While reviewing the latest scene, the picture will be played back without sound.

Operating modes: AUTO **M** CINEMA | 🎞 📷

1 **Set the mode switch to M or CINEMA.**

2 **Review the last 4 seconds of the scene.**

[FUNC.] ▶ [Review Recording]

Selecting the Video Quality (Recording Mode)

The camcorder offers 5 recording modes. Changing the recording mode will change the recording time available on the memory. Select MXP or FXP mode for better movie quality; select LP mode for longer recording times. The following table gives approximate recording times.

Operating modes: AUTO **M** CINEMA | 🎞 📷

Downloaded From VideoCamera-Manual.com Manuals

[FUNC.] ▸ [MENU] ▸ [camera] ▸ [Recording Mode] ▸ Desired recording mode ▸ [✕]

NOTES

- Movies recorded in MXP mode cannot be saved on AVCHD discs. Use an external Blu-ray Disc recorder to copy MXP movies onto Blu-ray discs or use the supplied software **VideoBrowser** to create AVCHD discs*.
- The camcorder uses a variable bit rate (VBR) to encode video so the actual recording times will vary depending on the content of the scenes.
- The camcorder retains the last setting used even if you set the camcorder to AUTO mode.

* MXP scenes will be converted to an image quality similar to that of FXP scenes.

Approximate recording times

♦ Default value

Recording mode → / Memory ↓	MXP[1]	FXP[1]	XP+	SP♦	LP
4 GB Memory card	20 min.	30 min.	40 min.	1 hr. 10 min.	1 hr. 30 min.
8 GB Memory card	40 min.	1 hr.	1 hr. 25 min.	2 hr. 20 min.	3 hr.
16 GB Memory card/ HF M46 Built-in memory[2]	1 hr. 25 min.	2 hr. 5 min.	2 hr. 50 min.	4 hr. 45 min.	6 hr. 5 min.
32 GB Memory card	2 hr. 55 min.	4 hr. 10 min.	5 hr. 45 min.	9 hr. 35 min.	12 hr. 15 min.[3]

[1] Recorded in 1,920 x 1,080 resolution. Movies recorded using other recording modes are recorded in 1,440 x 1,080 resolution.

[2] HF M46 At the time of purchase, the built-in memory contains about 70 MB of music files (background music) and 5 MB of image files (image mix frames).

[3] A single scene can be recorded continuously for 12 hours; at that point, the camcorder will stop for about 3 seconds before resuming recording.

Downloaded From VideoCamera-Manual.com Manuals

Selecting the Frame Rate

You can change the frame rate (the number of frames recorded per second) to change the look of your movies.

Operating modes: AUTO M CINEMA

[FUNC.] ▸ [MENU] ▸ [ ] ▸ [Frame Rate] ▸ Desired frame rate ▸ [✕]

Options

[50i 50i (Standard)] 50 fields per second, interlaced. Standard frame rate of PAL analog TV signals.

[PF25 PF25] Shooting at 25 frames per second, progressive*. Using this frame rate will give your recordings a cinematic look. Recording in CINEMA mode will further enhance the effect.

* Recorded as 50i.

Special Scene Recording Programs

Recording in a very bright ski resort or capturing the full colors of a sunset or a fireworks display becomes as easy as selecting a Special Scene recording program.

Operating modes: AUTO M CINEMA

[FUNC.] ▸ [Rec. Programs] ▸ [Portrait] ▸ Desired recording program ▸ [✕]

Options (♦ Default value)

[Portrait]♦ The camcorder uses a large aperture, to achieve a sharp focus on the subject while blurring the background.

Downloaded From VideoCamera-Manual.com Manuals

[Sports] To record sports scenes such as tennis or golf.

[Night Scene] To record nightscapes with lower noise.

[Snow] To record in bright ski resorts without the subject being underexposed.

[Beach] To record on a sunny beach without the subject being underexposed.

[Sunset] To record sunsets in vibrant colors.

[Low Light] To record in low-light situations.

[Spotlight] To record spotlit scenes.

[Fireworks] To record fireworks.

Downloaded From VideoCamera-Manual.com Manuals

[Underwater] To record underwater scenes in natural colors.

[Surface] To record after getting out of the water, such as on a boat after diving.

NOTES

- [Portrait]/[Sports]/[Snow]/[Beach]: The picture may not appear smooth during playback.
- [Portrait]: The blur effect of the background increases the more you zoom in (T).
- [Snow]/[Beach]: The subject may become overexposed on cloudy days or in shaded places. Check the image on the screen.
- [Low Light]:
  - Moving subjects may leave a trailing afterimage.
  - Picture quality may not be as good as in other modes.
  - White points may appear on the screen.
  - Autofocus may not work as well as in other modes. In such case, adjust the focus manually.
- [Fireworks]: To avoid camcorder blur (blur due to the camcorder moving) we recommend using a tripod.
- [Underwater]/[Surface]:
  - Use these recording programs when making recordings while the camcorder is in the optional WP-V3 Waterproof Case.
  - The [Underwater] recording program is for making recordings underwater*. When using underwater lighting equipment or making recordings while on land, we recommend using the [Surface] recording program.
  - To switch the recording program between [Underwater] and [Surface] while the camcorder is in the waterproof case, turn on the camcorder while moving the zoom lever toward T or W. Keep pushing the zoom lever until the or icon appears on the screen.
  - will appear on the screen when the camcorder's temperature becomes too high. If this happens, turn off the camcorder, take it out

Downloaded From VideoCamera-Manual.com Manuals

of the waterproof case and keep it in a cool place until the temperature goes down. If the camcorder becomes too hot, it will turn off automatically.
- When making recordings underwater with the [Underwater] recording program, the image on the LCD screen will appear redder than the actual subject. This will not affect the recording.
- When a commercially available wide-converter or other accessory is attached to the waterproof case, the camcorder may focus on the accessory. In such case, move the zoom lever toward **T** to focus on the subject.
- See *Specifications* (📖 181) for additional notes about the [Underwater] and [Surface] recording programs.

* Underwater is a unique environment that is ever-changing, depending on factors such as the weather and water conditions. In addition, water absorbs red light, which causes objects to appear bluer and greener.

Advanced Image Stabilization

The image stabilizer reduces camcorder blur (blur due to the camcorder moving) so you can get nice, stable shots. Select the image stabilization mode according to the shooting conditions.

Operating modes: AUTO M CINEMA

[FUNC.] ▸ [Image Stabilizer] ▸ Desired IS mode ▸ [✕]

Options (♦ Default value)

[Dynamic]♦ (Compensates for a higher degree of camcorder shake, such as when shooting while walking, and is more effective as the zoom approaches full wide angle.

[Standard] Compensates for a lower degree of camcorder shake, such as when shooting while remaining stationary, and is suitable for shooting natural-looking scenes. Use this setting when recording movies with the optional Wide-converter or Tele-converter.

[Off] Use this setting when the camcorder is mounted on a tripod.

Downloaded From VideoCamera-Manual.com Manuals

Powered IS

You can use Powered IS to make the image stabilization even more powerful. Powered IS is most effective when you are stationary and zooming in on far subjects using high zoom ratios (the more you approach the telephoto end). Holding the LCD panel with your left hand will add to the stability of the shot.

Press and hold [POWERED IS] as long as you want to activate Powered IS.



- appears in yellow, while Powered IS is activated. The degree of camcorder shake will be indicated by the icon itself (-), but you can turn off this indication with the [ ] [Camcorder Shake Indicator] setting.
- You can change the operation of the [POWERED IS] button (long press or toggle on/off) with the [ ] [POWERED IS Button] setting.

NOTES

- If the degree of camcorder shake is too high, the image stabilizer may not be able to fully compensate.
- For surveying and following shots, when you pan the camcorder from side to side or tilt it up and down, we recommend setting the IS mode to [Dynamic] or [Standard].

Pre-Recording

The camcorder will start recording 3 seconds before you press [START/STOP], ensuring you do not miss important shooting opportunities. This is especially useful when it is difficult to predict when to start recording.

Operating modes: AUTO M CINEMA

Downloaded From VideoCamera-Manual.com Manuals

1 Activate the pre-recording function.

[FUNC.] ▸ [Pre REC] ▸ [ON On] ▸ [✕]

- will appear on the screen.
- Repeat, selecting [OFF Off], to turn off pre-recording.

2 Press START/STOP.

The scene recorded in the memory will start 3 seconds before START/STOP was pressed.

NOTES

- The camcorder will not record the full 3 seconds prior to pressing START/STOP if the button was pressed within 3 seconds of having turned on pre-recording or having finished the previous recording.
- Any of the following actions will deactivate the pre-recording function.
  - Leaving the camcorder without any operation for 5 minutes.
  - Changing the position of the mode switch.
  - Pressing or VIDEO SNAP.
  - Opening the decoration screen.
  - Closing the LCD panel to set the camcorder to standby mode.
  - Touching any of the following control buttons in the FUNC. panel: [MENU], [Rec. Programs], [White Balance], [AGC Limit], [Image Stabilizer], [Faders] or [Review Recording].

Face Detection

The camcorder automatically detects people's faces and uses this information to select the optimal settings for beautiful videos and photos.

Operating modes: AUTO* M CINEMA

* Face detection is always activated in AUTO mode.

POINTS TO CHECK

- Select a recording program other than [Night Scene], [Low Light], [Fireworks] or [Underwater].

Downloaded From VideoCamera-Manual.com Manuals

By default, face detection is activated. If the function was turned off, perform the following procedure to turn it on.

[FUNC.] ▸ [MENU] ▸ [🎥] ▸ [Face Detection & Tracking] ▸ [ON On] ▸ [✕]

To select the main subject

If there is more than one person in the picture, the camcorder will automatically select one person it determines is the main subject. The main subject is indicated by a white face detection frame and the camcorder will optimize the settings for that person. Other faces will have gray frames.

Touch a different face on the touch screen to optimize the camcorder's settings for that person using the Touch & Track function.

NOTES

- The camcorder may mistakenly detect the faces of non-human subjects. In such case, turn face detection off.
- In certain cases, faces may not be detected correctly. Typical examples include:
  - Faces extremely small, large, dark or bright in relation to the overall picture.
  - Faces turned to the side, at a diagonal or partially hidden.
- Face detection cannot be used when the shutter speed used is slower than 1/25 or when the digital zoom is activated at more than 40x zoom (dark blue area on the zoom bar).
- When face detection is activated, the slowest shutter speed used by the camcorder is 1/25.

Downloaded From VideoCamera-Manual.com Manuals

Touch & Track

When recording a group of people using face detection, the camcorder will automatically detect one person as the main subject. You can use Touch & Track to tell the camcorder to track and optimize settings for a different person. You can also use Touch & Track to always keep in focus other moving subjects, such as pets or moving vehicles.

Operating modes: AUTO M CINEMA

1 **Make sure face detection is activated (📖 83).**
Face detection is always activated in AUTO mode.

2 **Point the camcorder at a moving subject and touch the subject on the touch screen.**
- A white double frame will appear around the subject and track it as it moves.
- Touch [Cancel] to remove the frame and cancel the tracking.

NOTES

- Touching somewhere with a color or pattern unique to the subject will make it easier to track. However, if there is another subject in the vicinity that shares similar characteristics to the selected subject, the camcorder may start tracking the incorrect subject. Touch the screen again to select the desired subject.
- In certain cases, Touch & Track may not be able to track the subject. Typical examples include:
  - Subjects extremely small or large in relation to the overall picture.
  - Subjects too similar to the background.
  - Subjects lacking sufficient contrast.
  - Fast moving subjects.
  - When shooting indoors with insufficient lighting.

Downloaded From VideoCamera-Manual.com Manuals

Faders

The camcorder offers two professional looking transition effects to fade-in or fade-out scenes. You have the option to activate the fader only one time or every time you start or stop recording.

Operating modes: AUTO M CINEMA

[FUNC.] ▸ [Faders] ▸ Desired fader* ▸ [✕]

* You can preview the transition effect on the screen.

- The icon of the selected fader appears in green.

To fade in/out

Press START/STOP in record pause mode (●❚❚) to start recording with a fade in. Press START/STOP while recording (●) to fade out and pause the recording.

NOTES

- When you apply a fader, not only the picture but also the sound will fade in or out.
- Faders cannot be used in the following cases:
  - While using the [Old Movies] cinema-look filter in CINEMA mode.
  - When recording scenes with decorations.
  - When recording video snapshot scenes.
  - While pre-recording is activated.
- You can select whether to fade to/from a black screen or a white screen with the [ ] ▸ [Fader Setting] setting.

Downloaded From VideoCamera-Manual.com Manuals

Manually Setting the Shutter Speed or Aperture

[P Programmed AE] is the default automatic exposure (AE) recording program; using it, you can change functions like the white balance or image effects. Select one of the other AE recording programs to control the shutter speed or aperture.

Operating modes: AUTO M CINEMA

[FUNC.] ▸ [Rec. Programs] ▸ [Tv Shutter-Pri. AE] or [Av Aperture-Pri. AE] ▸ [◀] or [▶]* to set the desired shutter speed (Tv) or aperture value (Av) ▸ [✕]

* You can also drag your finger along the dial.

Options (♦ Default value)

[P Programmed AE]♦ The camcorder automatically adjusts the aperture and shutter speed to obtain the optimal exposure for the subject.

[Tv Shutter-Pri. AE] Set the shutter speed value. The camcorder automatically sets the appropriate aperture value.

[Av Aperture-Pri. AE] Set the aperture value. The camcorder automatically sets the appropriate shutter speed.

NOTES

- [Tv Shutter-Pri. AE]:
  - On screen only the denominator is displayed – [Tv 250] indicates a shutter speed of 1/250 second, etc.
  - When recording in dark surroundings, you can obtain a brighter picture by using slow shutter speeds; however, image quality may not be as good and autofocus may not work well.
  - The image may flicker when recording with fast shutter speeds.
- [Av Aperture-Pri. AE]: The actual range of values available for selection will vary depending on the initial zoom position.
- When setting a numeric value (aperture or shutter speed), the number displayed will flash if the aperture value or shutter speed is not appropriate for the recording conditions. In such case, select a different value.

Downloaded From VideoCamera-Manual.com Manuals

- During exposure lock, the aperture value/shutter speed cannot be changed. Set the aperture value or shutter speed before manually adjusting the exposure.

Shutter Speed and Aperture Value Guidelines

With slower shutter speed you can add a nice motion blur and sense of movement.

With faster shutter speeds you can "freeze the action" for powerful images of moving subjects.

1/6 1/12 1/25 1/30 1/50 1/120 1/250 1/500 1/1000 1/2000

Low-light situations

Most ordinary conditions

Indoor sports

Fast moving subjects or shooting from a moving car or train

Outdoor sports on sunny days

With small aperture values only the subject is in focus and the background is softly blurred. Great for portraits or to isolate a single object.

With large aperture values every part of the image is clearly in focus. Good for landscapes and architectural shots.

F2.0 F2.8 F4.0 F5.6 F8.0

○ F1.8 F2.4 F3.4 F4.8 F6.7 ⊙

More light ◀ Lens aperture ▶ Less light

Shallow ◀ Depth of Field ▶ Deep

Downloaded From VideoCamera-Manual.com Manuals

Manual Exposure Adjustment

At times, backlit subjects may appear too dark (underexposed) or subjects under very strong lights may appear too bright or glaring (overexposed). To correct this, you can adjust the exposure manually or use the Touch AE function to automatically set the optimal exposure for the subject you select. This is convenient when the brightness of the subject you want to shoot is noticeably brighter/darker than the general brightness of the image.

Operating modes: AUTO M CINEMA

POINTS TO CHECK

- Select a recording program other than [Fireworks].

1 Open the exposure adjustment screen.

[FUNC.] [Exposure]

2 Touch a subject that appears inside the frame.

- The Touch AE mark ( ) will flash and the exposure will be adjusted automatically so the area you touched will be correctly exposed. You have the option to further adjust the exposure manually as necessary.
- You can touch [M] instead to adjust the exposure manually without activating the Touch AE function.
- The manual adjustment dial appears and the adjustment value is set at ±0.
- Touch [M] again to return the camcorder to automatic exposure.

3 Touch [◀] or [▶] or drag your finger along the dial to set the exposure adjustment value.

The adjustment range may vary depending on the initial brightness of the image, and some values may be grayed out.

4 Touch [✕] to lock the exposure at the selected value.

During exposure lock, and the selected exposure adjustment value will appear on the screen.

Downloaded From VideoCamera-Manual.com Manuals

NOTES

- If the recording program is changed during exposure lock, the camcorder will return to automatic exposure.
- When shooting subjects with a strong light source behind them, the camcorder automatically corrects for the backlight*. You can turn off the automatic backlight correction with the [ ] [Auto Backlight Correction] setting.

  * Except in CINEMA mode when using a cinema-look filter other than [Cinema Standard].

Automatic Gain Control (AGC) Limit

When recording in dark surroundings, the camcorder will automatically increase the gain to try to get a brighter picture. However, using higher gain values may result in more noticeable video noise. You can select the AGC limit to curb the amount of noise by setting the maximum gain value to be used. The smaller the AGC limit, the picture will be darker but will have less the noise.

Operating modes: AUTO M CINEMA

[FUNC.] [AGC AGC Limit] [M Manual]* [◀] or [▶]** to set the AGC limit [✕]

* Touch [A Automatic] to remove the limit for the automatic gain control.
** You can also drag your finger along the dial.

- The selected AGC limit will appear on the screen.

Manual Focus Adjustment

Autofocus may not work well on the following subjects. In such case, focus manually.

- Reflective surfaces
- Subjects with low contrast or without vertical lines
- Fast moving subjects
- Through wet windows
- Night scenes

Downloaded From VideoCamera-Manual.com Manuals

Operating modes: AUTO M CINEMA

POINTS TO CHECK

- Adjust the zoom before you start the procedure.

1 Open the manual focus screen.

[FUNC.] ▸ [Focus]

2 Touch a subject that appears inside the frame.

- The Touch AF mark will flash and the focusing distance will be adjusted automatically. You have the option to further adjust the focus manually as necessary.
- You can touch [MF] instead to adjust the focus manually without activating the Touch AF function.
- The manual focus controls and an estimate of the current focusing distance appear.
- Touch [MF] again to return the camcorder to autofocus.

3 Touch and hold [▲] or [▼] to adjust the focus.

- The center of the screen will be magnified to help you focus more easily. You can also turn off this function with the ▸ [Focus Assistance] setting.
- The focusing distance displayed will change as you adjust the focus. You can change the units used for the distance display with the ▸ [Distance Units] setting.
- If you wish to focus on faraway subjects such as mountains or fireworks, touch and hold [▲] until the focusing distance changes to ∞.

4 Touch [✕] to lock the focus at the selected distance.

During manual focus, [MF] will appear on the screen.

Downloaded From VideoCamera-Manual.com Manuals

Tele Macro

Using tele macro, the camcorder can focus at a shorter distance (up to 40 cm from the subject at full telephoto), allowing you get closer shots of small subjects like flowers and insects. This function also adds a soft focus to the background, so the subject not only looks larger but it also stands out more.

Operating modes: AUTO* M CINEMA

* In AUTO mode, tele macro will be activated automatically when you zoom in to full telephoto and bring the camcorder up close to the subject.

POINTS TO CHECK

- Select a recording program other than [Fireworks].

[FUNC.] ▸ [ZOOM] ▸ [*]* (tele macro) ▸ [✕]

* Touch again to turn off the tele macro function.

- The camcorder will automatically adjust the zoom to the telephoto end.

NOTES

- Any of the following actions will deactivate the tele macro function.
  - Turning off the camcorder.
  - Pressing .
  - Setting the camcorder to AUTO mode.
  - Zooming out toward **W** (wide angle).
  - Changing the recording program to [Fireworks].
- Tele macro cannot be turned on/off while recording.

Downloaded From VideoCamera-Manual.com Manuals

White Balance

The white balance function helps you to accurately reproduce colors under different lighting conditions so that white objects will always look truly white in your recordings.

Operating modes: AUTO M CINEMA

POINTS TO CHECK

- Select a recording program other than the Special Scene recording programs.

[FUNC.] ▸ [WB White Balance] ▸ Desired option* ▸ [✕]

* When you select [Custom WB], set the custom white balance with the following procedure before touching [✕].

To set the custom white balance

Point the camcorder at a white object, so it fills the whole screen, and touch [Set WB].

When the adjustment is completed, stops flashing and disappears. The camcorder will retain the custom white balance even if you turn it off.

Options (♦ Default value)

- **[AWB Automatic]♦** The camcorder automatically sets the white balance for natural looking colors.
- **[☀ Daylight]** To record outdoors on a bright day.
- **[Shade]** To record in shaded places.
- **[☁ Cloudy]** To record on a cloudy day.
- **[Fluorescent]** To record under warm white, cool white or warm-white-type (3-wavelength) fluorescent lighting.
- **[Fluorescent H]** To record under daylight or daylight-type (3-wavelength) fluorescent lighting.
- **[Tungsten]** To record under tungsten and tungsten-type (3-wavelength) fluorescent lighting.
- **[Custom WB]** Use the custom white balance setting to make white subjects appear white under colored lighting.

Downloaded From VideoCamera-Manual.com Manuals

NOTES

- **When you select the custom white balance:**
  - Set [ ] ▸ [Digital Zoom] to [OFF Off].
  - Reset the white balance when you change locations or the lighting or other conditions change.
  - Depending on the light source, may keep flashing. The result will still be better than with [AWB Automatic].
- Custom white balance may provide better results in the following cases:
  - Changing lighting conditions
  - Close-ups
  - Subjects in a single color (sky, sea or forest)
  - Under mercury lamps and certain types of fluorescent lights
- Depending on the type of fluorescent light, optimal color balance may not be obtained with [Fluorescent] or [Fluorescent H]. If the color looks unnatural, select [AWB Automatic] or [Custom WB].

Image Effects

You can adjust the color depth, brightness, contrast, and sharpness of the image.

Operating modes: AUTO M CINEMA

POINTS TO CHECK

- Select a recording program other than the Special Scene recording programs.

1 Open the image effects screen.

[FUNC.] ▸ [Image Effects]

2 Touch [ON] and then touch [Color Depth], [Sharpness], [Contrast] or [Brightness].
Repeat, selecting [OFF], to turn off the image effects.

3 Touch [◀] or [▶] or drag your finger along the dial to adjust the effect level.

Downloaded From VideoCamera-Manual.com Manuals

+ levels: richer colors, sharper image, stronger contrast, brighter image.
- levels: shallower colors, softer image, softer contrast, darker image.

4 Touch [✕] to save and apply the customized picture settings.
B_C will appear on the screen.

Self Timer

Operating modes: AUTO M CINEMA

[FUNC.] ▸ [MENU] ▸ [ ] ▸ [Self Timer] ▸ [ON On ⏲] ▸ [✕]

- ⏲ will appear on the screen.
- Repeat, selecting [OFF Off], to turn off the self timer.

Movies: In record pause mode, press START/STOP.
The camcorder starts recording after a 10-second countdown*. The countdown appears on the screen.

Photos: In record pause mode, touch [PHOTO].
The camcorder will record the photo after a 10-second countdown*. The countdown appears on the screen.

* 2 seconds when using the wireless controller.

NOTES

- Once the countdown has begun, any of the following actions will cancel the self timer.
  - Pressing START/STOP, when recording movies.
  - Pressing PHOTO (on the wireless controller) or touching [PHOTO] (on the screen), when recording photos.
  - Turning off the camcorder.
  - Changing the camcorder's operating mode.
  - Closing the LCD panel to set the camcorder to standby mode.

Downloaded From VideoCamera-Manual.com Manuals

Audio Recording Level

You can adjust the audio recording level of the built-in or an external microphone. You can display the audio level indicator while recording.

Operating modes: AUTO **M** CINEMA

POINTS TO CHECK

- Select a recording program other than [Underwater] or [Surface].

Manual Adjustment of the Audio Recording Level

1 Open the manual audio recording level adjustment screen.

[FUNC.] ▸ [Mic. Level] ▸ [**M** Manual]

- The audio level indicator and current audio recording level will appear on the screen.
- Touch [**A** Automatic] to return the camcorder to automatic audio recording levels.



2 Touch and hold [◀] or [▶] to adjust the audio recording level as necessary.

As a guideline, adjust the audio recording level so that the audio level meter will go to the right of the -12 dB mark (yellow area) only occasionally.

3 Touch [✕] to lock the audio recording level at the current level.

Downloaded From VideoCamera-Manual.com Manuals

To display the audio level indicator

Usually, the audio level indicator will be displayed only after activating the manual adjustment of the audio recording level. You can choose to display it also when the audio level is adjusted automatically.

[FUNC.] ▸ [Mic. Level] ▸ [A Automatic] ▸ [Audio Level Indicator] ▸ [✕]

NOTES

- When the audio level meter reaches the red point (0 dB), the sound may be distorted.
- If the audio level is too high and the sound gets distorted, activate the microphone attenuator with the [ ] ▸ [Microphone Attenuator] setting (or [Surround Mic Attenuator] when the optional SM-V1 Surround Microphone is attached to the camcorder).
- We recommend using headphones to check the sound level while adjusting the audio recording level or when the microphone attenuator is activated.

Built-In Microphone Directionality

You can change the directionality of the built-in microphone to have more control over how sound is recorded.

Operating modes: AUTO M CINEMA

[FUNC.] ▸ [MENU] ▸ [ ] ▸ [Built-in Mic Directionality] ▸ Desired option ▸ [✕]

Options (♦ Default value)

[2ch MONO Monaural] Mono recording that emphasizes sound coming from the front of the camcorder/microphone.

[NORM Normal]♦ Standard stereo recording; a middle point between the [Wide] and [Monaural] settings in reach.

Downloaded From VideoCamera-Manual.com Manuals

[2ch WIDE Wide] Stereo recording of ambient sound over a more extensive area that adds to the sense of presence of movies.

[2ch ZOOM Zoom] Stereo recording with the sound linked to the zoom position. The larger the subject appears on the screen, the louder the sound will be.

NOTES

- An external microphone overrides the built-in microphone. The built-in microphone's directionality cannot be changed when an external microphone is attached to the mini advanced shoe.

Audio Equalizer

You can use the audio equalizer to adjust sound levels by specifically targeting the high- or low-frequency range and selecting one of 3 available levels. The audio equalizer settings are only available when recording sound using the built-in microphone.

Operating modes: AUTO M CINEMA

[FUNC.] ▸ [MENU] ▸ [🎥] ▸ [Built-in Mic Freq. Response] ▸ Desired option ▸ [✕]

Options (♦ Default value)

[NORM Normal]♦ Appropriate for balanced sound under most normal recording conditions.

[LB Boost LF Range] Accentuates the low-frequency range for more powerful sound.

[LC Low Cut Filter] Filters the low-frequency range to reduce the noise of blowing wind, a car's engine and similar ambient sounds.

[MB Boost MF Range] Best for recording human voices and dialog.

[LHB Boost HF+LF Range] Best, for example, for recording live music and clearly capture the special sound characteristics of a variety of instruments.

Downloaded From VideoCamera-Manual.com Manuals

Using Headphones

Use headphones for playback or to check the audio level while recording. The headphones are connected to the AV OUT/🎧 terminal, which is used for both the headphones and the audio/video output. Before connecting the headphones, follow the procedure below to change the function of the terminal from AV output to 🎧 (headphones) output.

Operating modes: AUTO* | M | CINEMA | 🎥 | 📷

* Headphones can be used also in AUTO mode but the function of the terminal cannot be changed in this mode. Change the setting in advance in one of the other operating modes.

1 Change the function of the terminal to headphones output.

[FUNC.]* ▸ [MENU] ▸ [↩] ▸ [AV/Headphones] ▸ [Headphones] ▸ [⮌]

* Only when performing the procedure in a recording mode.

2 Connect the headphones to the AV OUT/🎧 terminal.

3 Adjust the volume as necessary.

[Volume] ▸ [🎧›] or [🎧»]** to adjust the volume ▸ [✕]

** You can also drag your finger along the [Headphones] bar.

- 🎧 will appear on the screen.



To adjust the volume during playback

In 🎥 mode, and in 📷 mode during slideshow playback, adjust the headphones volume the same way you adjust the speaker's volume (📖 50).

Downloaded From VideoCamera-Manual.com Manuals

IMPORTANT

- When using headphones, make sure to lower the volume to an appropriate level.
- Do not connect the headphones to the AV OUT/🎧 terminal if the 🎧 icon does not appear on the screen. The noise output in such case may be harmful to your hearing.

NOTES

- Use commercially available headphones with a ∅ 3.5 mm minijack and a cable no longer than 3 m.
- Even if [AV/Headphones] was set to [🎧 Headphones] in a playback mode, the function of the AV OUT/🎧 terminal will return automatically to AV output when you turn off the camcorder.

Using the Mini Advanced Shoe

Using the mini advanced shoe, you can attach to the camcorder a range of optional accessories to expand its functionality. For details about optional accessories available for use with your camcorder, refer to *Accessories* (📖 174). For details about how to attach and use the accessories, refer also to the instruction manual of the accessory used.

1 **Open the mini advanced shoe cover.**

2 **Attach the optional accessory to the mini advanced shoe.**

When a compatible accessory is attached to the mini advanced shoe, "S" will appear on the screen.



Example: Attaching an optional DM-100 Directional Stereo Microphone.

Downloaded From VideoCamera-Manual.com Manuals

NOTES

- Accessories designed for the Advanced Accessory Shoe cannot be used with this camcorder. Look for video accessories bearing this logo to ensure compatibility with the **mini advanced shoe**.

Mini ADVANCED SHOE

Using an External Microphone

When recording in very quiet surroundings, the built-in microphone may pick up the sound of the camcorder's internal machinery. In such case, we recommend using an external microphone.

Operating modes: AUTO M CINEMA

Using the SM-V1 Surround Microphone or DM-100 Directional Stereo Microphone

Using the SM-V1 you can add a sense of depth and presence to your recordings with 5.1ch surround sound. Using the DM-100 you can accurately record audio coming directly from the direction you are recording.

Attach the optional SM-V1 Surround Microphone or DM-100 Directional Stereo Microphone to the mini advanced shoe.

Refer to *Using the Mini Advanced Shoe* (📖 100).
will appear on the screen.
For details about using the optional external microphone, refer to the instruction manual of the accessory used.



Downloaded From VideoCamera-Manual.com Manuals

NOTES

- When an external microphone is connected to the camcorder, [ ] [Wind Screen] will automatically be set to [OFF Off].
- If the audio level is too high and the sound gets distorted, adjust the audio recording level manually (96) or activate the microphone attenuator with the [ ] [Microphone Attenuator] setting.
- **When using the optional SM-V1 Surround Microphone:**
  - Change the microphone's directionality mode with the [ ] [Surround Mic Directionality] setting.
  - If the sound gets distorted, activate the microphone attenuator with the [ ] [Surround Mic Attenuator] setting.
  - You can enjoy the full effect of recordings made with 5.1ch surround sound on HDTVs compatible with 5.1ch surround sound connected to the camcorder using the supplied HDMI cable. Audio output from the AV OUT/ terminal (including headphone output) will be converted to 2ch stereo. The camcorder's built-in speaker is monaural.

Using an External Video Light

You can use the optional VL-5 Video Light or VFL-2 Video Flash Light when you need to record movies in dark locations.

Attach the optional video light to the mini advanced shoe.

- Refer to *Using the Mini Advanced Shoe* (100).
- will appear on the screen when you turn on the optional video light (ON or AUTO). For details about using the optional video light, refer to the instruction manual of the accessory used.
- The optional VFL-2 Video Flash Light cannot be used as a flash with this camcorder.

Using a Zoom Remote Controller

By attaching the optional RA-V1 Remote Control Adapter to the mini advanced shoe, you can use the optional ZR-2000 or ZR-1000 Zoom Remote Controller. Doing so will allow you to use certain functions while viewing the picture on an external monitor without touching the

Downloaded From VideoCamera-Manual.com Manuals

camcorder. This is particularly useful while the camcorder is mounted on a tripod and you want to ensure maximum stability of a shot.

Operating modes: AUTO M CINEMA

Attach the optional RA-V1 Remote Control Adapter to the mini advanced shoe.

Refer to *Using the Mini Advanced Shoe* (100).

will appear on the screen. For details about using the adapter, refer to the instruction manual of the RA-V1. For details about using the zoom remote controller, refer to the instruction manual of the ZR-2000 or ZR-1000.



Functions Available with the Zoom Remote Controller

Using the ZR-2000 or ZR-1000: turning the power on/off, starting/stopping a recording, zoom, focus adjustment and displaying on-screen displays on an external monitor.
Using the ZR-2000 only: switching between autofocus and manual focus, Push AF* and focus assistance (MAGNIFYING button).

* The Push AF function allows you to switch to autofocus temporarily during manual focus.

NOTES

- In AUTO mode, the only available functions are turning the power on/off, starting/stopping a recording, and zoom.

Downloaded From VideoCamera-Manual.com Manuals

Selecting the Playback Starting Point

If you have a very long scene, you may want to start playing back the scene from a certain point. You can use the movie timeline to break the scene to segments at fixed time intervals ranging from 6 seconds to 6 minutes.

Operating modes: AUTO M CINEMA

1 Open the date index screen.

2 Open the scene's [Timeline] screen.

[i] ❯ Desired scene

The [Timeline] screen appears. The large thumbnail will show the first frame of the scene. Below it, the timeline ruler shows frames taken from the scene at fixed intervals.

3 Touch the desired frame in the timeline ruler to start playing back the scene from that point.

1 Touch twice to return to the index screen.
2 Previous/next scene.
3 Drag your finger left along the ruler to display the next 5 frames.
4 Scene's recording mode and length.
5 Recording date and time.
6 Drag your finger right along the ruler to display the previous 5 frames.
7 Current scene / Total number of scenes.
8 Currently selected interval between frames.

Downloaded From VideoCamera-Manual.com Manuals

To change the interval between frames

[6 sec] ❯ Desired interval ❯ [↩]

Onscreen Displays and Data Code

You can turn most onscreen displays on or off.

Operating modes: AUTO | M | CINEMA | 🎥 | 📷

Repeatedly press DISP. to turn the onscreen displays on/off in the following sequence:

M, CINEMA mode:
- All displays on
- Most displays off[1]

🎥, 📷 mode[2]:
- Only data code on
- All displays on



[1] Pressing DISP. will turn off most of the icons and displays that appear automatically but will not remove control buttons ([FUNC.], [PHOTO], etc.) and onscreen displays that were turned on manually (for example, onscreen markers or the audio level meter).

[2] Touch the screen to display the playback controls.

About the Data Code

With every scene or photo recorded, the camcorder keeps a data code (date/time of recording, information about the camera setup, etc.). You can select the information to be displayed with the 🎥 / 📷 ❯ [Data Code] setting.

Downloaded From VideoCamera-Manual.com Manuals

Capturing Photos and Video Snapshot Scenes from a Movie

You can capture video snapshot scenes, single photos or a series of continuous photos from a previously recorded scene. For example, you may want to print photos from video recorded at a party or create a small video clip using video snapshot scenes from the highlights of an event.

Operating modes: AUTO M CINEMA

Capturing a Video Snapshot Scene

1 **Play back the scene or story from which you want to capture the video snapshot scene.**

2 **Press START/STOP to capture the video snapshot scene.**
The camcorder captures the video snapshot scene for about 4 seconds (the blue frame serves as a visual progress bar), and then enters playback pause mode. You can change the length of the video snapshot scenes you capture to 2 or 8 seconds with the [Video Snapshot Length] setting.

3 **Touch [■] to stop the playback.**

NOTES

- A video snapshot scene can be captured only during playback; it cannot be captured during playback pause mode.
- The captured video snapshot scene is saved to the same memory that contains the source scene.
- Video snapshot scenes cannot be captured from any of the following types of scenes.
  - Scenes shorter than 1 second
  - Scenes that were edited using the supplied software **VideoBrowser** and were then transferred to a memory card connected to the computer.
- When the source scene is itself a video snapshot scene, you may not be able to capture a video snapshot scene depending on the length of the source scene and the length currently selected for video snapshot scenes.

Downloaded From VideoCamera-Manual.com Manuals

- When you start capturing a video snapshot scene less than 1 second from the end of the scene, the video snapshot scene will be captured starting from the beginning of the following scene.
- During the playback of video snapshot scenes captured from a previously recorded movie, you may notice some anomalies in the picture/sound at the point where the playback switches to a new scene.

Capturing Photos

You can capture a single photo or a series of photos. The size of the captured photos will be 1920x1080 and it cannot be changed.
Please read the IMPORTANT section before using an Eye-Fi card.

To select the photo capture settings

[MENU] ▸ [📷] ▸ [Photo Capture from Video] ▸ [☐ Single Photo] or [🖳 Photo Sequence] ▸ [✕]

To capture the photos

1 Play back the scene or story from which you want to capture the photo.

2 Pause the playback at the point you want to capture.

3 Touch [PHOTO].
To capture a photo sequence, keep touching [PHOTO]. The scene will be played back frame-by-frame and each frame captured as a separate photo.

4 Touch [■] to stop the playback.

IMPORTANT

- When capturing photos on an Eye-Fi card in memory card slot **B**, photos will be uploaded automatically if you are within the range of a configured network. Always verify that Eye-Fi cards have been approved in the country/region of use. See also *Using an Eye-Fi card* (🕮 133).

NOTES

- The data code of the photos will reflect the date and time of recording of the original scene.

Downloaded From VideoCamera-Manual.com Manuals

- Photos captured from a scene with a lot of fast movement may be blurred.
- Photos will be recorded on the memory selected for recording photos.
- [Photo Sequence]:
  - Up to 100 photos can be captured at a time.
  - The photo sequence capture will stop when the end of the scene is reached (playback will pause at the beginning of the following scene).
  - Photos will be captured at intervals of 1/25 second.

Dividing Scenes

You can divide scenes in order to leave out the best parts and later cut out the rest.

Operating modes: AUTO M CINEMA

1 Play back the scene you want to divide.

2 Pause the playback at the point where you want to divide the scene.

3 Open the scene division screen.

[Edit] ❯ [Divide]

4 Bring the scene to a precise point, if necessary.

Playback controls will appear on the screen (📖 50). Use any special playback modes (fast playback, frame reverse/advance) as necessary to locate the desired point.

5 Divide the scene.

[Divide] ❯ [Yes]

- The video from the division point to the end of the scene will appear as a new scene in the index screen.

Downloaded From VideoCamera-Manual.com Manuals

NOTES

- When advancing/reversing frames while dividing the scenes, the interval between frames is about 0.5 seconds.
- If the scene cannot be divided at the point where you paused the playback, advance/reverse a frame and then divide the scene.
- During the playback of a scene that was divided, you may notice some anomalies in the picture/sound at the point where the scene was cut.
- The following scenes cannot be divided:
  - Video snapshot scenes and other scenes that are too short (less than 3 seconds).
  - Scenes that were edited using the supplied software **VideoBrowser** and were then transferred to a memory card connected to the computer.
- Scenes cannot be divided within 1 second from the beginning or the end of the scene.

Downloaded From VideoCamera-Manual.com Manuals

4 Photos

Refer to this chapter for details on viewing photos and other photo-related operations.

Viewing Photos

Operating modes: AUTO M CINEMA

1 Press .



2 Open the [Photos] index screen, if it is not displayed.

[ ] [Photos]

3 Look for the photo you want to play back.

Move the zoom lever toward **W** to show 15 photos per page; move it toward **T** to show 6 photos per page.

Downloaded From VideoCamera-Manual.com Manuals



1 Memory being read.
2 Drag your finger left for the next index page.*
3 Drag your finger right for the previous index page*.
4 Open the index selection screen (52).
5 Division line between recording dates.

* While browsing through index pages, a scroll bar will appear at the bottom of the screen for a few seconds. When you have a large number of photos it may be more convenient to drag your finger along the scroll bar.

4 Touch the photo you wish to view.

- The photo is displayed in single photo view.
- Drag your finger left/right to browse through the photos one by one.

To return to the index screen from single photo view

1 Touch the screen to display the playback controls.

2 Touch [▪▪].

Photo Jump Function

When you have recorded a large number of photos, you can jump easily through the photos using the scroll bar.

1 Touch the screen to display the playback controls.

2 Jump through the photos using the scroll bar.

[⌂] ➤ Drag your finger left and right along the scroll bar ➤ [↩]

Downloaded From VideoCamera-Manual.com Manuals

IMPORTANT

- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.
  - Do not open the double memory card slot cover.
  - Do not disconnect the power source or turn off the camcorder.
  - Do not change the camcorder's operating mode.
- Even if you transfer them to a memory card connected to a computer, the following image files may not be displayed correctly using the camcorder.
  - Images not recorded with this camcorder.
  - Images edited on a computer.
  - Images whose file names have been changed.

Deleting Photos

You can delete those photos that you are not interested in keeping.

Operating modes: AUTO M CINEMA

Deleting a Single Photo

1 In single photo view, select the photo you want to delete.

2 Touch the screen to display the playback controls.

3 Delete the photo.

[Edit] ▸ [Delete] ▸ [🗑 Proceed] ▸ [Yes]

4 Drag your finger left/right to select another photo to delete or touch [✕].

Deleting Photos from the Index Screen

1 Open the [Photos] index screen.

[⤴▶⤵] ▸ [Photos]

Downloaded From VideoCamera-Manual.com Manuals

2 **Delete the photos.**

[Edit] ❯ [Delete] ❯ Desired option* ❯ [Yes]** ❯ [OK]

* When you select [Select], perform the following procedure to select the individual photos you want to delete before touching [Yes].
** Touch [Stop] to interrupt the operation while it is in progress. Some photos will be deleted nevertheless.

To select individual photos

1 Touch on the individual photos you want to delete.
- A checkmark ✓ will appear on the photos you touch. The total number of selected photos will appear next to the ☑ icon.
- Touch a selected photo to remove the checkmark. To remove all checkmarks at once, touch [Remove All] ❯ [Yes].

2 After selecting all the desired photos, touch [OK].

Options

[Select] Select individual photos to delete.
[All Photos] Delete all the photos.

IMPORTANT

- Be careful when deleting photos. Deleted photos cannot be recovered.
- Photos that were protected with other devices and then transferred to the memory card when it was connected to a computer cannot be deleted with this camcorder.

Slideshow

You can play a slideshow of all the photos and even set it to music.

Operating modes: AUTO M CINEMA

1 **Open the [Photos] index screen.**

[⇄] ❯ [Photos]

Downloaded From VideoCamera-Manual.com Manuals

2 **Select the music track to use during the photo slideshow.**
Step 2 (69).

3 **Touch the photo that will open the slideshow to display it in single photo view.**

4 **Touch the screen to display the playback controls, then touch [▶] to play back the slideshow set to the selected music track.**

During the photo slideshow

- Touch the screen and drag your finger left and right along the volume bar to adjust the volume.
- Touch the screen and touch [❚❚] to stop the slideshow. Hide the playback controls if necessary.

To change the slideshow's transition effects

[MENU] ➤ [📷] ➤ [Slideshow Transition] ➤ [Off], [Dissolve] or [Slide Image] ➤ [✕]

Downloaded From VideoCamera-Manual.com Manuals

5 External Connections

This chapter explains how to connect your camcorder to an external device such as a TV, VCR, or computer.

Terminals on the Camcorder

Open the LCD panel to access the terminals on the camcorder.



① **USB Terminal**

② **AV OUT/🎧 Terminal**
Sound from the built-in speaker will be muted while the STV-250N Stereo Video Cable is connected to the camcorder. Adjust the volume on the connected TV.

③ **HDMI OUT Terminal***
The HDMI OUT terminal offers a high-quality digital connection that combines audio and video in a single convenient cable.

④ **COMPONENT OUT Terminal***
The component video terminal is for video only. When you use connection 2, do not forget the audio connections using the AV OUT/🎧 terminal.

* When connecting a cable to the camcorder, make sure to align the triangle marks on the cable's connector and on the camcorder's terminal.

Downloaded From VideoCamera-Manual.com Manuals

Connection Diagrams

In the following connection diagrams, the left side shows the terminals on the camcorder and the right side shows (for reference only) an example of terminals on a connected device.

Connection 1 — HDMI

Type: Digital • Quality: High definition • Output only

Connect to a high-definition TV (HDTV) with an HDMI input terminal. If your HDTV supports HDMI-CEC or 1080p input, you can activate these functions with the [ ] [Control for HDMI] and [HDMI 1080p Output] settings, respectively. You can check the standard of the current output signal with the [ ] [HDMI Status] setting.



About the HDMI™ connection

The HDMI (High-Definition Multimedia Interface) connection (1) is a convenient all-digital connection using a single cable for both video and audio. When you connect the camcorder to an HDTV equipped with an HDMI terminal, you can enjoy video and audio playback at the highest quality.

- The HDMI OUT terminal on the camcorder is for output only. Do not connect it to an HDMI output terminal on an external device, as this may damage the camcorder.
- While the camcorder is connected to an HDTV using connection 1, there will be no video output from other terminals.
- Correct operation cannot be guaranteed when connecting the camcorder to DVI monitors.
- Depending on the HDTV, correct playback of personal video content may not be possible using connection 1. Try one of the other connections.

Downloaded From VideoCamera-Manual.com Manuals

Connection 2 — Component Video

Type: Analog • Quality: High Definition • Output only

Connect to a high-definition TV (HDTV) with component video input terminals. Change the following settings on the camcorder:

- [ ] [AV/Headphones] to [AV AV]



Connection 3 — Composite Video

Type: Analog • Quality: Standard definition • Output only

Connect to a standard TV or a VCR with audio/video input terminals. Change the following settings on the camcorder:

- [ ] [TV Type] according to the TV set (widescreen or 4:3), if the TV cannot automatically detect and change the aspect ratio
- [ ] [AV/Headphones] to [AV AV]

Downloaded From VideoCamera-Manual.com Manuals

Connection 3

Composite Video (SCART)

In all respects, exactly the same connection as connection 3.
Connect to a standard TV or VCR with SCART input terminal. Requires a SCART adapter (commercially available).



Connection 4

USB

Type: Digital data connection
Connect to a computer to save your recordings, or to a compatible digital video recorder to copy your recordings.



Downloaded From VideoCamera-Manual.com Manuals

Playback on a TV Screen

Connect the camcorder to a TV to enjoy your recordings with family and friends. Playback on an HDTV using one of the high-definition connections will ensure the best playback quality.

Operating modes: AUTO M CINEMA

1 **Turn off the camcorder and the TV.**

2 **Connect the camcorder to the TV.**
Refer to *Connection Diagrams* (📖 116) and select the most appropriate connection for your TV.

3 **Turn on the connected TV.**
On the TV, select as the video input the same terminal to which you connected the camcorder. Refer to the instruction manual of the connected TV.

4 **Turn on the camcorder and set it to or mode.**
Play back the movies or photos.

NOTES

- To correctly play back movies recorded with x.v.Color (📖 144) on an HDTV compatible with this standard, additional settings may be required on the connected HDTV. Refer to the TV's instruction manual.
- We recommend powering the camcorder using the compact power adapter.
- Connection 3 or 3: When you play back your 16:9 movies on standard TV sets with a 4:3 aspect ratio, the TV set will switch automatically to widescreen mode if it is compatible with the WSS system. Otherwise, change the aspect ratio of the TV manually.

Downloaded From VideoCamera-Manual.com Manuals

Copying Recordings to a Memory Card

You can copy your recordings only one way: from the built-in memory (HF M46 only) or from memory card A to memory card B. Scenes and photos will be copied from the index screen or from a story in the gallery on the source memory to the same index screen or story on memory card B.
Please read the IMPORTANT section (123) before using an Eye-Fi card.

Copying Scenes from the Date Index Screen

Operating modes: AUTO M CINEMA

1 Open the date index screen.

- Check that you have selected the built-in memory tab (HF M46 only) or A tab (memory card A).
- To copy all the scenes recorded on a specific date, drag your finger left/right until the desired date appears in the title bar.

2 Copy the scenes.

[Edit] ▶ [Copy (built-in memory → B)] (HF M46 only) or [Copy (A → B)] ▶ Desired option* ▶ [Yes]** ▶ [OK]

* When you select [Select], perform the following procedure to select the individual scenes you want to copy before touching [Yes].
** Touch [Stop] to interrupt the operation while it is in progress.

To select individual scenes

1 Touch on the individual scenes you want to copy.

- A checkmark ✓ will appear on the scenes you touch. The total number of selected scenes will appear next to the ☑ icon.
- Touch a selected scene to remove the checkmark. To remove all checkmarks at once, touch [Remove All] ▶ [Yes].

2 After selecting all the desired scenes, touch [OK].

Downloaded From VideoCamera-Manual.com Manuals

Options

[*date*] Copy all the scenes recorded on the date shown in the control button.

[Select] Select individual scenes to copy.

[All Scenes] Copy all the scenes.

Copying Scenes from a Story by Rating

1 Open the gallery and bring the desired story to the front.

[ ] ▸ [Gallery] ▸ Desired story

- Check that you have selected the tab (built-in memory, HF M46 only) or [A] tab (memory card A).

2 Select the rating of the stories you want to copy.

[Story Details] ▸ [Play by Rating] ▸ Desired rating ▸ [ ] ▸ [ ]

3 Copy all the applicable scenes.

[Story Details] ▸ [Edit Story] ▸ [Copy (➧ [B])] (HF M46 only) or [Copy ([A] ➧ [B])] ▸ [Yes]* ▸ [OK] ▸ [ ]

* Touch [Stop] to interrupt the operation while it is in progress.

Copying a Single Photo

Operating modes: AUTO M CINEMA

1 In single photo view, select the photo you want to copy.
Check that you are viewing photos recorded in the built-in memory (HF M46 only) or on memory card A. (or [A] appears next to the photo number.)

2 Touch the screen to display the playback controls.

Downloaded From VideoCamera-Manual.com Manuals

3 **Copy the photo.**

[Edit] ▸ [Copy (▭ ➔ B)] (HFM46 only) or [Copy (A ➔ B)] ▸ [Proceed] ▸ [Yes]

4 **Drag your finger left/right to select another photo to copy or touch [✕].**

Copying Photos from the Index Screen

Operating modes: AUTO | M | CINEMA | ▶ | 📷

1 **Open the [Photos] index screen.**
Check that you have selected the ▭ tab (built-in memory, HFM46 only) or A tab (memory card **A**).

2 **Copy the photos.**

[Edit] ▸ [Copy (▭ ➔ B)] (HFM46 only) or [Copy (A ➔ B)] ▸ Desired option* ▸ [Yes]** ▸ [OK]

* When you select [Select], perform the following procedure to select the individual photos you want to copy before touching [Yes].
** Touch [Stop] to interrupt the operation while it is in progress.

To select individual photos

1 Touch on the individual photos you want to copy.
- A checkmark ✓ will appear on the photos you touch. The total number of selected photos will appear next to the ☑ icon.
- Touch a selected photo to remove the checkmark. To remove all checkmarks at once, touch [Remove All] ▸ [Yes].

2 After selecting all the desired photos, touch [OK].

Options

[Select] Select individual photos to copy.

[All Photos] Copy all the photos.

Downloaded From VideoCamera-Manual.com Manuals

IMPORTANT

- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.
  - Do not open the double memory card slot cover.
  - Do not disconnect the power source or turn off the camcorder.
  - Do not change the camcorder's operating mode.
- When copying photos onto an Eye-Fi card in memory card slot B, photos will be uploaded automatically if you are within the range of a configured network. Always verify that Eye-Fi cards have been approved in the country/region of use. See also *Using an Eye-Fi card* (133).

NOTES

- In the following cases, you will not be able to copy recordings to the memory card:
  - If the double memory card slot is open.
  - If the LOCK switch on memory card B is set to prevent writing.
  - If there is no memory card in memory card slot B.
- Scenes that were edited using the supplied software **VideoBrowser** and were then transferred to a memory card connected to the computer cannot be copied to another memory card.
- If there is not enough space on memory card B, as many photos as possible will be copied before stopping the operation.

Saving Recordings on a Computer

Movies recorded with this camcorder are saved in the built-in memory (HF M46 only) or on a memory card. Because space is limited, make sure to save your recordings on a computer on a regular basis.

Saving Movies (Windows only)

With the supplied software **Transfer Utility** or **VideoBrowser** you can save to your computer the scenes you have recorded. Additionally, the supplied software **VideoBrowser** offers many options for organizing your video library, editing video, creating discs and more.

Downloaded From VideoCamera-Manual.com Manuals

Installation

Install the software before you connect the camcorder to the computer for the first time. Refer to the Installation Guide (supplied leaflet) and follow the instructions in the Software Guide (PDF file) to install the supplied PIXELA's software.

Connecting the Camcorder to a Computer

1 **Power the camcorder using the compact power adapter.**

2 **Open the date index screen.**

3 **Connect the camcorder to the computer using the supplied USB cable.**
Connection 4. Refer to *Connection Diagrams* (📖 118).

4 **Camcorder: Select [All (for PC only)].**
Camcorder: When the connection is successfully established, [USB Connection] appears on the screen.

5 **Computer: Depending on the software you chose to install, Transfer Utility or VideoBrowser will start up automatically.**
- **Transfer Utility:** Click [Video file import] to start transferring files. For details about using the software, click [Help] to open the Software Guide (PDF file).
- **VideoBrowser:** Click in the menu panel to start transferring files. For details about using the software, click to open the Software Guide (PDF file).

Saving Photos (Windows/Mac OS)

With the supplied software **Photo Application** you can save photos to your computer and easily organize and edit them.

Installation

Install the software before you connect the camcorder to the computer for the first time. See also the relevant sections in the 'Photo Application' Instruction Manual (PHOTO, PDF file in the [MANUALS_ENGLISH] folder on the supplied Camcorder Supplemental Disc).

Downloaded From VideoCamera-Manual.com Manuals

Install the supplied Photo Application software following the instructions in the software's instruction manual.

PHOTO Refer to *Installing Photo Application.*

First-time connection to a computer running Windows

Windows users only: The first time you connect the camcorder to the computer, you also need to select the CameraWindow auto-launch setting.

PHOTO Refer to *Starting CameraWindow*.

Connecting the Camcorder to a Computer

1 **Power the camcorder using the compact power adapter.**

2 **Open the [Photos] index screen.**

Select in advance the memory that contains the photos you want to save.

3 **Connect the camcorder to the computer using the supplied USB cable.**

- Connection 4. Refer to *Connection Diagrams* (📖 118).
- Camcorder: When the connection is successfully established, [USB Connection] appears on the screen.

4 **Save the photos onto the computer.**

PHOTO Refer to *Downloading Still Images to the Computer.*

IMPORTANT

- **When the camcorder is connected to a computer:**
  - Do not open the double memory card slot cover and do not remove the memory cards.
  - Do not access, change or delete any of the camcorder's folders or files directly from the computer as this may result in permanent data loss. Always use only the supplied PIXELA's software to save your movies on the computer and, if necessary, to transfer previously save video files to a memory card connected to the computer.
- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.
  - Do not open the double memory card slot cover.
  - Do not disconnect the USB cable.

Downloaded From VideoCamera-Manual.com Manuals

- Do not turn off the camcorder or the computer.
- Do not change the camcorder's operating mode.

- Operation may not work correctly depending on the software and the specifications/settings of your computer.
- If you wish to use the image files on your computer, make copies of them first. Use the copied files, retaining the originals.

NOTES

- Refer also to the computer's instruction manual.
- With the supplied PIXELA's software you can also choose to save complete stories from the gallery. In such case, all the scenes in the story will be merged and saved as a single video file.
- **Users of Windows 7, Windows Vista, Windows XP and Mac OS X:** Your camcorder is equipped with the standard Picture Transfer Protocol (PTP) allowing you to transfer photos (JPEG only) simply by connecting the camcorder to a computer using the supplied USB cable, without having to install the supplied software **Photo Application**.
- If you connect the camcorder to the computer while it is set to mode, the process of creating scene thumbnails will start automatically. If your intention was to save photos to the computer, you can touch [Skip] to stop the process and use the computer's Safely Remove Hardware function (Windows) or Eject function (Mac OS) to end the connection to the camcorder. Disconnect the USB cable, set the camcorder to mode and restore the connection.

Downloaded From VideoCamera-Manual.com Manuals

Copying Recordings to an External Video Recorder

Operating modes: AUTO M CINEMA

In High Definition

Connect the camcorder to Blu-ray Disc recorders and other AVCHD-compatible digital video recorders using the supplied USB cable to make perfect copies of your movies in high definition. If the external digital video recorder has an SD memory card slot*, you can use the memory card to copy your movies without connecting the camcorder.

* Make sure the external device is compatible with the type of memory card used.

Connecting

1. **Power the camcorder using the compact power adapter.**
2. **Open the date index screen or gallery.**
3. **Connect the camcorder to the digital video recorder using the supplied USB cable.**
   Connection 4. Refer to *Connection Diagrams* (📖 118).
4. **Camcorder: Select the memory that contains the scenes you want to copy.**
   - Select an option other than [All (for PC only)].
   - Camcorder: When the connection is successfully established, [USB Connection] appears on the screen.

Recording

Details will vary depending on the device used so be sure to refer to the instruction manual of the digital video recorder.

In Standard Definition

You can copy your movies by connecting the camcorder to a VCR or a digital video recorder with analog audio/video inputs. Video output will be in standard definition, although the original scenes are in high definition.

Downloaded From VideoCamera-Manual.com Manuals

Connecting

Connect the camcorder to the VCR using Connection 3 or 3. Refer to *Connection Diagrams* (📖 117).

Recording

1 **External recorder: Load a blank cassette or disc and set the recorder to record pause mode.**

2 **Turn on the camcorder and set it to [▶] mode.**
- We recommend powering the camcorder using the compact power adapter.
- Verify that [⚙] ▸ [AV/Headphones] is set to [AV AV].

3 **Camcorder: Locate the scene or story you wish to copy and pause the playback shortly just before the desired scene.**

4 **Camcorder: Resume playback.**
By default, onscreen displays will be embedded in the output video signal. You can change the displays by repeatedly pressing [DISP.] (📖 105).

5 **External recorder: Start recording when the scene you wish to copy appears; stop recording when it ends.**

6 **Camcorder: Stop playback.**

HFM46 Uploading Movies to Video Sharing Web Sites

You can convert your high-definition scenes into standard-definition movies in the camcorder and then use the supplied PIXELA's software in order to upload them to your favorite video sharing Web site. You can even decorate scenes so your unique decorations will be embedded in the converted SD movies.
If you are using an Eye-Fi card, you can upload the standard-definition scenes wirelessly, directly from the camcorder. Refer to Eye-Fi's homepage for the latest information on compatible Web sites.

Installation

Install the software before you connect the camcorder to the computer for the first time. Refer to the Installation Guide (supplied leaflet) and

Downloaded From VideoCamera-Manual.com Manuals

follow the instructions in the Software Guide (PDF file) to install the supplied PIXELA's software.

Converting Scenes into Standard Definition from the Date Index Screen

Operating modes: AUTO M CINEMA

1 **Power the camcorder using the compact power adapter.**

2 **Make sure there is a memory card in memory card slot B with sufficient available space.**

3 **Open the date index screen.**
- Check that you have selected the tab (built-in memory) or A tab (memory card A).
- To convert all the scenes recorded on a specific date, drag your finger left/right until the desired date appears in the title bar.

4 **Press WEB to convert all the scenes recorded in the selected date. Alternatively, touch [Edit] [Convert HD SD (B)] or [Convert HD SD (A B)] and select one of the options for converting multiple scenes.**
- You can convert all the scenes recorded on the date shown in the control button, select individual scenes to convert or convert all the scenes.
- When you select [Select], perform the procedure described below to select the individual scenes you want to convert.



5 **Review the conversion settings and touch [Next].**
- If a copyright notice appears, read it carefully and touch [OK] if you agree.
- Before touching [Next], you can touch [ ] to change the conversion settings as described below.

6 **Touch [START] to convert the scenes.**

Downloaded From VideoCamera-Manual.com Manuals

- Before touching [START], you can touch [] to decorate the converted SD movies (📖 62), or touch [] to adjust the volume (📖 50) and background music balance (📖 70).
- You can also decorate the scenes as they are being converted.
- Touch [STOP] to interrupt the operation while it is in progress.

7 **When the conversion is completed, a confirmation screen will appear.**

Connect the camcorder to the computer at this point (📖 131) to continue uploading the converted videos to the Web or touch [End Without Connecting] to connect to the computer later.

To select individual scenes (step 4)

1 Touch on the individual scenes you want to convert.
- A checkmark ✓ will appear on the scenes you touch. The total number of selected scenes will appear next to the ☑ icon.
- Touch a selected scene to remove the checkmark. To remove all checkmarks at once, touch [Remove All] ▶ [Yes].

2 After selecting all the desired scenes, touch [OK].

To select the bit rate (step 5)

Using a higher bit rate will result in better video quality for the converted scenes, while a lower bit rate will result in smaller file sizes and faster uploads.

[] ▶ [Bit Rate (Quality)] ▶ Desired option ▶ [⮌] ▶ [⮌]

To automatically divide scenes (step 5)

If you are converting a long scene, you can have the camcorder divide it into 10-minute SD movies to make uploading easier.

[] ▶ [Auto Divide] ▶ [On] ▶ [⮌] ▶ [⮌]

Downloaded From VideoCamera-Manual.com Manuals

1 **Connect the camcorder to the computer using the supplied USB cable.**

Connection 4. Refer to *Connection Diagrams* (📖 118).

2 **Computer: Depending on the software you chose to install, Transfer Utility or VideoBrowser will start up automatically.**

- **Transfer Utility:** Click [Web Upload] to upload your SD movies to the Web. For details about using the software, click [Help] to open the Software Guide (PDF file).
- **VideoBrowser:** Click in the menu panel to upload your SD movies to the Web. For details about using the software, click to open the Software Guide (PDF file).

IMPORTANT

- While the camcorder is connected to the computer, do not open the double memory card slot cover and do not remove the memory cards.
- Observe the following precautions while the ACCESS indicator is on or flashing. Failing to do so may result in permanent data loss.
  - Do not open the double memory card slot cover.
  - Do not disconnect the USB cable.
  - Do not disconnect the compact power adapter or turn off the camcorder or the computer.

NOTES

- The time required to convert scenes is approximately equal to the total playback time of the converted scenes. In most cases this is still faster than converting the scenes in the computer so we recommend you convert scenes in the camcorder.
- If after converting the scenes you selected the [End Without Connecting] option, you will need to upload the SD movies manually when you connect the camcorder to the computer. First, open the [SD Movies] index screen on the memory card that contains the converted SD movies and save them to the computer (📖 123). Then, use the supplied PIXELA's software to upload the SD movies to the Web.
- You can check and play back the converted SD movies from the [SD Movies] index screen on the memory card used for the conversion.

Downloaded From VideoCamera-Manual.com Manuals

Converting Scenes into Standard Definition from a Story by Rating

1 Open the gallery and bring the desired story to the front.

[ ] ▸ [Gallery] ▸ Desired story

- Check that you have selected the tab (built-in memory) or [A] tab (memory card **A**).

2 Select the rating of the stories you want to convert.

[Story Details] ▸ [Play by Rating] ▸ Desired rating ▸ [ ]

3 Press [WEB] and continue the conversion to standard definition from step 5 in the previous procedure (📖 129).

NOTES

- **When converting scenes from a story:**
  - All the scenes are merged into one converted SD movie.
  - If the converted SD movie is too large, it will be split into smaller 10-minute long movies.
  - The maximum total playback time of the scenes to be converted is 2 hours and 30 minutes.

Converting Only Part of a Scene or Story

1 Play back the scene or story that you want to partially convert.
Check that you have selected a scene recorded in the built-in memory or on memory card **A**.

2 Pause the playback where you want the converted SD movie to begin.

3 Press [WEB] and continue the conversion to standard definition from step 5 in the previous procedure (📖 129).
The video from the playback pause until the end of the scene/story (or up to a maximum of 10 minutes, in case of longer scenes/stories) will be converted to standard definition.

Downloaded From VideoCamera-Manual.com Manuals

If you are using an Eye-Fi card, you can automatically upload the converted SD movies to your favorite video sharing Web site. You will need to have installed the software supplied with your Eye-Fi card and completed all the required configuration setup in advance. Refer to the instruction manual of the Eye-Fi card.
Please read the IMPORTANT section before using an Eye-Fi card.

1 Insert your Eye-Fi card into memory card slot B and make sure there is sufficient available space on the memory card.

2 Convert the desired movies (📖 129).

- When the conversion is completed, touch [End Without Connecting].
- If you are within the range of a configured network, Web upload will start automatically.
- The status of the wireless communication is shown by the Eye-Fi icon as follows:
  - (grayed out) Communication not established
  - (white, flashing) Connecting; (white, continuously on) Wireless upload on standby
  - (animated) Wireless upload in progress
  - [Eye-Fi Communication] is set to [OFF Off]
  - Wireless upload stopped by the camcorder (📖 159)
  - Error reading from the Eye-Fi card (📖 157)

IMPORTANT

Using an Eye-Fi Card

- This product is not guaranteed to support Eye-Fi card functions (including wireless transfer). In case of an issue with an Eye-Fi card, please check with the card manufacturer. Also note that an approval is required to use Eye-Fi cards in many countries or regions. Without approval, use of the card is not permitted. If it is unclear whether the card has been approved for use in the area, please check with the card manufacturer.
- Do not use Eye-Fi cards on airplanes and in other places where wireless communication is forbidden. Remove the Eye-Fi card from the camcorder beforehand.

Downloaded From VideoCamera-Manual.com Manuals

NOTES

- Depending on the amount of data to be uploaded and the network's wireless connection conditions, it can take some time to upload video files. If the wireless connection is too weak, the wireless upload may fail and the video files will be registered as incomplete uploads.
- **About power saving:**
  - Wireless communication drains the power of the battery pack faster than usual. We recommend powering the camcorder using the compact power adapter.
  - While files are being uploaded wirelessly, the camcorder's automatic power off function will be disabled.
- Wirelessly uploading files is not possible when the Eye-Fi card is in memory card slot A (the Eye-Fi icon will not appear on the screen). Be sure to insert the Eye-Fi card into memory card slot B.
- While using an Eye-Fi Card, the ACCESS indicator may flash from time to time.
- Wireless communication is available only in playback mode. Any wireless transfer in progress will be stopped if you set the camcorder to recording mode.
- You can turn off the wireless communication with the [Eye-Fi Communication]* setting.
- If the LOCK switch on the Eye-Fi card is set to prevent writing, you will not be able to turn the wireless communication on/off and the status icon will change to . To use wireless communication make sure the switch on the Eye-Fi card is not in the LOCK position.

* This menu option will appear only when using an Eye-Fi card.

Downloaded From VideoCamera-Manual.com Manuals

6 Additional Information

This chapter contains troubleshooting advice, screen messages, handling and maintenance tips, and other information.

Appendix: Menu Options Lists

Menu items not available appear grayed out. For details about how to select an item, refer to *Using the Menus* (📖 28). For details about each function, see the reference page. Menu options without a reference page are explained after the tables. Underlined menu options indicate default values.

FUNC. Panel

FUNC. Panel - Recording Modes

Control Button	Setting options/Function	AUTO	M	CINEMA	📖
[MENU]	Open the menus	–	●	●	29
[Rec. Programs]	[P Programmed AE], [Tv Shutter-Pri. AE], [Av Aperture-Pri. AE]	–	●	●	87
	[Portrait], [Sports], [Night Scene], [Snow], [Beach], [Sunset], [Low Light], [Spotlight], [Fireworks], [Underwater], [Surface]	–	●	–	78
[Decoration][1]	[Pens and Stamps], [Animated Stamps], [Captions][2]	●	●	●	62
	[] (image mix): Toggle on (▮) or off (▯), [▮▮] (pause live video)	–	●	–	
	[] (minimize toolbar)	●	●	●	
[WB White Balance]	[AWB Automatic], [Daylight], [Shade], [Cloudy], [Fluorescent], [Fluorescent H], [Tungsten], [Custom WB]	–	●	●	93

Downloaded From VideoCamera-Manual.com Manuals

Control Button	Setting options/Function	AUTO	M	CINEMA	📖
[Focus]	[MF] (manual focus): Toggle on (I) or off (▯), Touch AF frame	–	●	●	90
[Exposure]	[M] (manual exposure): Toggle on (I) or off (▯), Touch AE frame	–	●	●	89
[ZOOM]	Zoom controls, [START]/[STOP] control	●	●	●	46
	[] (tele macro): Toggle on (I) or off (▯)	–	●	●	92
[Mic. Level][1]	[A Automatic], [M Manual] [Audio Level Indicator]: Toggle on (I) or off (▯)	–	●	●	96
[Image Effects]	[ON], [OFF] When [ON] - [Color Depth], [Sharpness], [Contrast], [Brightness]: ±0 (-2 to +2)	–	●	–	94
[AGC Limit]	[A Automatic], [M Manual]: (0 dB to 24 dB)	–	●	●	90
[Image Stabilizer]	[Dynamic], [Standard], [Off]	–	●	●	81
[Faders][1]	[Off], [F1 Fade Trigger/Once], [F1 Fade Trigger/Always], [F2 Wipe/Once], [F2 Wipe/Always]	–	●	●	86
[Pre REC][1]	[ON On], [OFF Off]	–	●	●	82
[Review Recording][1]	–	–	●	●	76

[1] Option available only for recording movies.
[2] Some options are available only when recording a story using Story Creator.

Downloaded From VideoCamera-Manual.com Manuals

Edit Panel - Mode

Control Button	Date Index Screen	[SD Movies] Index Screen	Playback Pause	📖
[Copy (A → B)][1] HFM46 [Copy (Built-in → B)][1]	<*date*>, [Select], [All Scenes]	–	–	120
HFM46 [Convert HD → SD (A → B)][1] [Convert HD → SD (Built-in → B)][1]	<*date*>, [Select], [All Scenes]	–	–	129
[Delete]	<*date*>, [Select], [All Scenes]	[This Scene], [All Scenes]	[This Scene]	54
[Divide]	–	–	●	108

Control Button	[Edit Story] from the [Story Details] screen	[Edit Scene] from the [Scene List] screen	Playback Pause	📖
[Copy (A → B)][1] HFM46 [Copy (Built-in → B)][1]	<*by scene rating*>	–	–	121
HFM46 [Convert HD → SD (A → B)][1] [Convert HD → SD (Built-in → B)][1]	<*by scene rating*>	–	–	132
[Delete] or [🗑]	<*by scene rating*>	[This Scene]	[This Scene]	54
[Delete Story][2]	●	–	–	56
[Story Thumbnail][2]	●	–	–	72

Downloaded From VideoCamera-Manual.com Manuals

Control Button	[Edit Story] from the [Story Details] screen	[Edit Scene] from the [Scene List] screen	Playback Pause	🕮
[Edit Title][2]	●	–	–	73
[Copy]	–	●	–	71
[Move]	–	●	–	71
[Divide]	–	–	●	108
[Rating]	–	[★★★], [★★ •], [★ • •], [• • •] (unrated), [— — —] (others)		68

[1] Operation not available for recordings on memory card B ([B] tab).
[2] Operation not available for the two preexisting stories, [Unsorted] and [Video Snapshot].

Edit Panel - [📷] Mode

Control Button	Index Screen	Single Photo View	🕮
[Copy ([A] ➔ [B])]* HF M46 [Copy ([▣] ➔ [B])]*	[Select], [All Photos]	●	121, 122
[Delete]		●	112

* Operation not available for recordings on memory card B ([B] tab).

Setup Menus

[🎥] Camera Setup

Menu item	Setting options	M	CINEMA	🕮
[Digital Zoom]	[OFF Off], [40x 40x], [200x 200x]	●	–	–
[Zoom Speed]	[VAR Variable], [≫ Speed 3], [≫ Speed 2], [> Speed 1]	●	●	45
[AF Mode]	[I.AF Instant AF], [AF Normal AF]	●	●	–
[Focus Assistance][1]	[ON On], [OFF Off]	●	●	–
[Face Detection & Tracking]	[ON On 👤], [OFF Off]	●	●	83

Downloaded From VideoCamera-Manual.com Manuals

Menu item	Setting options	M	CINEMA	📖
[Auto Backlight Correction]	[ON On], [OFF Off]	●	●	90
[Auto Slow Shutter]	[ON On], [OFF Off]	●	●	–
[Conversion Lens]	[Tele Tele-converter], [Wide Wide-converter], [OFF Off]	●	●	–
[Fader Setting][1]	[BLACK Black Screen], [WHITE White Screen]	●	●	86
[Onscreen Markers]	[OFF Off], [Level (White)], [Level (Gray)], [Grid (White)], [Grid (Gray)]	●	●	–
[Camcorder Shake Indicator]	[ON On], [OFF Off]	●	●	–
[Wind Screen][1]	[A Automatic], [OFF Off]	●	●	–
[Microphone Attenuator][1]	[A Automatic],[ON On ATT]	●	●	–
[Built-in Mic Freq. Response]	[NORM Normal], [LB Boost LF Range], [LC Low Cut Filter], [MB Boost MF Range], [LHB Boost HF+LF Range]	●	●	98
[Built-in Mic Directionality]	[2ch MONO Monaural], [NORM Normal], [2ch WIDE Wide], [2ch ZOOM Zoom]	●	●	97
[Surround Mic Directionality][1, 2]	[5.1ch Surround], [5.1ch ZOOM Zoom], [5.1ch GUN Shotgun]	●	●	–
[Surround Mic Attenuator][1, 2]	[ON On ATT], [OFF Off]	●	●	–

[1] Option available only for recording movies.
[2] Option available only when the optional SM-V1 Surround Microphone is attached to the camcorder after having updated the camcorder's firmware using the memory card supplied with the SM-V1.

Downloaded From VideoCamera-Manual.com Manuals

[Digital Zoom]: Determines the operation of the digital zoom. The color of the indicator indicates the zoom.

- When activated, the camcorder will switch automatically to digital zoom when you zoom in beyond the optical zoom range.
- With the digital zoom the image is digitally processed, so the image resolution will deteriorate the more you zoom in.

Optical zoom	Digital zoom	
White	Light blue	Dark blue
Up to 10x	10x - 40x	40x - 200x

[AF Mode]: Select how fast the autofocus will operate.

- With [i.AF Instant AF] the autofocus adjusts quickly to a new subject. This is convenient, for example, when changing the focus from a near subject to a far subject in the background, or when recording moving subjects.
- When the optional Wide-converter or Tele-converter is attached to the camcorder, it may partially obstruct the Instant AF sensor. Set the AF mode to [AF Normal AF].
- When the recording program is set to [Underwater] or [Surface], the AF mode is automatically set to [AF Normal AF].

[Focus Assistance]: When focus assistance is activated, the image at the center of the screen is magnified to help you focus manually (📖 90).

- Using focus assistance will not affect the recordings. It will be cancelled automatically after 4 seconds or when you start recording.

[Auto Slow Shutter]: The camcorder automatically uses slow shutter speeds to obtain brighter recordings in places with insufficient lighting.

- Minimum shutter speed used: 1/25; 1/12 when the frame rate is set to [PF25 PF25].
- The auto slow shutter can only be activated when the recording program is set to [P Programmed AE], but the setting will not change even if you set the camcorder to [AUTO] mode.
- If a trailing afterimage appears, set the slow shutter to [OFF Off].
- When the recording program is set to [Underwater] or [Surface], the auto slow shutter is automatically set to [OFF Off].

[Conversion Lens]: When you attach to the camcorder an optional tele-converter or wide-converter, set the appropriate conversion lens setting to obtain optimal image stabilization.

Downloaded From VideoCamera-Manual.com Manuals

- When you select a setting other than [OFF Off], the AF mode is automatically set to [AF Normal AF].

[Onscreen Markers]: You can display a grid or a horizontal line at the center of the screen. Use the markers as a reference to make sure your subject is framed correctly (vertically and/or horizontally).
- Using the onscreen markers will not affect the recordings.

[Camcorder Shake Indicator]: The degree of camcorder shake will be indicated by the POWERED IS icon (5 levels: , , , ,) to help you be aware of excessive movement.

[Wind Screen]: The camcorder automatically reduces the background sound of wind when recording outdoors.
- Some low-frequency sounds will be suppressed along with the sound of wind. When recording in surroundings unaffected by wind or if you want to record low-frequency sounds, we recommend setting the wind screen to [OFF Off].

[Microphone Attenuator]: Helps prevent audio distortions.
[A Automatic]: The camcorder will automatically activate the microphone attenuator as necessary for optimal audio recording levels so high audio levels will not be distorted.
[ON On ATT]: The microphone attenuator will be activated at all times to reproduce more faithfully the sound dynamics. ATT will appear on the screen.
- This menu option is not available when the optional SM-V1 Surround Microphone is attached to the camcorder. In that case, activate the microphone attenuator with the [Surround Mic Attenuator] setting.
- When the recording program is set to [Underwater] or [Surface], the microphone attenuator is automatically set to [OFF Off].

[Surround Mic Directionality]: Sets the directionality mode of the optional SM-V1 Surround Microphone.
[5.1ch Surround]: Records 5.1ch surround sound.
[5.1ch ZOOM Zoom]: Records 5.1 audio channels. Additionally, the audio is linked to the zoom position. The larger the subject appears on the screen, the louder the sound will be as well.
[5.1ch GUN Shotgun]: Records monaural audio with a highly directional setting that is most sensitive to sound coming directly from the front of the camcorder/microphone.

[Surround Mic Attenuator]: Helps prevent audio distortions due to high audio recording levels when the optional SM-V1 Surround Microphone is

Downloaded From VideoCamera-Manual.com Manuals

attached to the camcorder. When set to [ON On ATT], ATT will appear on the screen.

[▶] / [📷] Playback Setup

Menu item	Setting options	▶	📷	📖
[Select Music]	[OFF Off], [ON On] When [ON On] - list of music tracks, [▶] ····· [♫] (Original sound/Background music)	●	●	69
[Data Code]	[OFF Off], [Date], [Time], [Date and Time], [Camera Data]	●	●	–
[Slideshow Transition]	[OFF Off], [Dissolve], [Slide Image]	–	●	113
[TV Type]*	[4:3 Normal TV], [16:9 Wide TV]	●	●	–

* Option not available when the camcorder is connected to an HDTV using the supplied HDMI cable.

[Data Code]: Displays the date and/or time when the scene or photo was recorded.
[Camera Data]: Displays the aperture (f-stop) and shutter speed used when recording the scene or photo.

[TV Type]: When you connect the camcorder to a TV using the supplied STV-250N Stereo Video Cable, select the setting according to the type of TV in order to display the picture in full and in the correct aspect ratio.
[4:3 Normal TV]: TV sets with 4:3 aspect ratio.
[16:9 Wide TV]: TV sets with 16:9 aspect ratio.
- When the TV type is set to [4:3 Normal TV], during the playback of video originally recorded with an aspect ratio of 16:9, the picture will not be displayed fullscreen.

[🎞] Recording & Connections Setup

Menu item	Setting options	M	CINEMA	▶	📷	📖
[Self Timer]	[ON On], [OFF Off]	●	●	–	–	95
[Video Snapshot Length][1]	[2sec 2 sec], [4sec 4 sec], [8sec 8 sec], [Story Length-Based]: Toggle on (▮) or off (▯)	●	●	●	–	61, 106

Downloaded From VideoCamera-Manual.com Manuals

Menu item	Setting options	M	CINEMA			
[Rate Scenes (Recording)][1]	[ON On], [OFF Off]	●	●	–	–	–
[Rec Media for Movies][1]	HF M46 [ ] (built-in memory), [A] (memory card A), [B] (memory card B), [Relay Recording]: [OFF Off], [→ A], [→ A → B], [A → B] HF M406 [A] (memory card A), [B] (memory card B), [Relay Recording]: [OFF Off], [A → B]	●	●	–	–	36
[Recording Mode][1]	[MXP High Quality 24 Mbps], [FXP High Quality 17 Mbps], [XP+ High Quality 12 Mbps], [SP Standard Play 7 Mbps], [LP Long Play 5 Mbps]	●	●	–	–	76
[Frame Rate][1, 2]	[50i 50i (Standard)], [PF25 PF25]	●	●	–	–	78
[Rec Media for Photos][3]	[ ]* (built-in memory), [A] (memory card A), [B] (memory card B) * HF M46 only.	●	–	●	–	36
[Photo Capture from Video][3]	[Single Photo], [Photo Sequence]	–	–	●	–	107
[Memory Info]	[ ]* (built-in memory), [A] (memory card A), [B] (memory card B) * HF M46 only.	●	●	●	●	–
[x.v.Color]	[ON On color], [OFF Off]	●	●	–	–	–
[Photo Numbering][3]	[Reset], [Continuous]	●	–	●	●	–

[1] Option available only for recording movies.

Downloaded From VideoCamera-Manual.com Manuals

[2] Can be set independently for [M] and [CINEMA] mode. The default value in [CINEMA] mode is [PF25 PF25].
[3] Option available only for recording photos.

[Rate Scenes (Recording)]: When set to [ON On], the scene rating scene will appear after every scene you record.

[Memory Info]: Displays a screen where you can verify how much of the built-in memory (HFM46 only) or the memory card is currently in use (total recording time and total number of photos) and how much space remains available for recording.
- Estimated figures about available movie recording time and available number of photos are approximate and based on the recording mode and photo quality/size settings currently in use.
- In the information screen of a memory card you can also check its Speed Class.
- HFM46 The [Total space] shown for the built-in memory indicates actually usable space. It may be slightly smaller than the nominal built-in memory capacity listed in the specifications.

[x.v.Color]: Uses a color space with an extended gamut to achieve deeper colors, closer to real life.
- Use this function to record video only when you intend to play back your recordings on an HDTV compatible with x.v.Color, connected to the camcorder using the supplied HDMI cable. If recordings made with x.v.Color are played back on a non-compatible TV, colors may not be reproduced correctly.

[Photo Numbering]: Select the photo numbering method to be used on a new memory card. Photos are automatically assigned consecutive numbers from 0101 to 9900, and stored in folders containing up to 100 photos. Folders are numbered from 101 to 998.
[Reset]: Photo numbers will restart from 101-0101 every time you insert a new memory card.
[Continuous]: Photo numbers will continue from the number following that of the last photo recorded with the camcorder.
- If the memory card you insert already contains a photo with a larger number, a new photo will be assigned a number one higher than that of the last photo on the memory card.
- We recommend using the [Continuous] setting.
- The photo number indicates the name and location of the file on the memory card. For example, the file name of a photo numbered 101-0107 is “IMG_**0107**.JPG”, stored under the folder “DCIM**101**CANON”.

Downloaded From VideoCamera-Manual.com Manuals

Menu item	Setting options	M	CINEMA			
[Output Onscreen Displays]	[ON On], [OFF Off]	●	●	●	●	–
[Language]	[Česky], [Dansk], [Deutsch], [Ελληνικά], [English], [Español], [Français], [Italiano], [Magyar], [Melayu], [Nederlands], [Norsk], [Polski], [Português], [Română], [Suomi], [Svenska], [Türkçe], [Русский], [Українська], [العربية], [فارسی], [ภาษาไทย], [简体中文], [繁體中文], [한국어], [日本語]	●	●	●	●	31
[LCD Brightness]	☀ ▬▬▬▬ ☀	●	●	●	●	–
[LCD Screen Dimmer]	[ON On], [OFF Off]	●	●	●	●	–
[LCD Mirror Image]	[ON On], [OFF Off]	●	●	–	–	–
[AV/Headphones]	[AV AV], [🎧 Headphones]	●	●	●	●	99
[Volume]	Speaker: 🔈 ▬▬▬▬ 🔊 , OFF	–	–	●	●	50
	Headphone: 🎧 ▬▬▬▬ 🎧 , OFF	●	●	●	●	99
[Notification Sounds]	[High Volume], [Low Volume], [OFF Off]	●	●	●	●	–
[Wireless Remote Control]	[ON On], [OFF Off]	●	●	●	●	–
[POWERED IS Button]	[ON Press and Hold], [ON/OFF Toggle On/Off]	●	●	–	–	82
[Autostart Decoration]	[ON On], [OFF Off]	●	●	●	–	–
[Power Saving Mode]	[Auto Power Off]: [OFF Off], [ON On] [Quick Start (Standby)]: [Off], [10 min], [20 min], [30 min]	●	●	●	●	–

Downloaded From VideoCamera-Manual.com Manuals

Menu item	Setting options	M	CINEMA			
HF M46 [Initialize /]	[Built-in Mem.]*, [A Mem. Card A], [B Mem. Card B] * HF M46 only.	●	●	●	●	38
HF M406 [Initialize]	[Complete Initialization]: Toggle on (I) or off (O)					
[Time Zone/DST]	[ ] (home time zone) or [ ] (travel time zone): [Paris], list of world time zones [ ] (DST adjustment): Toggle on (I) or off (O)	●	●	●	●	31
[Date/Time]	[Date/Time]: – [Date Format]: [Y.M.D], [M.D,Y], [D.M.Y] (Y- year, M- month, D- day) [24H]: Toggle on (I, 24-hour clock) or off (O, 12-hour clock)	●	●	●	●	30
[Battery Info]	–	●	●	●	●	–
[Control for HDMI][1]	[ON On], [OFF Off]	●	●	●	●	–
[HDMI 1080p Output][1]	[ON On], [OFF Off]	●	●	●	●	–
[HDMI Status]	[Video Output], [Audio Output]	●	●	●	●	–
[Distance Units]	[m meters], [ft feet]	●	●	–	–	–
[Demo Mode]	[ON On], [OFF Off]	●	●	–	–	–
[Firmware]	–	–	–	–	●	–
[Eye-Fi Communication][2]	[A Automatic], [OFF Off]	●	●	●	●	133

[1] Option not available when the camcorder is connected to an HDTV using the supplied HDMI cable.
[2] Option available only after having inserted an Eye-Fi card into memory card slot B.

[Output Onscreen Displays]: When set to [ON On], the camcorder's onscreen displays will appear also on the screen of a TV or monitor connected to the camcorder.

[LCD Brightness]: Adjusts the brightness of the LCD screen.

Downloaded From VideoCamera-Manual.com Manuals

- Changing the brightness of the LCD screen does not affect the brightness of your recordings or the brightness of the playback image on a TV.

[LCD Screen Dimmer]: When set to [ON On], the LCD screen is dimmed. Doing so is ideal when using the camcorder in locations where the LCD's illumination could become a nuisance to others. Hold DISP. pressed down for about 2 seconds to restore the LCD screen to its previous brightness setting.
- Dimming the LCD screen does not affect the brightness of your recordings or the brightness of the playback image on a TV.
- When the screen dimmer is set to [OFF Off], the LCD screen will return to the brightness level that was in use before the screen was dimmed.

[LCD Mirror Image]: When set to [ON On], you can rotate the LCD panel 180 degrees to let the subject check the image while you record. While the LCD panel is rotated toward the subject you will not be able to decorate the scene.

[Notification Sounds]: A beep will accompany some operations like turning on the camcorder, the self-timer countdown, etc.
- While pre-recording (📖 82) is activated, the camcorder will not emit any notification sounds.

[Wireless Remote Control]: Allows the camcorder to be operated with the wireless controller.

[POWERED IS Button]: Determines the operation mode of the POWERED IS button.
[ON Press and Hold]: Powered IS will be activated while you hold the button pressed down.
[ON/OFF Toggle On/Off]: Each press of the button will turn the Powered IS function on and off.

[Autostart Decoration]: When set to [ON On], the decoration screen will open automatically when you stow the LCD panel with the LCD screen facing out.

[Power Saving Mode]: Controls the camcorder's automatic power off settings.
[Auto Power Off]: In order to save power when the camcorder is powered by a battery pack, it will automatically shut off if left without any operation for 5 minutes.
- Approximately 30 seconds before the camcorder shuts off, [Auto Power Off] will appear.

Downloaded From VideoCamera-Manual.com Manuals

- In standby mode, the camcorder will shut off after the time selected for the [Quick Start (Standby)] setting.

[Quick Start (Standby)]: Select whether to activate the Quick Start function (📖 46) when you close the LCD panel in a recording mode and the length of time after which the camcorder will end the standby mode and shut off automatically.

- You can set Quick Start to [Off], for example, if the camcorder is set on a fixed position and you want to keep recording video with the LCD panel closed in order to conserve the battery's power.

[Battery Info]: Displays a screen where you can verify the battery charge (as a percentage) and the remaining recording time (M , CINEMA mode) or playback time (, mode).

[Control for HDMI]: Activates the HDMI-CEC (Consumer Electronics Control) function. When you connect the camcorder to an HDTV compatible with HDMI-CEC using the supplied HDMI cable, you can control the camcorder's playback using the remote control of the TV.

- If set to [ON On], when the camcorder is connected to a compatible HDTV using the supplied HDMI cable, the video input on the TV will automatically be set to the camcorder's video input. Then, you can use the up/down/left/right buttons and the OK or SET button on the TV's remote control to play back your recordings.
- Depending on the TV set, additional settings may be required on the TV itself to activate the HDMI-CEC function. Refer to the TV's instruction manual.
- Correct operation of the HDMI-CEC function cannot be guaranteed even when connecting the camcorder to compatible TV sets. If you cannot use the remote control of the TV, set [Control for HDMI] to [OFF Off] and operate the camcorder directly or use the camcorder's wireless controller.
- The remote control of the TV can only be used to play back movies or photos (or mode only). If the camcorder is connected to the TV while it is set to a recording mode, depending on the TV used, turning off the TV will automatically turn off the camcorder even if it is recording at the time.
- We recommend not connecting more than 3 HDMI-CEC compatible devices at a time.

[HDMI 1080p Output]: If set to [ON On], when the camcorder is connected to an HDTV that supports the 1080p standard using the supplied HDMI cable, your video recordings (made in 1080i) will be converted and output as 1080p.

Downloaded From VideoCamera-Manual.com Manuals

[HDMI Status]: Displays a screen where you can verify the standard of the output signal from the HDMI OUT terminal.

[Distance Units]: Selects the units to use for the focusing distance display during manual focus.

[Demo Mode]: The demonstration mode displays the camcorder's main features. It starts automatically when the camcorder is powered with the compact power adapter if you leave it turned on without a memory card for more than 5 minutes.

- To cancel the demo mode once it has started, press any button or turn off the camcorder.

[Firmware]: You can verify the current version of the camcorder's firmware. This menu option is usually unavailable.

Downloaded From VideoCamera-Manual.com Manuals

Appendix: Onscreen Icons and Displays

AUTO Recording Movies (using Story Creator)



① Control button [FUNC.]: Open the FUNC. panel (📖 28)
② Smart AUTO (📖 42)
③ Face detection frame (📖 83)
④ Touch & Track frame (📖 85)
⑤ Control button [PHOTO]: Take a photo (📖 40, 75, 107)
⑥ Control button [📖]: Return to the list of story scenes (📖 58)
⑦ Memory operation (📖 153)
⑧ Image stabilizer (📖 81)
⑨ Remaining battery time (📖 153)
⑩ Zoom (📖 46)
⑪ Recording mode (📖 76)
⑫ Current story scene (category) (📖 58)
⑬ Recommended scene length (📖 58)
⑭ Decoration (📖 62)

Downloaded From VideoCamera-Manual.com Manuals

M, CINEMA Recording Movies

M Manual mode



CINEMA mode



⑮ Recording program (📖 78, 86)
⑯ Manual exposure (📖 89)
⑰ I.AF Instant AF/ AF Normal AF (📖 140), MF Manual focus (📖 90)
⑱ Face detection (📖 83)
⑲ White balance (📖 93)
⑳ Audio level indicator (📖 96)
㉑ x.v.Color (📖 144)
㉒ While recording/during playback: Scene counter (hours : minutes : seconds)
㉓ Remote sensor off (📖 147)
㉔ Fader (📖 86)
㉕ Frame rate (📖 78)
㉖ Remaining recording time
A/B On the memory card
In the built-in memory*
*/A Relay recording (📖 37)
* HFM46 only.
㉗ Tele macro (📖 92)
㉘ Image effects (📖 94)
㉙ Microphone attenuator (📖 141)
㉚ Headphone output (📖 99)
㉛ Control button: Last function used ([ZOOM] in this case)
㉜ Level marker (📖 141)
㉝ Conversion lens (Tele-converter shown) (📖 140)
㉞ Wind screen off (📖 141)
㉟ Directionality of the optional SM-V1 Surround Microphone (📖 101)
㊱ Mini advanced shoe (📖 100)
㊲ AGC (automatic gain control) limit
㊳ Control button [FILTER 1]: Cinema-look filters (📖 60)
㊴ In record pause mode: Total number of scenes
㊵ Self timer (📖 95)
㊶ Pre-recording (📖 82)

Downloaded From VideoCamera-Manual.com Manuals

Playing Movies (during playback)



㊷ Playback control buttons (📖 50)
㊸ Eye-Fi wireless communication (📖 133)
㊹ Scene number
㊺ Data code (📖 105, 142)
㊻ Volume and background music balance controls (📖 50, 70)

Viewing Photos



㊼ Control button [MENU]: Open the setup menus (📖 138)
㊽ Control button [Edit]: Open the Edit panel (📖 138)
㊾ Current photo / Total number of photos
㊿ Photo number (📖 144)
(51) Control button [🏠]: Photo jump (📖 111)
(52) Control button [▶]: Slideshow (📖 113)
(53) Control button [▪]: Return to the [Photos] index screen (📖 110)

Downloaded From VideoCamera-Manual.com Manuals

⑦ Memory operation

● Record, ●❚❚ Record pause, ► Playback, ❚❚ Playback pause, ►► Fast playback, ◄◄ Fast reverse playback, ❙► Slow playback, ◄❙ Slow reverse playback, ❚❚► Frame advance, ◄❚❚ Frame reverse.

⑨ Remaining battery time



- The icon shows a rough estimate of the remaining charge as a percentage of the full charge of the battery pack. The remaining recording/playback time of the battery pack is displayed, in minutes, next to the icon.
- When is displayed in red, replace the battery pack with a fully charged one.
- When you attach an empty battery pack, the power may turn off without displaying .
- Depending on the conditions under which the camcorder and the battery pack are used, the actual battery charge may not be indicated accurately.
- When the camcorder is off, press BATT.INFO to display the charge status of a battery pack. The Intelligent System will display the charge status (as a percentage) and the remaining recording time (in minutes) for 5 seconds. If the battery pack is exhausted, the battery information may not be displayed.

㉖ Remaining recording time

When there is no more free space on the memory, [End] (built-in memory, HFM46 only) or [A End] (memory card A) or [B End] (memory card B) will be displayed in red and the recording will stop.

Downloaded From VideoCamera-Manual.com Manuals

Troubleshooting

If you have a problem with your camcorder, refer to this section. Sometimes what you think is a malfunction of the camcorder may have the simplest of solutions - please read the “CHECK THIS FIRST” box before going on to the more detailed problems and solutions. Consult your dealer or a Canon Service Center if the problem persists.

CHECK THIS FIRST

Power supply

- Is the battery charged? Is the compact power adapter correctly connected to the camcorder? (📖 19)

Recording

- Did you turn the camcorder on and correctly set it to a recording mode? (📖 40, 75) If you are recording on a memory card, is one correctly inserted into the camcoder? (📖 35)

Playback

- Did you turn the camcorder on and correctly set it to playback mode? (📖 48, 110) If you are playing back recordings from a memory card, is one correctly inserted into the camcorder? (📖 35) Does it contain any recordings?

Other

- Does the camcorder make a rattling sound? The internal lens fixture can move when the camcorder is turned off or in a playback mode. This is not a malfunction.

Power source

The camcorder will not turn on or it turns off by itself.

- The battery pack is exhausted. Replace or charge the battery pack.
- Remove the battery pack and reattach it correctly.
- When the recording program is set to [Underwater] or [Surface], the camcorder may turn off automatically if it becomes too hot. Turn off the camcorder and let it cool down.

Cannot charge the battery pack.

- Make sure the camcorder is off so charging can start.
- The temperature of the battery pack is outside its operating range (approximately 0 – 40 °C). Remove the battery pack, warm it or let it cool down, as necessary, and try charging it again.
- Charge the battery pack in temperatures between approximately 0 °C and 40 °C.
- The battery pack is faulty. Replace the battery pack.

Downloaded From VideoCamera-Manual.com Manuals

- The camcorder cannot communicate with the battery pack attached. Battery packs not recommended by Canon for use with this camcorder cannot be charged using this camcorder.
- If you are using a battery pack recommended by Canon for use with this camcorder, there may be a problem with the camcorder or battery pack. Consult a Canon Service Center.

A noise can be heard from the compact power adapter.

- A faint sound can be heard while the compact power adapter is connected to a power outlet. This is not a malfunction.

The battery pack is exhausted extremely quickly even at normal temperatures.

- The battery may have reached the end of its battery life. Buy a new battery pack.

Recording

Pressing START/STOP will not start recording.

- You cannot record while the camcorder is writing previous recordings onto the memory (while the ACCESS indicator is on or flashing). Wait until the camcorder has finished.
- The memory is full or it already contains the maximum number of scenes (3,999 scenes). Delete some recordings (📖 54, 112) or initialize the memory (📖 38) to free some space.

The point where START/STOP was pressed does not match the beginning/end of the recording.

- There is a slight interval between pressing START/STOP and the actual start/end of recording. This is not a malfunction.

The camcorder will not focus.

- Autofocus does not work on the subject. Focus manually (📖 90).
- The lens or Instant AF sensor is dirty. Clean the lens or sensor with a soft lens-cleaning cloth (📖 172). Never use tissue paper to clean the lens.

When a subject flits across in front of the lens, the image appears slightly bent.

- This is a phenomenon typical of CMOS image sensors. When a subject crosses very quickly in front of the camcorder, the image may seem slightly warped. This is not a malfunction.

Changing the operating mode between recording (●)/record pause (●❚❚)/playback (▶) takes longer than usual.

- When the memory contains a large number of scenes, some operations may take longer than usual. Save your recordings (📖 123) and initialize the memory (📖 38).

Movies or photos cannot be recorded properly.

- This may occur as movies and photos are recorded/deleted over time. Save your recordings (📖 123) and initialize the memory (📖 38).

Cannot record a photo while recording movies.

- You cannot take photos in CINEMA mode, while the digital zoom is activated (📖 140) or while fading in or fading out a scene (📖 86).

Downloaded From VideoCamera-Manual.com Manuals

After using the camcorder for a long time, it becomes hot.

- The camcorder may become hot after using it continuously for long periods of time; this is not a malfunction. If the camcorder becomes unusually hot or it becomes hot after using it only for a short while, it may indicate a problem with the camcorder. Consult a Canon Service Center.

Cannot create a new story.

- A memory can contain a maximum of 98 user-created stories. Delete some stories from the gallery (📖 56) or select a different memory (📖 36).

Playback

Cannot copy/move scenes in a story.

- The memory is full. Delete some recordings (📖 54, 112) to free some space.

Cannot delete a scene.

- You may not be able to delete scenes recorded or edited using another device.

Deleting scenes takes longer than usual.

- When the memory contains a large number of scenes, some operations may take longer than usual. Save your recordings (📖 123) and initialize the memory (📖 38).

Cannot capture a video snapshot scene from a movie.

- You cannot capture video snapshot scenes from scenes recorded or edited using another device and then transferred to a memory card connected to the computer.
- The memory is full. Delete some recordings (📖 54, 112) to free some space.

When playing back scenes/slideshow with background music, the music track is not played back correctly.

- This can occur when you transfer the music files to a memory card after repeatedly recording and deleting scenes (fragmented memory). Save your recordings (📖 123) and initialize the memory card (📖 38). Then, transfer the music files first and only then transfer the video files.
- Music tracks will not play back correctly if the connection was interrupted while transferring the music files to a memory card. Delete the music tracks and transfer the music files again.
- The transfer rate of the memory card used is too slow. Use a recommended memory card (📖 33).

Cannot divide scenes

- You cannot divide scenes recorded or edited using another device and then transferred to a memory card connected to the computer.
- The memory is full. Delete some recordings (📖 54, 112) to free some space.

Cannot copy scenes/photos

- You may not be able to copy scenes/photos recorded or edited using another device and then transferred to a memory card connected to the computer.

Downloaded From VideoCamera-Manual.com Manuals

Cannot mark individual scenes/photos in the index screen with a checkmark ✓

- You cannot select more than 100 scenes/photos individually. Select the [All Scenes] or [All Photos] option instead of [Select].

Indicators and Onscreen Displays

[ZZ] lights up in red.

- Battery pack is exhausted. Replace or charge the battery pack.

[?] appears on the screen.

- The camcorder cannot communicate with the battery pack attached so the remaining battery time cannot be displayed.

[A]/[B] lights up in red.

- A memory card error occurred. Turn off the camcorder. Remove and reinsert the memory card. Initialize the memory card if the display does not change back to normal.
- The memory card is full. Replace the memory card or delete some recordings (📖 54, 112) to free some space on the memory card.

Even after stopping recording, the ACCESS indicator does not go off.

- The scene is being recorded in the memory. This is not a malfunction.

[Underwater] appears on the screen.

- The camcorder has become hot while in the [Underwater] or [Surface] recording program. Turn off the camcorder and let it cool down.

The red ON/OFF (CHG) indicator flashes rapidly (one flash at 0.5-second intervals).

- Charging has stopped because the compact power adapter or the battery pack is faulty. Consult a Canon Service Center.

The red ON/OFF (CHG) indicator flashes very slowly (one flash at 2-second intervals).

- The temperature of the battery pack is outside its operating range (approximately 0 – 40 °C). Remove the battery pack, warm it or let it cool down, as necessary, and try charging it again.
- Charge the battery pack in temperatures between approximately 0 °C and 40 °C.
- The battery pack is damaged. Use a different battery pack.

[Eye-Fi] appears on the screen

- The LOCK switch on the Eye-Fi card is set to prevent accidental erasure. Change the position of the LOCK switch.
- An error occurred when trying to access control data on the Eye-Fi card. Turn the camcorder off then on again. If the icon appears often, there might be a problem with the Eye-Fi card. Contact the card manufacturer's customer care.

Downloaded From VideoCamera-Manual.com Manuals

Picture and Sound

The screen appears too dark.

- The LCD screen was dimmed. Hold DISP. pressed down for 2 seconds to restore the LCD screen to its previous brightness setting.

Screen displays turn on and off repeatedly.

- The battery pack is exhausted. Replace or charge the battery pack.
- Remove the battery pack and reattach it correctly.

Abnormal characters appear on the screen and the camcorder does not operate properly.

- Disconnect the power source and reconnect it after a short time. If the problem still persists, remove the battery pack and disconnect all other power sources from the camcorder. Then, press the RESET button with a pointed object to reset all the camcorder's settings to default values.

Video noise appears on screen.

- Keep a distance between the camcorder and devices that emit strong electromagnetic fields (plasma TVs, cellular phones, etc.).

Horizontal bands appear on the screen.

- This is a phenomenon typical of CMOS image sensors when recording under some types of fluorescent, mercury or sodium lamps. To reduce the symptoms, set the recording program to [Programmed AE] or [Shutter-Pri. AE] (📖 87). This is not a malfunction.

Sound is distorted or is recorded at lower levels.

- When recording near loud sounds (such as fireworks, shows or concerts), sound may become distorted or it may not be recorded at the actual levels. Activate the microphone attenuator (📖 141) or adjust the audio recording level manually (📖 96).

The picture is displayed correctly but there is no sound from the built-in speaker.

- Speaker volume is turned off. Adjust the volume.
- If the STV-250N Stereo Video Cable is connected to the camcorder, disconnect it.
- The AV terminal is set to headphone output. Set [ ] [AV/Headphones] to [AV].

Memory Card and Accessories

Cannot insert the memory card.

- The memory card was not facing the correct direction. Turn the memory card over and insert it.

Cannot record on the memory card.

- The memory card is full. Delete some recordings (📖 54, 112) to free some space or replace the memory card.
- Initialize the memory card (📖 38) when you use it with the camcorder for the first time.

Downloaded From VideoCamera-Manual.com Manuals

- The LOCK switch on the memory card is set to prevent accidental erasure. Change the position of the LOCK switch.
- A compatible memory card must be used to be able to record movies on a memory card (33).
- The folder and file numbers have reached their maximum value. Set [Photo Numbering] to [Reset] and insert a new memory card.

The wireless controller will not work.

- Set [Wireless Remote Control] to [On].
- Replace the battery of the wireless controller.

Cannot upload files wirelessly using an Eye-Fi card.

- You may have inserted the Eye-Fi card into memory card slot **A**. Insert it into memory card slot **B**.
- [Eye-Fi Communication] is set to [Off] (appears onscreen). Set it to [Automatic].
- Wireless communication is not available in recording mode. Set the camcorder to playback mode.
- Opening the LCD panel may help when the wireless connection is not strong enough.
- During wireless transfer, wireless communication may stop when the wireless signal conditions worsen (appears onscreen). Perform wireless transfer in a place with good signal conditions.
- Contact the card manufacturer's customer care.

The wireless communication status icon does not appear

- You may have inserted the Eye-Fi card into memory card slot **A**. Insert it into memory card slot **B**.

Connections with External Devices

Video noise appears on the TV screen.

- When using the camcorder in a room where a TV is located, keep a distance between the compact power adapter and the power or antenna cables of the TV.

Playback looks fine on the camcorder but there is no image on the TV screen.

- The video input on the TV is not set to the video terminal to which you connected the camcorder. Select the correct video input.
- There will be no video output from the AV OUT terminal while the optional CTC-100 Component Cable is connected to the camcorder's COMPONENT OUT terminal. Disconnect the CTC-100 Component Cable in advance to use the AV OUT terminal.

There is no sound from the TV.

- When connecting the camcorder to an HDTV using the optional CTC-100 Component Cable, make sure to connect also the audio connections using the white and red plugs of the STV-250N Stereo Video Cable.

Downloaded From VideoCamera-Manual.com Manuals

The camcorder is connected using the supplied HDMI cable, but there is no picture or sound from the HDTV.

- Disconnect the supplied HDMI cable and then restore the connection or turn the camcorder off and then on again.

The camcorder is connected using the supplied HDMI cable, but HDMI-CEC does not work (cannot play back using the TV's remote control).

- Disconnect the HDMI cable and turn off the camcorder and the TV. After a short while turn them on again and restore the connection.
- [ ] [Control for HDMI] is set to [Off]. Set it to [On].
- HDMI-CEC is not activated on the connected TV. Activate this function on the TV.
- Even with TV sets compatible with HDMI-CEC the range of functions available differs depending on the type of TV. Refer to the instruction manual of the connected TV.

The computer does not recognize the camcorder even though the camcorder is connected correctly.

- Disconnect the USB cable and turn off the camcorder. After a short while, turn it on again and restore the connection.
- Connect the camcorder to a different USB port on the computer.

Cannot save photos on my computer

- When the memory contains too many photos (Windows – 2,500 photos or more, Macintosh – 1,000 photos or more), you may not be able to transfer photos to a computer. Try using a card reader to transfer the photos on the memory card. HF M46 only: To transfer the photos in the built-in memory, copy them to the memory card in advance (📖 120).

List of Messages (in alphabetical order)

Accessing the memory card. Do not remove the memory card.

- You opened the double memory card slot cover while the camcorder was accessing the memory card or the camcorder started accessing the memory card as you opened the double memory card slot cover. Do not remove the memory card until this message disappears.

Back up recordings regularly

- This message may appear when you turn on the camcorder. In the event of a malfunction, recordings may be lost so back up your recordings regularly.

Buffer overflow. Recording was stopped.

- The data transfer rate was too high for the memory card in use and the recording was stopped. Replace the memory card with one rated SD Speed Class 2, 4, 6 or 10.
- After repeatedly recording, deleting and editing scenes (fragmented memory), it will take longer to write data on the memory and recording may stop. Save your recordings (📖 123) and initialize the memory (📖 38).

HF M46 Built-in memory error

- The built-in memory could not be read. Contact a Canon Service Center.

Downloaded From VideoCamera-Manual.com Manuals

HFM46 Built-in memory is full

- The built-in memory is full ("End" appears on the screen). Delete some recordings (54, 112) to free some space. Alternatively, save your recordings (123) and initialize the built-in memory (38).

HFM46 Built-in memory writing error Attempt recovering the data?

- This message will appear the next time you turn on the camcorder if power supply was accidentally interrupted while the camcorder was writing to the built-in memory. Select [Recover] to try to recover the recordings.

HFM46 Cannot access the built-in memory

- There is a problem with the built-in memory. Contact a Canon Service Center.

Cannot communicate with the battery pack. Continue using this battery pack?

- You attached a battery pack that is not recommended by Canon for use with this camcorder.
- If you are using a battery pack recommended by Canon for use with this camcorder, there may be a problem with the camcorder or battery pack. Consult a Canon Service Center.

HFM46 Cannot convert

- Cannot access the memory card. Check the memory card and make sure it is inserted correctly.
- You inserted a MultiMedia Card (MMC) into the camcorder. Use a recommended memory card (33).
- There was an error creating the file name. Set [Photo Numbering] to [Reset] and initialize the memory card (38) or delete all the photos (112) and converted SD movies (54).

Cannot copy

- The total size of the scenes you selected to copy exceeds the available space on the memory card. Delete some recordings on the memory card (54, 112) or reduce the number of scenes to copy.
- The memory card already contains the maximum number of scenes (3,999 scenes). Delete some scenes (54) to free some space.
- The gallery already contains the maximum number of stories (98 stories in any one given memory). Delete some stories (56) to free some space.

Cannot divide the scene. Initialize only using the camcorder.

- Use the supplied software VideoBrowser to save the scene and divide it on the computer.

Cannot enter standby mode now

- The camcorder cannot enter standby mode if the remaining battery charge is too low. Charge or replace the battery pack (19).

Cannot load canvas

- The canvas file that was saved on the memory is corrupted.
- Canvas data cannot be read from canvas files created using other devices and then transferred to a memory card connected to the computer.

Downloaded From VideoCamera-Manual.com Manuals

Cannot play back

- There is a problem with the memory. If this message appears often without apparent reason, contact a Canon Service Center.

HFM46 Cannot play back Cannot access the built-in memory

- There is a problem with the built-in memory. Save your recordings (📖 123) and initialize the built-in memory using the [Complete Initialization] option (📖 38). If the problem persists, contact a Canon Service Center.

Cannot play back Check the memory card

- There is a problem with the memory card. Save your recordings (📖 123) and initialize the memory card using the [Complete Initialization] option (📖 38). If the problem persists, use a different memory card.

HFM46 Cannot play the movies in the built-in memory Initialize only using the camcorder

- The camcorder's built-in memory was initialized using a computer. Initialize the built-in memory with this camcorder (📖 38).

Cannot play the movies on this memory card

- Movies cannot be played back from a 64 MB or smaller memory card. Use a recommended memory card (📖 33).

Cannot play the movies on this memory card Initialize only using the camcorder

- The memory card in the camcorder was initialized using a computer. Initialize the memory card with this camcorder (📖 38).

Cannot record

- You cannot capture video snapshot scenes from scenes recorded or edited using another device and then transferred to a memory card connected to the computer.
- There is a problem with the memory. If this message appears often without apparent reason, contact a Canon Service Center.

HFM46 Cannot record Cannot access the built-in memory

- There is a problem with the built-in memory. Save your recordings (📖 123) and initialize the built-in memory using the [Complete Initialization] option (📖 38). If the problem persists, contact a Canon Service Center.

Cannot record Check the memory card

- There is a problem with the memory card. Save your recordings (📖 123) and initialize the memory card using the [Complete Initialization] option (📖 38). If the problem persists, use a different memory card.

HFM46 Cannot record movies in the built-in memory Initialize only using the camcorder

- The camcorder's built-in memory was initialized using a computer. Initialize the built-in memory with this camcorder (📖 38).

Cannot record movies on this memory card

- Movies cannot be recorded on a 64 MB or smaller memory card. Use a recommended memory card (📖 33).

Downloaded From VideoCamera-Manual.com Manuals

Cannot record movies on this memory card Initialize only using the camcorder

- The memory card in the camcorder was initialized using a computer. Initialize the memory card with this camcorder (📖 38).

Cannot save the canvas

- Cannot save your [Pens and Stamps] drawings on the memory. Save your recordings (📖 123) and initialize the memory (📖 38).

Change the battery pack

- Battery pack is exhausted. Replace or charge the battery pack.

Check the memory card

- Cannot access the memory card. Check the memory card and make sure it is inserted correctly.
- A memory card error occurred. The camcorder cannot record or display the image. Try removing and reinserting the memory card, or use a different memory card.
- You inserted a MultiMedia Card (MMC) into the camcorder. Use a recommended memory card (📖 33).
- If after the message disappears, A/B appears in red, perform the following: Turn off the camcorder and remove and reinsert the memory card. If A/B turns back to green you can resume recording/playback. If the problem persists, save your recordings (📖 123) and initialize the memory card (📖 38).

Do not disconnect the power source. Do not disconnect the USB cable unless you first use the computer to safely end the connection.

- When the camcorder is in mode and is connected to the computer with the supplied USB cable, the camcorder cannot be operated. Disconnecting the USB cable or power source while this message appears may result in permanent loss of the recordings in the camcorder. Use the computer's Safely Remove Hardware function to end the connection and disconnect the USB cable before using the camcorder.

File name error

- The folder and file numbers have reached their maximum value. Set ▸ [Photo Numbering] to [Reset] and delete all the photos on the memory card (📖 112) or initialize it (📖 38).

Initialize only using the camcorder

- There is a problem with the file system that prevents accessing the selected memory. Initialize the memory with this camcorder (📖 38).

LCD Screen has been dimmed

- Hold DISP. pressed for 2 seconds to restore the LCD screen to its previous brightness setting.

May not be possible to record movies on this memory card

- You may not be able to record movies on a memory card without a Speed Class rating. Replace the memory card with one rated SD Speed Class 2, 4, 6 or 10.

Downloaded From VideoCamera-Manual.com Manuals

Mem. Card Number of scenes already at maximum

- The memory card already contains the maximum number of scenes (3,999 scenes); no further scenes can be copied onto the memory card. Delete some scenes (📖 54) to free some space.

Mem. Card Unable to recognize the data

- The memory card contains scenes recorded using a video configuration that is not supported (NTSC). Play back the recordings in the memory card with the device originally used to record them.

Memory card A / Memory card B writing error Attempt recovering the data?

- This message will appear the next time you turn on the camcorder if power supply was accidentally interrupted while the camcorder was writing on the memory card. Select [Recover] to try to recover the recordings. If you removed the memory card and used it with another device after this happened, we recommend you select [No].

Memory card cover is open

- After inserting a memory card, close the double memory card slot cover.

Memory card is full

- The memory card is full. Delete some recordings (📖 54, 112) to free some space or replace the memory card.

Memory card is write-protected

- The LOCK switch on the memory card is set to prevent accidental erasure. Change the position of the LOCK switch.

Need to recover files from the memory card. Change the position of the LOCK switch on the memory card.

- This message will appear the next time you turn on the camcorder if power supply was accidentally interrupted while the camcorder was writing on the memory card and later the position of the card's LOCK switch was changed to prevent erasure. Change the position of the LOCK switch.

No memory card

- Insert a compatible memory card into the camcorder (📖 35).

No photos

- There are no photos to play back. Have fun taking some photos (📖 40).

No scenes

- There are no scenes in the memory selected. Have fun shooting some video (📖 40).

HF M46 Not enough available space

- Delete some recordings on the memory card (📖 54, 112) or select the [3 Mbps] bit rate for the conversion to SD.

Number of scenes already at maximum

- The maximum number of scenes (3,999 scenes) has been reached. Delete some scenes (📖 54) to free some space.

Downloaded From VideoCamera-Manual.com Manuals

Number of stories already at maximum

- The gallery already contains the maximum number of stories (98 stories in any one given memory). Delete some stories (📖 56) or change the recording memory for movies (📖 36).

Recording program: Underwater / Surface
Turn on the camcorder while holding the zoom lever toward T or W to change the recording program.

- Follow the instructions to switch the recording program between [Underwater] and [Surface] while the camcorder is secured inside the optional WP-V3 Waterproof Case.

Scene recorded using another device. Cannot divide the scene.

- Scenes that were not recorded with this camcorder cannot be divided with this camcorder.

Scene recorded using another device. Cannot play back the scene.

- Scenes that were not recorded with this camcorder cannot be played back.

Select the desired scene number

- A number of scenes have the same recording date but different file control information. This can occur for example when you edit photos and write the files back to the camcorder. Select a number to display the corresponding group of scenes.

HF M46 Some scenes could not be converted

- Some scenes selected for conversion to SD were recorded using another device and then transferred to a memory card connected to the computer. These scenes were not converted.
- Among the scenes selected for conversion to SD there are scenes recorded with another device using 24p frame rate and then transferred to a memory card connected to the computer. When converting scenes to SD, leave out scenes recorded using another devices.

Some scenes could not be deleted

- Movies that were protected/edited with other devices and then transferred to a memory card connected to the computer, cannot be deleted with this camcorder.

Some scenes were recorded using another device and cannot be copied.

- Scenes that were not recorded with this camcorder cannot be copied to memory card **B**.

Task in progress. Do not disconnect the power source.

- The camcorder is updating the memory. Wait until the operation ends and do not disconnect the compact power adapter or remove the battery pack.

There are no scenes with the selected rating

- No scenes have been rated yet. Rate the scenes as you like (📖 68).
- The criteria you used to select scenes by rating resulted in no applicable scenes. Change the criteria used to select scenes by rating.

This memory card contains scenes. Delete all scenes to use relay recording.

- Save your movies (📖 123) if necessary, and delete all the movies from the memory card (📖 54).

This photo cannot be displayed

- You may not be able to display photos taken with other devices or image files created or edited on a computer and then transferred to a memory card connected to the computer.

Downloaded From VideoCamera-Manual.com Manuals

This scene was recorded using another device and cannot be copied.

- Scenes that were not recorded with this camcorder cannot be copied to memory card B.

To record video on this memory card, it is recommended to use only the XP+/SP/LP recording modes

- Movies may not be recorded correctly on this memory card if the recording mode is set to MXP or FXP mode (📖 76).

To use the wireless function, insert the Eye-Fi card into slot B.

- You may have inserted the Eye-Fi card into memory card slot A. Insert it into memory card slot B.

Too many photos. Disconnect the USB cable.

- Disconnect the USB cable. Try using a memory card reader or decrease the number of photos on the memory card to fewer than 2,500 photos (Windows), or 1,000 photos (Mac OS).
- If a dialog box appeared on the computer screen, close it. Disconnect the USB cable, and restore the connection after a short while.

HFM46 Total play time is too long

- When converting scenes from a story, the maximum total playback time of the scenes to be converted is 2 hours and 30 minutes. Reduce the number of scenes to be converted to SD.

Unable to recognize the data

- You transferred data to the camcorder recorded using a video configuration that is not supported (NTSC). Play back the recordings with the device originally used to record them.

Unable to recover data

- Could not recover a corrupted file. Save your recordings (📖 123) and initialize the memory using the [Complete Initialization] option (📖 38).

Unsupported gallery data detected. Cannot record or edit. Delete gallery data?

- The gallery data of the movies in the selected memory card is not supported. The movies can be played back but you cannot edit them or record additional scenes to this gallery. Select [Yes] to delete the unsupported gallery data. Note that after doing so, you will not be able to play back the movies with the device originally used to record the unsupported gallery data.

Downloaded From VideoCamera-Manual.com Manuals

Camcorder

Be sure to observe the following precautions to ensure maximum performance.

- **Save your recordings periodically.** Make sure to transfer your recordings to an external device such as a computer or digital video recorder (📖 120) and save them on a regular basis. This will protect your important recordings in case of damage and create more free space on the memory. Canon shall not be liable for any data loss.
- Do not carry the camcorder by the LCD panel. Be careful when closing the LCD panel. When using a wrist strap, do not allow the camcorder to swing and hit an object.
- **Handle the touch screen with care.** Do not apply excessive force and, with the exception of the supplied stylus pen, do not use ballpoint pens or other hard-tipped tools to operate the touch screen. This may damage the touch screen's surface or the pressure-sensitive layer beneath it.
- Do not attach protective film on the touch screen. The touch screen's operation is based on detecting applied pressure, so you may not be able to correctly operate the touch screen with an additional protective layer.
- Do not leave the camcorder in places subject to high temperatures (like the inside of a car parked under direct sunlight), or high humidity.
- Do not use the camcorder near strong electromagnetic fields such as above TVs, near plasma TVs or mobile phones.
- Do not point the lens at strong light sources. Do not leave the camcorder pointed at a bright subject.
- Do not use or store the camcorder in dusty or sandy places. The camcorder is not waterproof – avoid also water, mud or salt. If any of the above should get into the camcorder it may damage the camcorder and/or the lens.
- Be careful of heat generated by lighting equipment.
- Do not disassemble the camcorder. If the camcorder does not function properly, consult qualified service personnel.
- Handle the camcorder with care. Do not subject the camcorder to shocks or vibration as this may cause damage.

Downloaded From VideoCamera-Manual.com Manuals

- When mounting the camcorder on a tripod, make sure that the tripod's fastening screw is shorter than 5.5 mm. Using other tripods may damage the camcorder.



- **When recording movies, try to get a calm, stable picture.** Excessive camcorder movement while shooting and extensive use of fast zooms and panning can result in jittery scenes. In extreme cases, the playback of such scenes may result in visually induced motion sickness. If you experience such a reaction, stop the playback immediately and take a rest break as necessary.
- Do not insert the supplied stylus pen into the mouth. If swallowed, seek medical assistance immediately.
- Handle the supplied stylus pen with extreme care and keep it out of the reach of children. If mishandled, the stylus pen can present a risk of severe eye injury and even blindness.

Long-term storage

If you do not intend to use the camcorder for a long time, store it in a place free of dust, in low humidity, and at temperatures not higher than 30 °C.

Battery Pack

DANGER!

Treat the battery pack with care.

- Keep it away from fire (or it might explode).
- Do not expose the battery pack to temperature higher than 60 °C. Do not leave it near a heater or inside a car in hot weather.
- Do not try to disassemble or modify it.
- Do not drop it or subject it to shocks.
- Do not get it wet.

- Dirty terminals may cause a poor contact between the battery pack and the camcorder. Wipe the terminals with a soft cloth.

Downloaded From VideoCamera-Manual.com Manuals

Long-term storage

- Store battery packs in a dry place at temperatures no higher than 30 °C.
- To extend the battery life of the battery pack, discharge it completely before storing it.
- Charge and discharge all your battery packs fully at least once a year.

Remaining battery time

If the remaining battery time displayed is not correct, charge the battery pack fully. Still, the correct time may not be displayed after a large number of repeated uses, if a fully charged battery pack is left unused, or if a battery pack is used for long periods of time in high temperatures. Use the time shown on the screen as an approximation.

Regarding the use of non-Canon battery packs

- For your safety, battery packs that are not genuine Canon battery packs will not be charged even if you attach them to this camcorder or to the optional CG-800E Battery Charger.
- We recommend using genuine Canon battery packs bearing the Intelligent System mark. Intelligent Li-ion Battery
- If you attach to the camcorder battery packs that are not genuine Canon battery packs, will appear and the remaining battery time will not be displayed.

Memory Card

- We recommend backing up the recordings on the memory card onto your computer. Data may be corrupted or lost due to memory card defects or exposure to static electricity. Canon shall not be liable for lost or corrupted data.
- Do not touch or expose the terminals to dust or dirt.
- Do not use memory cards in places subject to strong magnetic fields.
- Do not leave memory cards in places subject to high humidity and high temperature.
- Do not disassemble, bend, drop, or subject memory cards to shocks and do not expose them to water.

Downloaded From VideoCamera-Manual.com Manuals

- Check the direction before inserting the memory card. Forcing a memory card into the slot if it is not correctly oriented may damage the memory card or the camcorder.
- Do not attach any labels or stickers on the memory card.
- Secure Digital (SD) memory cards have a physical switch to prevent writing on the card so as to avoid the accidental erasure of the card's content. To write-protect the memory card set the switch to the LOCK position.



LOCK switch

Built-in Rechargeable Lithium Battery

The camcorder has a built-in rechargeable lithium battery to keep the date/time and other settings. The built-in lithium battery is recharged while you use the camcorder; however, it will discharge completely if you do not use the camcorder for about 3 months.

To recharge the built-in lithium battery: Connect the compact power adapter to the camcorder and leave it connected for 24 hours with the camcorder off.

Downloaded From VideoCamera-Manual.com Manuals

Lithium Button Battery

WARNING!

- The battery used in this device may present a fire or chemical burn hazard if mishandled.
- Do not disassemble, modify, immerse in water, heat above 100 °C or incinerate the battery.
- Replace with a CR2025 battery made by Panasonic, Hitachi Maxell, Sony, FDK, or with Duracell2025. Use of other batteries may present a risk of fire or explosion.
- Do not insert the battery into the mouth. If swallowed, seek medical assistance immediately. The battery case may break and the battery fluids may cause internal injuries.
- Keep the battery out of the reach of children.
- Do not recharge, short-circuit or insert the battery in the wrong direction.
- The used battery should be returned to the supplier for safe disposal.

- Do not pick up the battery using tweezers or other metal tools, as this will cause a short circuit.
- Wipe the battery with a clean dry cloth to ensure proper contact.

Disposal

When you delete movies or initialize the memory, only the file allocation table is altered and stored data is not physically erased. Take the necessary precautions when you dispose of the camcorder or memory card, for example by physically damaging it to prevent the leakage of private data.
If giving the camcorder or memory card to another person, initialize the built-in memory (HF M46 only) or memory card using the [Complete Initialization] option (📖 38). Fill it up with unimportant recordings, and then initialize it again using the same option. This makes recovering the original recordings very difficult.

Downloaded From VideoCamera-Manual.com Manuals

Cleaning

Camcorder Body

- Use a soft, dry cloth to clean the camcorder body. Never use chemically treated cloths or volatile solvents such as paint thinner.

Lens and Instant AF Sensor

- If the lens surface or Instant AF sensor is dirty, autofocus may not work properly.
- Remove any dust or dirt particles using a non-aerosol type blower brush.
- Use a clean, soft lens-cleaning cloth to gently wipe the lens. Never use tissue paper.

LCD Touch Screen

- Clean the LCD touch screen using a clean, soft lens-cleaning cloth.
- Condensation may form on the surface of the screen when the temperature changes suddenly. Wipe it with a soft dry cloth.

Condensation

Moving the camcorder rapidly between hot and cold temperatures may cause condensation (water droplets) to form on its internal surfaces. Stop using the camcorder if condensation is detected. Continued use may damage the camcorder.

Condensation may form in the following cases:

- When the camcorder is moved quickly from cold to warm places
- When the camcorder is left in a humid room
- When a cold room is heated rapidly

To avoid condensation

- Do not expose the camcorder to sudden or extreme changes in temperature.

Downloaded From VideoCamera-Manual.com Manuals

- Remove the memory card and battery pack. Then, place the camcorder in an airtight plastic bag and let it adjust gradually to temperature changes before removing it from the bag.

When condensation is detected

The camcorder automatically shuts off.
The precise time required for water droplets to evaporate will vary depending on the location and weather conditions. As a general rule, wait for 2 hours before resuming use of the camcorder.

Using the Camcorder Abroad

Power Sources

You can use the compact power adapter to operate the camcorder and to charge battery packs in any country with power supply between 100 and 240 V AC, 50/60 Hz. Consult a Canon Service Center for information on plug adapters for overseas use.

Playback on a TV Screen

You can only play back your recordings on TVs compatible with the PAL system. PAL (or the compatible SECAM system) is used in the following regions/countries:
Europe: All of Europe and Russia. **Americas:** Only in Argentina, Brazil, Uruguay and French territories (French Guiana, Guadeloupe, Martinique, etc.). **Asia:** Most of Asia (except in Japan, the Philippines, South Korea, Taiwan and Myanmar). **Africa:** All of Africa and African islands. **Australia/Oceania:** Australia, New Zealand, Papua New Guinea; most Pacific islands (except for Micronesia, Samoa, Tonga and US territories like Guam and American Samoa).

Downloaded From VideoCamera-Manual.com Manuals

Accessories (Availability differs from area to area)



Optional accessories not listed below are described in more detail in the following pages.

① SS-600/SS-650 Shoulder Strap
② WS-20 Wrist Strap
③ WL-D89 Wireless Controller
⑥ CA-570 Compact Power Adapter
⑩ Memory card
⑪ IFC-300PCU/S* or IFC-300PCU USB Cable
⑰ ZR-1000 Zoom Remote Controller
⑱ ZR-2000 Zoom Remote Controller
⑲ HTC-100/S* or HTC-100 HDMI Cable
⑳ DTC-100 D Terminal Cable
㉑ CTC-100 Component Cable
㉒ STV-250N Stereo Video Cable

* Supplied with the camcorder; not available as an optional accessory.

Downloaded From VideoCamera-Manual.com Manuals

NOTES

- Accessories that are compatible with the Advanced Accessory Shoe cannot be attached to this camcorder. Look for the **Mini ADVANCED SHOE** logo to ensure compatibility with the mini advanced shoe.

Optional Accessories

Use of genuine Canon accessories is recommended.
This product is designed to achieve excellent performance when used with genuine Canon accessories. Canon shall not be liable for any damage to this product and/or accidents such as fire, etc., caused by the malfunction of non-genuine Canon accessories (e.g., a leakage and/or explosion of a battery pack). Please note that this warranty does not apply to repairs arising out of the malfunction of non-genuine Canon accessories, although you may request such repairs on a chargeable basis.

④ Battery Packs

When you need extra battery packs, select one of the following models: BP-808*, BP-809(B)*, BP-809(S)*, BP-819, or BP-827.

* Please note that the shape/color of this battery does not match the external design of the camcorder.



When you use battery packs bearing the Intelligent System mark, the camcorder will communicate with the battery and display the remaining usage time (accurate to 1 minute). You can only use and charge these battery packs with camcorders and chargers compatible with Intelligent System.

⑤ CG-800E Battery Charger

Use the battery charger to charge the battery packs.



Downloaded From VideoCamera-Manual.com Manuals

Charging, Recording and Playback Times

The charging times given in the following table are approximate and vary according to charging conditions and initial charge of the battery pack.

Battery pack→ Charging conditions↓	BP-808 BP-809	BP-819	BP-827
Using the camcorder	150 min.	260 min.	385 min.
Using the CG-800E Battery Charger	105 min.	190 min.	260 min.

Recording and playback times given in the following tables are approximate and vary according to recording mode and charging, recording or playback conditions. The effective usage time of the battery pack may decrease when recording in cold surroundings, when using the brighter screen settings, etc.

HFM46 Using the built-in memory

Battery pack	Recording mode	Recording (maximum)	Recording (typical)*	Playback
BP-808 BP-809	MXP	125 min.	80 min.	195 min.
	FXP	125 min.	80 min.	195 min.
	XP+	130 min.	85 min.	200 min.
	SP	130 min.	85 min.	200 min.
	LP	130 min.	85 min.	200 min.
BP-819	MXP	255 min.	160 min.	390 min.
	FXP	255 min.	160 min.	390 min.
	XP+	260 min.	165 min.	400 min.
	SP	265 min.	170 min.	405 min.
	LP	270 min.	170 min.	405 min.
BP-827	MXP	385 min.	240 min.	595 min.
	FXP	390 min.	245 min.	600 min.
	XP+	400 min.	255 min.	615 min.
	SP	405 min.	255 min.	620 min.
	LP	405 min.	255 min.	620 min.

Downloaded From VideoCamera-Manual.com Manuals

Using a memory card

Battery pack	Recording mode	Recording (maximum)	Recording (typical)*	Playback
BP-808 BP-809	MXP	125 min.	80 min.	190 min.
	FXP	125 min.	80 min.	190 min.
	XP+	130 min.	85 min.	195 min.
	SP	130 min.	85 min.	195 min.
	LP	130 min.	85 min.	195 min.
BP-819	MXP	255 min.	160 min.	380 min.
	FXP	255 min.	160 min.	385 min.
	XP+	265 min.	170 min.	395 min.
	SP	265 min.	170 min.	395 min.
	LP	270 min.	170 min.	395 min.
BP-827	MXP	390 min.	245 min.	580 min.
	FXP	390 min.	245 min.	590 min.
	XP+	400 min.	255 min.	605 min.
	SP	405 min.	255 min.	605 min.
	LP	405 min.	255 min.	610 min.

* Approximate times for recording with repeated operations such as start/stop, zooming, and power on/off.

⑦ TL-H43 Tele-converter



This Tele-converter lens increases the focal length of the camcorder lens by a factor of 1.7.

- The image stabilizer is not as effective when the Tele-converter is attached.
- The minimum focusing distance at full telephoto with the TL-H43 is 3.3 m.

Downloaded From VideoCamera-Manual.com Manuals

⑧ **WD-H43 Wide-converter**

This Wide-converter lens decreases the focal length by a factor of 0.7, giving you a wide perspective for indoor shots or panoramic views.



⑨ **FS-H43U II Filter Set**

Neutral density and MC protector filters help you to control difficult lighting conditions.



⑫ **SM-V1 Surround Microphone**

Use 5.1ch surround sound to add a sense of presence to your movies. You can link the surround sound to the zoom position or use the microphone as a highly directional shotgun microphone (monaural).



⑬ **DM-100 Directional Stereo Microphone**

This highly sensitive, super-directional microphone attaches to the camcorder's mini advanced shoe. It can be used as directional microphone (monaural) or stereo microphone.



⑭ **VL-5 Video Light**

This video light enables you to record brightly in color even in dark places. It attaches to the camcorder's mini advanced shoe for cable-free operation.



Downloaded From VideoCamera-Manual.com Manuals

⑮ VFL-2 Video Flash Light

This video flash light allows you to record photos and movies even at night or in dark places. It attaches to the camcorder's mini advanced shoe for cable-free operation.

- The VFL-2 cannot be used as a flash with this camcorder.



⑯ RA-V1 Remote Control Adapter

Attaching this adapter to the mini advanced shoe allows you to use the optional ZR-2000 or ZR-1000 Zoom Remote Controller, which is useful when operating the camcorder while it is mounted on a tripod.



㉓ WP-V3 Waterproof Case

This case allows you to record movies and take photos underwater without getting the camcorder wet.



㉔ SC-2000 Soft Carrying Case

A handy camcorder bag with padded compartments and plenty of space for accessories.



This mark identifies genuine Canon video accessories. When you use Canon video equipment, we recommend Canon-brand accessories or products bearing the same mark.

Downloaded From VideoCamera-Manual.com Manuals

LEGRIA HF M46 / LEGRIA HF M406

♦ — Values given are approximate figures.

System

- **Recording System**
  Movies: AVCHD Video compression: MPEG-4 AVC/H.264;
  Audio compression: Dolby Digital 2ch; Dolby Digital 5.1ch*
  * Only when using the optional SM-V1 Surround Microphone.
  Photos: DCF (Design rule for Camera File system), compatible with Exif* Ver. 2.2
  Image compression: JPEG
  * This camcorder supports Exif 2.2 (also called "Exif Print"). Exif Print is a standard for enhancing the communication between camcorders and printers. By connecting to an Exif Print-compliant printer, the camcorder's image data at the time of shooting is used and optimized, yielding extremely high quality prints.
- **Video Signal Configuration**
  1080/50i*
  * Recordings made with the [PF25] frame rate are converted and recorded on the memory as 50i.
- **Recording Media**
  - HF M46 Built-in memory: 16 GB
  - SD, SDHC (SD High Capacity) or SDXC (SD eXtended Capacity) memory card (not included)
- **Maximum Recording Time**♦
  HF M46 16 GB built-in memory:
  MXP mode: 1 hr. 25 min. **FXP** mode: 2 hr. 5 min. **XP+** mode: 2 hr. 50 min.
  SP mode: 4 hr. 45 min. **LP** mode: 6 hr. 5 min.
  Commercially available 8 GB memory card:
  MXP mode: 40 min. **FXP** mode: 1 hr. **XP+** mode: 1 hr. 25 min.
  SP mode: 2 hr. 20 min. **LP** mode: 3 hr.
- **Image Sensor**
  1/3-type CMOS, 2,370,000 pixels♦
  Effective pixels: 2,070,000 pixels♦
- **LCD Touch Screen:** 7.51 cm (3 inch), wide, TFT color, 230,000 dots♦, touch operation
- **Microphone:** Stereo electret condenser microphone with multiple directionality settings
- **Lens**
  f=6.1-61 mm, F/1.8-3.0, 10x optical zoom, iris aperture
  35 mm equivalent: 43.6 – 436 mm♦
- **Lens Configuration:** 11 elements in 9 groups (1 double-sided aspheric element)
- **AF System**
  Autofocus (TTL + external distance sensor when set to [Instant AF]) or Manual focus
- **Filter Diameter:** 43 mm

Downloaded From VideoCamera-Manual.com Manuals

- **Minimum Focusing Distance**
  1 m; 40 cm with tele macro on at full telephoto; 1 cm at full wide angle
- **White Balance**
  Auto white balance, Custom white balance or Preset white balance settings:
  Daylight, Shade, Cloudy, Tungsten, Fluorescent, Fluorescent H
- **Minimum Illumination**
  0.1 lx ([Low Light] recording program, Shutter speed at 1/2)
  1.3 lx ([Programmed AE] recording program, Auto slow shutter [On], Shutter speed at 1/25)
- **Recommended Illumination:** More than 100 lx
- **Image Stabilization:** Optical-Shift Image Stabilizer
- **Size of Video Recordings**
  MXP, FXP mode: 1920 x 1080 pixels; **XP+, SP, LP** mode: 1440 x 1080 pixels
- **Size of Photos:** 1920 x 1080 pixels

Terminals

- **AV OUT/🎧 Terminal**
  ∅ 3.5 mm minijack; output only (dual purpose terminal also for headphones stereo output)
  Video: 1 Vp-p / 75 Ω unbalanced
  Audio: –10 dBV (47 kΩ load) / 3 kΩ or less
- **USB Terminal:** mini-B, USB 2.0 (Hi-Speed USB); output only
- **COMPONENT OUT Terminal (proprietary mini-D terminal)**
  Luminance (Y): 1 Vp-p / 75 Ω; Chrominance (P_B/P_R): ±350 mV / 75 Ω
  1080i (D3) compatible; output only
- **HDMI OUT Terminal**
  HDMI mini connector; output only; compatible with HDMI-CEC and x.v.Color

Power/Others

- **Power supply (rated)**
  7.4 V DC (battery pack), 8.4 V DC (compact power adapter)
- **Power consumption♦:** 2.7 W (SP mode, AF on)
- **Operating temperature♦:** 0 – 40 °C
- **Dimensions♦ [W x H x D] (excluding the grip belt):** 74 x 71 x 131 mm
- **Weight♦ (camcorder body only):** 350 g
- **When the recording program is set to [Underwater] or [Surface]**
  - The following functions are not available: face detection (available only for [Surface]), Instant AF, auto slow shutter, manual audio recording level adjustment, microphone attenuator, zoom speed adjustment (zoom speed is faster than [Speed 3] when [Zoom Speed] is set to [Variable])
  - The following settings are adjusted: white balance, image effects
  - Minimum focusing distance from the waterproof case lens window
    In the water: approx. 75 cm at full telephoto; approx. 5 cm at full wide angle
    In the air: approx. 1 m at full telephoto; approx. 5 cm at full wide angle

Downloaded From VideoCamera-Manual.com Manuals

CA-570 Compact Power Adapter

- **Power supply:** 100 – 240 V AC, 50/60 Hz
- **Rated output / consumption:** 8.4 V DC, 1.5 A / 29 VA (100 V) – 39 VA (240 V)
- **Operating temperature♦:** 0 – 40 °C
- **Dimensions♦:** 52 x 29 x 90 mm
- **Weight♦:** 135 g

BP-808 Battery Pack

- **Battery type**
  Rechargeable lithium ion battery, compatible with Intelligent System
- **Rated voltage:** 7.4 V DC
- **Operating temperature♦:** 0 – 40 °C
- **Battery capacity:** 890 mAh (typical); 6.3 Wh / 850 mAh (minimum)
- **Dimensions♦:** 30.7 x 23.3 x 40.2 mm
- **Weight♦:** 46 g

Downloaded From VideoCamera-Manual.com Manuals

About the music files

The specifications of the music files compatible with the camcorder are as follows.
Audio encoding: Linear PCM
Audio sampling: 48 kHz, 16 bits, 2 channels
Minimum length: 1 second
File type: WAV

The music data is saved in the memory under the following folders.

HFM46 In the built-in memory:
\CANON\MY_MUSIC\MUSIC_01.WAV to MUSIC_99.WAV

On the memory card:
\CANON\PRIVATE\MY_MUSIC\MUSIC_01.WAV to MUSIC_99.WAV

About the image files for the Image Mix function

Image files are saved in the memory under the following folders.
HFM46 In the built-in memory:
\CANON\MY_PICT\MIX_01.JPG to MIX_99.JPG

On the memory card:
\CANON\PRIVATE\MY_PICT\MIX_01.JPG to MIX_99.JPG

Weight and dimensions are approximate. Errors and omissions excepted. The information in this manual is verified as of November 2011. Subject to change without notice.

Downloaded From VideoCamera-Manual.com Manuals

Index

3D Flip View 52

A

Abroad, using the camcorder 173
AGC (automatic gain control) limit . 90
Aperture (f number) 87
Aspect ratio of a connected TV (TV type) 142
Audio equalizer 98
Audio recording level 96
AUTO mode 40
Auto slow shutter 140
Autofocus (AF):
Instant AF/Normal AF 140
Automatic backlight correction 90
Av (recording program) 87
AV OUT/🎧 terminal 99, 115, 117
AVCHD specifications 4

B

Background music 69
Battery pack
Battery information 148, 153
Charging 19
Remaining charge indicator . . 153
Beach (recording program) 79
Built-in backup battery 170

C

Camcorder supplemental disc 15
Capturing photos/video snapshot scenes from a movie 106
CINEMA mode 60
Cinema-look filters 60
COMPONENT OUT terminal 115, 117
Condensation 172
Connections to external devices . 116
Copying recordings to a memory card 120

D

Data code 105, 142
Date and time 30
Decoration 62
Deleting
Movies 54
Photos 112
Dividing scenes 108

E

Edit panel 28, 137
Editing stories 71, 72
Error messages 160
External microphone 101
Eye-Fi card 133

F

Face detection 83
Faders 86
Fireworks (recording program) 79
Frame rate 78
FUNC. panel 28, 135

G

Gallery 54, 66

H

HD to SD conversion* 129, 132
HDMI OUT terminal 115, 116
HDMI-CEC 148
Headphones 99

I

Image effects 94
Image mix 65
Image stabilizer 81
Index screen selection 52
Initializing the memory 38

L

Language 31

* HF M46 only.

Downloaded From VideoCamera-Manual.com Manuals

LCD screen dimmer 147
LCD touch screen 24, 26
Low light (recording program) 79

M

M (Manual) mode 75
Maintenance 172
Manual exposure 89
Manual focus 90
Markers 141
Memory card 33, 169
Microphone attenuator 141
Microphone directionality 97
Mini advanced shoe 100
Mode switch 27

N

Night scene (recording program) . . 79
Notification sounds 147

O

Onscreen display selection 105
Onscreen icons 150

P

P (recording program) 87
Photo numbers 144
Playback
  Movies 48, 66
  Photos 110
Portrait (recording program) 78
Power saving 44
Powered IS 82
Pre-recording 82

Q

Quick Start 46

R

Rating scenes 42, 68
Recording
  Movies 40, 60, 75
  Photos 40, 75
Recording mode 76
Recording programs 78, 87
Recording time 77
Relay recording 37
Remote sensor 21
Resetting all camcorder settings . 158
Reviewing recordings 76

S

Saving recordings 120
  Transferring to a computer . . 123
  Using external
    video recorders 127
Selecting the memory
  for playback 52
  for recording 36
Self timer 95
Serial number 18
Setup menus 29, 138
Shutter speed 87
Slideshow 113
Smart AUTO 42
Snow (recording program) 79
Sports (recording program) 79
Spotlight (recording program) 79
Story Creator 58
Sunset (recording program) 79
Surface (recording program) 80

T

Tele macro 92
Telephoto 45
Time zone/DST 31
Timeline 104
Touch & Track 85
Touch AE 89
Touch AF 90
Touch screen operations 26
Tripod 168
Troubleshooting 154
Tv (recording program) 87

U

Underwater (recording program) . . 80
Uploading movies to video sharing
  Web sites 128
USB terminal 115, 118, 127

Downloaded From VideoCamera-Manual.com Manuals

V

Video snapshot 61
Volume 50

W

White balance 93
Wide angle 45
Wind screen 141
Wireless controller 21

Z

Zoom 45
Digital zoom 140
Zoom speed 45, 138

Downloaded From VideoCamera-Manual.com Manuals

Canon

Canon Europa N.V.
Bovenkerkerweg 59-61, 1185 XB Amstelveen, The Netherlands
www.canon-europa.com

Canon UK Ltd
CCI Service Centre, Unit 130
Centennial Park, Borehamwood, Hertfordshire, WD6 3SE, United Kingdom
Telephone 0870-241-2161

Canon Australia Pty Ltd
Tel: 13-13-83 (within Australia only)
(61) 02-9805-2555
www.canon.com.au

Canon New Zealand Ltd
Tel: 0800-222-666 (within New Zealand only)
(64) 09-489-0300
www.canon.co.nz

Canon Singapore Pte. Ltd
1 HarbourFront Avenue, #04-01 Keppel Bay Tower, Singapore 098632
Tel: (65) 6799 8888, Fax: (65) 6799 8882

Canon Hongkong Company Ltd
19/F, The Metropolis Tower, 10 Metropolis Drive, Hunghom, Kowloon, Hong Kong
Tel: +852 3191 2333, Fax: +852 2428 3963

Canon Latin America, Inc.
Sales & Enquiries:
703 Waterford Way, Suite 400, Miami, FL 33126 USA

For support concerning the supplied PIXELA's software, please call PIXELA customer support (see the back cover of the Installation Guide for PIXELA's software).

© 2011 CANON INC.
30-2, Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, Japan
PUB. DIE-0391-000A

Downloaded From VideoCamera-Manual.com Manuals